



# MiBOXER FUT037Z 3 in 1 LED Controller Instruction Manual

[Home](#) » [MiBOXER](#) » MiBOXER FUT037Z 3 in 1 LED Controller Instruction Manual 

## Contents

- [1 MiBOXER FUT037Z 3 in 1 LED Controller](#)
- [2 Product features](#)
- [3 Set up output mode](#)
- [4 Compatible with these 2.4G RF remote controls \(Purchased separately\)](#)
- [5 4G RF Remote control instruction](#)
- [6 Dynamic mode table 1 \(default\)](#)
- [7 Dynamic mode table 2 \(need to switch manually\)](#)
- [8 Smartphone APP control instruction](#)
- [9 Philips Hue control instruction](#)
- [10 Alexa voice control instruction](#)
- [11 Google Home voice control instruction](#)
- [12 DMX512 LED Transmitter Control](#)
- [13 Attention](#)
- [14 Documents / Resources](#)
  - [14.1 References](#)
- [15 Related Posts](#)




**MiBOXER FUT037Z 3 in 1 LED Controller**



Indicator color	Red Light	Green Light	Blue Light
Output	RGB	RGBW	RGB+CCT

**Compatible with these 2.4G RF remote controls (Purchased separately)**



## 4G RF Remote control instruction

### Linking Code Instructions



1. Power off and power on again after 10 seconds.
2. Short press "I" button 3 times within 3 seconds.
3. Lights blink 3 times slowly means linking is done successfully.

Linking failed if light is not blinking slowly, Please follow above steps again.

(**Note:** Light that have linked can't link again)

### Unlinking Code Instructions



1. Power off 10 seconds and power on again or shortpress " SET " one time
2. Short press " I " button 5 times within 3 seconds.
3. Lights blink 10 times quickly means unlinking is done successfully.

Unlinking failed if light is not blinking quickly, Please follow above steps again. (**Note:** Light haven't linked that don't need to unlink)


### Auto transmitting & Synchronization (only for remote control)

#### Remote signal auto transmitting

One light can transmit the signals from the remote control to another light within 30m, as long as there is a light within 30m, the remote control distance can be limitless.

#### Dynamic modes auto synchronization

Multi lights can synchronize if they are in same dynamic mode and linked with same remote (distance between each light is within 30m)



### Dynamic mode table selection (only for remote control)

- **Select dynamic mode table 1:**

While the light is in static mode, short press " S+ " button 5 times quickly until blue light flashes 3 times slowly, static mode is activated successfully.

- **Select dynamic mode table 2:**

While the light is in static mode, short press " S- " button 5 times quickly until yellow light flashes 3 times slowly, static mode is activated successfully. mode table 2:

### Dynamic mode table 1 (default)

Number	Dynamic Mode	Brightness / Saturation / Speed
1	Mardi Gras	Adjustable
2	Automatic color change	
3	Sam	
4	Gemstone	
5	Twilight	
6	American	
7	Fat Tuesday	
8	Party	
9	Slow Color Splash	

### Dynamic mode table 2 (need to switch manually)

Number	Dynamic Mode	Brightness / Saturation / Speed
1	Seven colors gradual change	Adjustable
2	White light Gradual change	
3	RGB gradual change	
4	Seven colors jump to change	
5	Jump to change randomly	
6	Red light gradual change +Flash 3 times	
7	Green light gradual change +Flash 3 times	
8	Blue light gradual change +Flash 3 times	
9	White light gradual change +Flash 3 times	

### **PWM high-frequency / low-frequency switching**

#### **Switch to high frequency (16KHz):**

Press “OFF” button 1 time within three seconds and press “ON” button 5 times, Activated successfully once led light flashes 2 times quickly.

#### **Switch to low frequency (250Hz):**

Press “ON” button 1 time within three seconds and press “OFF” button 5 times, Activated successfully once led light flashes 2 times slowly.

#### **Do Not Disturb” mode is activated and shut down (default activated)**

Turn on “Do Not Disturb” mode (wide using in the area which have power failure frequently to save energy)

**2.4G RF Remote turn on and turn off instruction Turn on “Do Not Disturb” mode:**

- Press “OFF” button three times within three seconds and press “ON” button three times, Activated successfully once led light flashes four times quickly.

**Attention:** Do not disturb mode is activated

1. When the light is OFF status (For example: Use app or remote to turn off light) The light is OFF status once you turn off power and turn on again. (User must turn off and turn on power twice times to activate light or use APP/ remote to activate light)
2. When the light is ON status The light is ON status once you turn off and turn on power one time.

#### Turn off “Do Not Disturb” mode:


Press “ON” button three times within three seconds and press “OFF” button three times, closed successfully once led light flashes four times slowly.

**Attention:** The light will be always “ON” status if you turn on and turn off power once user closed “Do Not Disturb” mode. App turn on and off “Do Not Disturb” mode instruction (check details in page 8)

### Smartphone APP control instruction


Added Zigbee 3.0 gateway into “Tuya Smart” App (please review instruction of Zigbee 3.0 gateway)

1. Connect with power supply.
2. Pairing network (attention: factory default is pairing network).
  - **Way one:** Turn off and turn on light 3 times or over 3 times continuously, the light is in breathing status.
  - **Way two:** Long press SET key until indicator light flashing.
3. Open “Tuya Smart” APP to click Zigbee gateway, then click “Add sub device”.
4. Click “Indicator is flashing quickly”
5. Support APP dimming or group control and etc once added successfully.



#### App turn on and off “Do Not Disturb” mode (default activated)


Click the light which need to be set up or group control — click “More” — click “Power-on behavior” — turn on or off




## Philips Hue control instruction

### Added “Philips Hue” into the APP

1. Connect with the power supply
2. Pairing network (attention: factory default is pairing network)
  - Way one: Turn off and turn on the light 3 times or over 3 times continuously, the light is in breathing status.
  - Way two: Long press ” SET ” key until the indicator light flashes.
3. Open “Philips Hue” App to click “SETTINGS” and click “Lights”
4. Click “+” on the top of the right corner
5. Click “Search”
6. Click “Start configuration”, Follow the app instruction to complete the configuration








## Alexa voice control instruction

### Alexa control (Audio support Zigbee 3.0 protocol)

You can connect directly if your Amazon ECHO already is built-in zigbee 3.0 protocol, following model with zigbee 3.0 protocol: Amazon ECHO Plus ( 2nd Gen), ECHO (4th Gen), ECHO Studio, ECHO Show (2. Gen)




1. Connect with power supply
2. Pairing network (attention: factory default is pairing network)
  - **Way one:** Turn off and turn on light 3 times or over 3 times continuously, the light is in breathing status.
  - **Way two:** Long press the " SET " key until the indicator light flashing.
3. Say to Amazon ECHO "Alexa, Discover devices" Wait for a while to discover device, Voice control is activated


### Alexa control (Audio doesn't support Zigbee 3.0 protocol)

Please add the device into Miboxer Zigbee 3.0 gateway if your Alexa doesn't support zigbee 3.0 protocol (check details in page 7), then start following steps

1. Open Alexa App
2. Click “More” at the bottom of the right corner
3. Click “Skills & Games”




1. Click “Q” on the top of the right corner
2. Type into “Smart life” and search
3. Click “Smart Life” skill, and follow instructions to finish configuration and start voice control





## Google Home voice control instruction

Please add device into MiBoxer Zigbee 3.0 gateway (check details in page 7) and start following steps


1. Open Google Home App
2. Click “+” on the top of left corner
3. Click “Set up device”



4. Click “Works with Google”
5. Click “ ” on the top of right corner
6. Type into “Smart life” and search
7. Click “Smart Life” skill, follow instruction to finish configuration and start voice control




## DMX512 LED Transmitter Control



### DMX512 LED Transmitter Link/Unlink

1. Follow instruction of DMX512 transmitter (FUTD01), Choose the zone for the light by pressing “+” or “-” (e.g. “CH12” means zone 12)



### Link

- Power off and power on again after 10 seconds.
- When the light is on, short press “**set**” 3 times within 3 seconds
- The light blink slowly 3 times, means the linking is done successfully

### Unlink

- Power off and power on again after 10 seconds.
- When the light is on, short press “**set**” 5 times within 3 seconds
- The light blink quickly 10 times, means the unlinking is done successfully

If the link or unlink failed, please follow the above steps again.

### Attention

1. Please turn off the power supply before installation.
2. Please ensure the input voltage to be same as the requirements from the device.

3. Don't disassemble the device if you are not an expert, otherwise, it will damage it.
4. Please do not use the light in a place with widely range metal area or strong electromagnetic waves nearby, otherwise, the remote distance will be seriously affected.

Scan the QR code to watch the Zigbee series video instructions Or enter into the following link directly



- <https://miboxer.com/light/video/zigbee.html>

## Documents / Resources

[illegible]

## References

- [!\[\]\(223f1a84e0bc2cacb9c165f716817dcc\_img.jpg\) Zigbee Series Video - MiBoxer](#)