



MiCRO CONTROL SYSTEMS MCS-BMS-GATEWAY Module Instructions

[Home](#) » [MiCRO CONTROL SYSTEMS](#) » MiCRO CONTROL SYSTEMS MCS-BMS-GATEWAY Module Instructions




Product Spotlight MCS-BMS-GATEWAY



MCS-BMS-GATEWAY is a peripheral device that provides a BACnet® MS/TP, LonWorks®, or Metasys® N2 communications interface to Building Automation Systems. A configured MCS-BMS-GATEWAY protocol is field selectable.

MCS is now offering two models, the original MCS-BMS-GATEWAY with LonWork® support*, and the new MCS-BMS-GATEWAY-NL, without LonWork®.



MCS-BMS-GATEWAY-NL units have the following 2 ports: RS-485 + Ethernet
MCS-BMS-GATEWAY units have the following 3 ports: LonWorks® + RS-485 + Ethernet
*MCS-BMS-GATEWAY with LonWorks® is currently on backorder due to supply limits.



For additional information on the MCS-BMS-GATEWAY-NL or MCS-BMS-GATEWAY with LonWorks®, call 239-694-0089 sales, or email sales@mcscontrols.com

MICRO CONTROL SYSTEMS 5580 Enterprise Pkwy. Fort Myers, FL 33905
Email: sales@mcscontrols.com or call 239-694-0089
www.mcscontrols.com

Contents

- 1 Documents / Resources
- 1.1 References
- 2 Related Posts

Documents / Resources



[MiCRO CONTROL SYSTEMS MCS-BMS-GATEWAY Module](#) [pdf] Instructions
MCS-BMS-GATEWAY Module, MCS-BMS-GATEWAY, Module

References

-  [Welcome to MCS](#)

Manuals+.