

Microsoft C3K1969 Bluetooth Number Pad User Manual

[Home](#) » [Microsoft](#) » Microsoft C3K1969 Bluetooth Number Pad User Manual 

Contents

- [1 Microsoft C3K1969 Bluetooth Number Pad](#)
- [2 Swift Pair](#)
- [3 Pairing manually](#)
- [4 Pair up to 3 devices](#)
- [5 CUSTOMIZE YOUR KEYS](#)
- [6 Stay healthy](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



Microsoft C3K1969 Bluetooth Number Pad




Swift Pair

When you first turn on the keyboard, it will go into pairing mode. For PCs that support Swift Pair¹, a notification will pop up in the lower right corner saying that your keyboard has been found. Select Connect.

Pairing manually

1. Press and hold the pair key for 3 seconds. The light will blink when it's ready to pair.
2. Open the Windows 10 Start menu, then select Settings > Devices > Bluetooth & other devices > Add Bluetooth or other device > Bluetooth.

Select Designer Compact Keyboard.




Swift Pair is available on Windows 10 with the latest updates. For information about how to install the latest

updates to Windows 10, visit aka.ms/updatewindows.

Pair up to 3 devices

The lights on the pair key indicate which device is active. Press the pair key quickly to select a different device. Repeat the pairing steps from the previous page for each device.



CUSTOMIZE YOUR KEYS


To customize the keys, install Microsoft mouse and keyboard center aka.ms/mouseandKeyboard

Stay healthy

Important safety information for your keyboard, including information about musculoskeletal disorders (MSDs), is available at aka.ms/KeyboardSafety.

support.microsoft.com

Documents / Resources



[Microsoft C3K1969 Bluetooth Number Pad \[pdf\] User Manual](#)
C3K1969 Bluetooth Number Pad, Bluetooth Number Pad, Number Pad

References

- [Product safety warnings and instructions](#)
- [Mouse and Keyboard Center download](#)
- [Update Windows](#)
- [Microsoft Support](#)
- [PC accessories help & learning](#)