



[Home](#) » [MIDLAND](#) » **MIDLAND BTR1 Advanced Intercom Instruction Manual** 

Contents [[hide](#)]

- [1 MIDLAND BTR1 Advanced Intercom](#)
- [2 ON/OFF](#)
- [3 ACCESS SETTINGS](#)
- [4 PAIRING 4 UNITS IN CONFERENCE](#)
- [5 OPERATING MODES](#)
- [6 INTERCOM MODE](#)
- [7 TO OPEN/CLOSE CONFERENCE](#)
- [8 PHONE MODE](#)
- [9 Frequently Asked Questions](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)



MIDLAND BTR1 Advanced Intercom




Product Specifications


- Model: BTR1 ADVANCED
- High Definition Sound
- Output Power: 100mW
- Frequency (GHz) 2.402 – 2.480
- Max power (mW) 100

ON/OFF


DESCRIPTION OF BUTTONS



SWITCH ON




SWITCH OFF



PAIRINGS

DESCRIPTION OF BUTTONS







ATTENTION: To carry out any pairings you need to access Settings. If the Control button is pressed for fewer than 7 seconds, the device will switch itself on instead of

accessing Settings. If this occurs, repeat the process.

ACCESS SETTINGS


Status: *device off*








Press for 7 seconds	
	Beep
	Flashes
	Static

PHONE, GPS, TFT PAIRING







Status: *Settings*



Press for 3 seconds	
	Beep
	Flashes
	Select BTR1 Advanced on phone, GPS or TFT
	Beep
	Confirm (1 sec.)





Note: to pair a 2nd device in mono audio, repeat this procedure using Vol -.

MIDLAND INTERCOM PAIRING


Status: Settings	
	
Press for 3 seconds	Press for 3 seconds
 Flashes	 Flashes
 Confirm (1 sec.)	 Confirm (1 sec.)
Pairing successful	

Note: to pair another Midland intercom, follow the same procedure using the Up/Down buttons.

OTHER BRAND INTERCOM PAIRING (UNIVERSAL INTERCOM)

Status: Settings	
	
Press for 7 seconds	Follow procedure to pair with a phone
 Flashes fast (press and hold)	
 Flashes slowly (Release)	

PAIRING 4 UNITS IN CONFERENCE



Note: the Conference mode allows the simultaneous communication amongst units. All units must be paired in a “chain” configuration: the Down button of the first unit must be paired to the Up button of the second unit and so on. For a detailed description of the function go to paragraph “Conference” of the complete user manual or watch the video tutorial

RESET BLUETOOTH PAIRINGS


Status: Settings

Press together, 3 seconds

The diagram shows a hand pressing the Up and Down buttons of a unit simultaneously, with a green circle containing '3"' indicating the duration.

	Beep
	Confirm (1 sec.)
	Static


EXIT SETTINGS MODE CANCEL PAIRING



OPERATING MODES


- Intercom Mode: to communicate with another device.
- Phone Mode: for phone calls or for managing music.
- FM Radio Mode: to listen to radio, search and store stations.

Note: Phone mode and Intercom mode are enabled only when your intercom is paired to other devices.





INTERCOM MODE

FUNCTION DESCRIPTION



TO OPEN/CLOSE INTERCOM MANUALLY


Status: Intercom mode

	Press 1 time
	 Beep
	 Flashes






Nota: to communicate with Rider 1/3 repeat the process pressing the Up/(Rider 1)/Down (Rider 3) buttons.

VOX ACTIVATION/DEACTIVATION

Status: in all modes

	Press for 7 seconds
	 Voice announcement




TO OPEN/CLOSE INTERCOM BY VOICE

Status: in all modes	
	Say "Hi"
	Voice announcement
	Flashes
	Silent for 40 sec. <i>the intercom deactivates</i>
	Beep

Note: Voice activation is only possible when the intercom device is paired with the Control button.

SHORTCUT: In Intercom/FM radio modes pressing Control 2 times activates/deactivates the music.


TO OPEN/CLOSE UNIVERSAL INTERCOM

Status: Intercom mode	
	Press for 3 seconds to activate or deactivate the Universal Intercom
	 Beep
	 Flashes



Note: to activate/deactivate the audio from a different brand device, use the voice call command (for some models it is necessary to send the voice call twice)

TO ENABLE/DISABLE THE CONFERENCE MODE

Status: in all modes




Keep pressed together for 3 seconds; the Conference mode will be **enabled/disabled**.

	Voice announcement
	Connection status


Note: in Conference mode, the devices paired to Vol+/Vol- are temporarily disconnected.

TO OPEN/CLOSE CONFERENCE


Status: Conference mode



Press once
opens/closes Conference to the unit paired to **button Up**.




Press once
opens Conference to **all units paired**.



Press once
opens/closes Conference to unit paired to **button Down**.

PHONE MODE

FUNCTION DESCRIPTION



MAKING A CALL



Note: If you have a phone paired with the Vol – button, use the Down button.

SHORTCUT: In Phone mode by pressing the UP/DOWN buttons twice, turns the Intercom on/off (Rider 1, 3).

ANSWERING/ENDING A CALL – REJECTING A CALL

Status: All modes



Press 1 time to answer/end a call



Press for 3 sec. to reject a call

Note: If you have a phone paired with the Vol – button, use the Down button.

MUSIC

Status: Phone mode



Select Music app



Press 1 time Play/Pause



Press 1 time Next track




Press 1 time Previous track











Press for 3 sec. Start/stop sharing music with passenger (paired with Control button)

RADIO MODE

FUNCTION DESCRIPTION



FM RADIO

Status: Radio mode	
	<div>  </div> Press 1 time ON/OFF
	<div>  </div> Press 1 time Next station
	<div>  </div> Press for 3 seconds Next preset
	<div>  </div> Press 1 time Previous station
	<div>  </div> Press for 3 seconds Previous preset

Go to our website [midlandeurope.com](https://www.midlandeurope.com), download the complete manual and the BT Updater software.

Customize your intercom and discover all the functions with the BTPRO SetApp.

Download it here:



Frequently Asked Questions




- **How do I pair the device with other intercom systems?**

To pair with other intercom systems, follow the pairing instructions provided in the manual. Ensure both devices are in pairing mode and follow the specific steps for successful connection.

- **How do I switch between different operating modes?**

To switch between operating modes (Intercom, Music Playback, Radio), use the designated buttons as outlined in the manual. Press once or hold for a specified duration to switch modes accordingly.

Documents / Resources

	MIDLAND BTR1 Advanced Intercom [pdf] Instruction Manual 714f709753eb2c1467f96356280246f6d6c4f156, BTR1 Advanced Intercom, BTR1, Advanced Intercom, Intercom
	MIDLAND BTR1 Advanced Intercom [pdf] User Guide BTR1 Advanced Intercom, BTR1, Advanced Intercom, Intercom
	MIDLAND BTR1 Advanced Intercom [pdf] User Guide BTR1 Advanced Intercom, BTR1, Advanced Intercom, Intercom

References

- [User Manual](#)

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.