

MIDLAND BTRUSH Mesh and Bluetooth Conference System User Guide

Home » MIDLAND » MIDLAND BTRUSH Mesh and Bluetooth Conference System User Guide 🖔



BTRUSH
MESH & BLUETOOTH CONFERENCE SYSTEM



HIGH DEFINITION SOUND BY RFC POCKET GUIDE

Contents


- 1 ON/OFF
- **2 PAIRINGS**
- **3 INTERCOM MODE**
- 4 PHONE MODE
- **5 ANSWERING/ENDING A CALL REJECTING A**

CALL

- 6 MUSIC
- **7 RADIO MODE**
- 8 FM RADIO
- 9 Documents / Resources
 - 9.1 References
- **10 Related Posts**

ON/OFF

DESCRIPTION OF BUTTONS



SWITCH ON




SWITCH OFF



PAIRINGS


DESCRIPTION OF BUTTONS



ATTENTION: To carry out any pairings you need to access Settings. If the Control button is pressed for fewer than 7 seconds, the device will switch itself on instead of accessing Settings. If this occurs, repeat the process.

ACCESS SETTINGS

Status: device off



PHONE, GPS, TFT PAIRING

Status: Settings



Note: to pair a 2nd device in mono audio, repeat this procedure using Vol -.







Press for 3 seconds		Press for 3 seconds			
<u>~</u>	Flashes	Flashes			
711	Confirm (1 and)	Confirm (1 and)			
	Confi rm (1 sec.)	Confi rm (1 sec.)			
Pairing successful					


OTHER BRAND INTERCOM PAIRING Status: Settings

Status: Settings





prss for 7 seconds		
	Flashes fast (press and hold)	
~~	Flashes slowly (Release)	Follow procedure to pair with phone
4		






Status: Settings







Status: Settings



Frequency (GHz)	
2.402 – 2.480	

EXIT SETTINGS MODE CANCEL PAIRING

Status: Settings




OPERATING MODES

- A. Intercom Mode: to communicate with another device via Mesh or Bluetooth.
- B. Phone Mode: for phone calls or for managing music.
- C. FM Radio Mode: to listen to, search for, and store radio stations.

Note: Phone mode is only active when there are devices paired to the Vol+/Vol- buttons.

CHOOSE OPERATING MODE



Note: By pressing simultaneously Vol + and Vol – for 1 second, BT Rush communicates the selected operating mode.

Attention: to communicate the participants must be in the same Mesh group and have different IDs.



Conference Mesh Group: 10 people in a 1.4 Km bubble. **Mesh Dynamic Repeat Group:** 6 people within 3.5 Km.

Mesh Dynamic Repeat Secure Group: 6 people within 3.5 Km with Secure key assigned for private

communications.

INTERCOM MODE

The default Mesh Group is set to Dynamic Repeat. For further information consult the online manual (www.midlandeurope.com) or the tutorials on YouTube – Midland World.

MESH IDENTIFICATION CODE (ID) SELECTION






TABLE 1 - IDS ASSIGNED TO THE VARIOUS GROUPS:


GROUP	ID	GUEST	LED
Mesh Conference	1-10	Infi nite	
Mesh Dynamic R epeat	1-6	Infi nite	
Mesh Dynamic Repeat Secure	1-6	Infi nite	

Guest: listening mode only

FUNCTION DESCRIPTION








Note: to communicate with Rider 1 repeat the process of pressing the Up button.



Status: in all modes



Note: Voice activation is only possible with an intercom paired with the down button.


VOX ACTIVATION/DEACTIVATION

Status: in all modes




SHORTCUT: In Intercom mode pressing Control 2 times activates/deactivates the music.






Note: to activate/deactivate the audio from a different brand device, use the voice call command (for some models it is necessary to send the voice call 2 times)



SHORTCUT: In Phone/FM Radio modes pressing Control 2 times activates/deactivates Mesh communication.

PHONE MODE

FUNCTION DESCRIPTION






Note: If you have a phone paired with the Vol – button, use the Down button.

SHORTCUT: In Phone/FM Radio modes pressing the Down button 2 times turns the Intercom on/off.

ANSWERING/ENDING A CALL REJECTING A CALL

Status: Phone mode



Note: If you have a phone paired with the Vol – button, use the Down button.


MUSIC

Status: Phone mode




RADIO MODE

FUNCTION DESCRIPTION



FM RADIO

Status: Radio mode



Go to our website www.midlandeurope.com, download the complete manual and the BT Updater software.

Customize your intercom with the BTPRO SetApp. Download it here:



https://play.google.com/store/apps/details? id=com.midlandeurope.btsetapppro&hl=it&gl=US

https://apps.apple.com/it

Documents / Resources



MIDLAND BTRUSH Mesh and Bluetooth Conference System [pdf] User Guide BTRUSH, Mesh and Bluetooth Conference System



<u>MIDLAND BTRUSH Mesh and Bluetooth Conference System</u> [pdf] User Guide BTRUSH, Mesh and Bluetooth Conference System, Bluetooth Conference System, Mesh Conference System, Conference System

References

- O Startseite | Alan Electronics
- Midland Europe | Radio and CB, Motorbike intercom systems and Action Cams

Manuals+, home privacy