

**Contents** [ [hide](#) ]

- [1 MIDLAND LS2 Interroom Spectrum System](#)
- [2 Product Specifications](#)
- [3 ON/OFF](#)
- [4 PAIRING](#)
- [5 INTERCOM](#)
- [6 PHONE](#)
- [7 MUSIC](#)
- [8 Frequently Asked Questions](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)

# MIDLAND

## MIDLAND LS2 Interroom Spectrum System



## Product Specifications

- Compatibility: LS2 intercom, Obi (Midland, Cardo), other brands, phone, TFT, GPS
- Intercom Pairing: Up to 3 intercom devices can be paired

- Bluetooth Pairings Reset: Press all buttons for 9 seconds
- Volume Adjustment: Press and hold to adjust volume
- Language Change: Press and hold for language selection

## ON/OFF

Led

Front button

Control button

Back button

SWITCH ON	SWITCH OFF
Status: UNIT OFF	Status: UNIT ON

<div>3"</div> <div>Press together for 3 seconds</div>	<div>3"</div> <div>Press together for 3 seconds</div>
<div>Flashes</div>	<div>Flashes</div>
<div>Power on</div>	<div>Power off</div>

## PAIRING

Pairing to:  
LS2 intercom, Obi  
(Midland, Cardo)  
and other brands

Pairing to: phone, TFT, Gps


Pairing to:  
LS2 intercom, Obi  
(Midland, Cardo)  
and other brands

Pairing to:  
LS2 intercom, Obi  
(Midland, Cardo)  
and other brands

Pairing to:  
LS2 intercom, Obi  
(Midland, Cardo)  
and other brands

## PHONE/GPS/TFT PAIRING

## Status: UNIT OFF



7"

Press for 7 seconds



Pairing phone



Flashes




Select Spectrum on phone, GPS or TFT



Pairing successful

## LS2/OBI INTERCOM PAIRING

### Status: UNIT ON



7"

Press for 7 seconds



Flashes



Pairing Intercom

### LS2 or OBI (Midland&Cardo)


Follow the **intercom** pairing procedure  
(See instruction of the device)

**Pairing successful**

Note: By following the same procedure, it is possible to pair two further devices to the Front or Back buttons.

## OTHER BRAND INTERCOM PAIRING (UNIVERSAL INTERCOM)

## Status: UNIT ON



7"

Press for 7 seconds



Flashes



Pairing Intercom




Follow the **phone** pairing procedure  
(See instruction of the device)

Note: By following the same procedure, it is possible to pair two further devices to the Control or Back buttons.

## RESET BLUETOOTH PAIRINGS

### Status: UNIT ON



9"


Press all the buttons together  
for 9 seconds




Flashes

## VOLUME ADJUSTMENT

### Status: While listening to an audio source (music, phone,...)




Keep pressed to increase  
the volume



Keep pressed to decrease  
the volume

## CHANGE LANGUAGE

### Status: UNIT ON



9"

Keep pressed for more than  
9 seconds




"Battery status" in the various  
languages. Release the buttons  
as soon as you hear the  
announcement in the desired  
language.

## INTERCOM

### OPEN/CLOSE INTERCOM

**Status: UNIT ON and already paired**



Press once the button used for LS2/Obi pairing




Beep



Flashes

Note: to communicate with the other intercom paired to Front/Back keys, repeat the procedure on the correspondent key.

**Status: UNIT ON and already paired**



Press once the button used for LS2/Obi pairing



Beep



Flashes


Note: to open/close the audio from a different brand device, use the voice call command (for some models, it is required to send the voice call twice).

Note: to communicate with the other intercom paired to Control/Back keys, repeat the procedure on the correspondent buttons.

## PHONE

### VOICE DIAL (ACTIVATE CALL, NAVIGATOR, MUSIC)

**Status: UNIT ON and paired to a phone**



Press twice



Voice assistance response  
(Google assistant, Siri)



Give instructions




Flashes




Call, Navigator, Music

TO ANSWER/END/REJECT A CALL

Status: While listening to an audio source (music, phone,...)




Press once any button to answer or end a call



Press for 3 seconds any button to reject a call

Note: if the Automatic Response is enabled, the phone automatically answers after 8 seconds.

Status: UNIT OFF



Press 9 seconds



Enable



Flashes


MUSIC

PLAY/PAUSE


Status: UNIT ON and paired to a phone




Select Music App



Press 2 seconds Play/Pause



Press twice Next track



Press twice Previous track


MUSIC SHARE WITH PASSENGER

**Status: UNIT ON and paired to a phone**



Select Music App

Open Intercom



2"

Press 2 seconds



Music Share

**Note:** To stop the Music Share press the same button.

Frequency (GHz)	Max power (mW)
2.402 - 2.480	100

- Scan the QR code to access the support page, update the firmware and find all info about LS2 SPECTRUM, including video tutorial and installation.
- Produced and imported by: MIDLAND EUROPE S.R.L.
- Via R. Sevardi 7, 42124 Reggio Emilia – Italy
- Distributed by: LS2
- C/ Colom 372 – 08223 Terrassa, BARCELONA, SPAIN



## Frequently Asked Questions


- **Q: How can I reset Bluetooth pairings?**

**A:** To reset Bluetooth pairings, press all buttons together for 9 seconds until it flashes.

- **Q: How do I adjust the volume?**


**A:** While listening to an audio source, keep the volume button pressed to increase or decrease the volume.


# Documents / Resources

	<a href="#">MIDLAND LS2 Interroom Spectrum System [pdf]</a> User Guide LS2, LS2 Interroom Spectrum System, Interroom Spectrum System, Spectrum System
---	--

## References

- [User Manual](#)

 Interroom Spectrum System, LS2, LS2 Interroom Spectrum System, MIDLAND, Spectrum

 MIDLAND System

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.



[Post Comment](#)

## Search:

[Search](#)

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.