



Home » MIDLAND » MIDLAND SMARTCOM Smartphone Bluetooth User Guide 🟗




2 – POCKET GUIDE

Contents [hide]

- 1 DESCRIPTION LEGENDA
- 2 PAIRING TO PHONE/GPS
- 3 PAIRING ANOTHER SMARTCOM OR MIDLAND
- 4 PAIRING TO A DIFFERENT MODEL/BRAND UNIT
- 5 OPEN/CLOSE INTERCOM
- **6 RESET ALL PAIRINGS**
- 7 ANSWER A CALL
- **8 VOLUME ADJUSTMENT**
- 9 MUSIC
- 10 CHANGE LANGUAGE
- 11 Documents / Resources
 - 11.1 References

DESCRIPTION – LEGENDA



AUDIO FEEDBACK

••	Button+/Button OPERATION
X"	Press X sec.
	Press X times
<u> </u>	Sound alert VISUAL FEEDBACK
	Blue led blinking
	Red led blinking
	Red/blue led blinking
	Purple led
	Steady blue led
	Steady red led

POWER ON

33 m	Press 3 sec.
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Led Blinking
হী ((০	"Power on"
<u> </u>	Battery status

OWER OFF

37 Cm	Press 3 sec.
***	Led Blinking
<u> </u>	"Power off"

PAIRING TO PHONE/GPS

Status: Power off

	Press 7 sec.
	Led blinks alternately
MENU Pereng SSANTCOM Pareng Gode 1000	Searching Bluetooth device on your phone. If needed, enter PIN code (0000).
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Four led blinkings
3 ((0	"Pairing successful"
3)((0	"Device connected"

PAIRING ANOTHER SMARTCOM OR MIDLAND

Status: Both units powered on

• Pm	Press 7 sec. on both devices
<u> </u>	"Pairing"
	Led blinks alternately on both devices

	Three led blinkings on both devices
<u> </u>	"Pairing successful"

PAIRING TO A DIFFERENT MODEL/BRAND UNIT

Status: Both units powered on

• •	Press 7 sec.	
	Led blinks alternately	
<u> </u>	"Pairing"	
	Follow the "phone" pairing procedure	
Both units stop flashing		
3 ((0	"Pairing successful"	

OPEN/CLOSE INTERCOM

Status: units on and paired

	Press once
<u> </u>	"Beep"
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Led blinks: audio active

RESET ALL PAIRINGS

Status: power on

	Press 9 sec.
	Steady led for 3 sec.
3) ((0	"Beep"

VOICE CALL

Status: unit on and connected to a phone

Press twice
Voice assistant (Google assistant, Siri)
Press twice to end the call

ANSWER A CALL

Status: phone rings

	Press once to answer a call
	Press once to end a call
3"	Press 3 sec. to reject a call

Status: while listening to an audio source (intercom, music, phone call...)

VOLUME ADJUSTMENT

To turn off/on the Auto Answer when device is turned off, press + and – for 9 seconds.

Keep pressed to increase the volume
Keep pressed to decrease the volume

MUSIC

Status: unit on and connected to the phone


	Select a music APP from the phone
	Press 1 time Play/Pause
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Blinking
	Press 3 times Song fordward
	Press 3 times Song backward

CHANGE LANGUAGE

Status: unit on

	Keep pressed for more than 9 seconds
<u> </u>	"Battery status" in the various languages. Release + button to select the desired one.

Frequency	2.4GHz
-----------	--------



The power supplied by the charger must be between min 05 watt required by the radio equipment, and max 05 watt to achieve maximum charging speed.

To download the complete manual visit www.omniaretail.it



Distributed by:

OMNIA RETAIL srl

Via T.Grossi, 5 – 20841 Carate Brianza

MB (Italia) - www.omniaretail.it

Produced and imported by:

MIDLAND EUROPE srl

Via R. Sevardi 7 – 42124 Reggio Emilia Italia

Documents / Resources

h, Bluetooth



MIDLAND SMARTCOM Smartphone Bluetooth [pdf] User Guide SMARTCOM Smartphone Bluetooth, SMARTCOM, Smartphone Bluetoot

References

- User Manual
 - bluetooth, MIDLAND, Smartcom, SMARTCOM Smartphone Bluetooth, Smartphone
- MIDLAND Bluetooth

Leave a comment

Your email address will not be published. Required fields are marked *

Comment * Name Email Website Save my name, email, and website in this browser for the next time I comment. **Post Comment** Search: e.g. whirlpool wrf535swhz Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.