

# midocean MO6169 Bottle with Touch Thermometer User **Manual**

Home » midocean » midocean MO6169 Bottle with Touch Thermometer User Manual



### **Contents**

- 1 midocean MO6169 Bottle with Touch
- **Thermometer**
- 2 Function
- **3 Battery Replacement Instructions**
- 4 Documents / Resources
- **5 Related Posts**



midocean MO6169 Bottle with Touch Thermometer



Hereby, MOB, declares that item MO6169 is in Compliance with the essential requirements and other relevant conditions of Directive 2014/30/EU. A copy of the DOC (Declaration of Conformity) is available at: DOC@reclamond.com or MOB, PO BOX 644, 6710 BP (NL).

### **Function**

When touching the display screen which is in the top of the lid it will indicate the temperature inside the bottle.

## **Battery Replacement Instructions**



- Open the black lid cover in an anti-clockwise direction
- · Replace with a new battery
- Close the black lid cover tightly in clockwise direction

This product may emit a scent when it is new. Handwash and dry thoroughly before use. Clean with warm water and mild detergents only, do not use detergents that contain bleach or chlorine. Do not over fill as liquid may escape. Not suitable for carbonated, alcohol and dairy-based beverages. Please use caution when opening

### **Documents / Resources**



midocean MO6169 Bottle with Touch Thermometer [pdf] User Manual MO6169, Bottle with Touch Thermometer

Manuals+,