





MIGHTY MULE MMT103 3 Button Entry Remote Instruction Manual

[Home](#) » [Mighty Mule](#) » MIGHTY MULE MMT103 3 Button Entry Remote Instruction Manual 

MIGHTY MULE MMT103 3 Button Entry Remote



Contents

1 DESCRIPTION

2 PROGRAMMING THE REMOTE TO THE GARAGE DOOR OPENER

3 PROGRAMMING/LEARNING A GATE OPENER REMOTE

4 DELETING A DIP SWITCH CODE

5 REPLACING REMOTE'S BATTERY

6 WARNING

7 CUSTOMER SUPPORT

8 Documents / Resources

8.1 References

9 Related Posts

DESCRIPTION


The MMT103 Code Safe entry remote is a wireless radio control designed for use with Mighty Mule garage door openers and can also be programmed to your Mighty Mule gate openers. One remote for two or three devices.

Each of the remote's three buttons will send a unique code when pressed. All buttons can be used to activate an individual Mighty Mule garage door opener, multiple Mighty Mule garage door openers or Mighty Mule garage door opener(s) and gate opener(s).


PROGRAMMING THE REMOTE TO THE GARAGE DOOR OPENER

PROGRAMMING

1. Press the operator's LEARN button (S3) until the operator's red LED flashes once and the light turns on. A remote must be added while the light is still on (15 seconds).



2. Send a signal from the desired button on the remote. The operator's light and the red LED will flash once if the remote was added.




Repeat to program additional buttons for other garage door openers.


After programming, test the remote from various locations. Be sure the door or gate areas are clear. Activate the remote and verify that the receiver triggers the opener(s).

PROGRAMMING THE REMOTE TO MIGHTY MULE 7TH GENERATION AUTOMATIC GATE OPENER

1. Press the gate opener's LEARN button (S3) located on the control board.



2. Press the desired button on the remote to complete programming process. The remote is now programmed to the gate opener.




DELETING A REMOTE FROM THE GARAGE DOOR OPENER OR GATE OPENER

If a remote is already programmed to the opener and you want to delete it, follow the same procedure as PROGRAMMING THE REMOTE above. The opener will recognize the remote and delete it from memory.

PROGRAMMING/LEARNING A GATE OPENER REMOTE

If you have a Mighty Mule gate opener, you can program one of the buttons to open the gate also.


1. Press and hold button 1 and button 3 at the same time for 5 seconds. The LED will turn on, then release the buttons.



2. Press and release the button that you want to learn the gate opener code to.




3. Hold the gate opener remote with the front/top facing the side of the MMT103. Press the button on the gate opener remote and the LED on the MMT103 will blink twice when it has successfully learned the code.



DELETING A DIP SWITCH CODE

1. Press and hold button 1 and button 3 at the same time for about 5 seconds. The LED will turn on, then release the buttons.




2. Press and hold the button you want to delete a code from for 5 seconds, then the LED will blink twice indicating the DIP switch code was successfully removed.



REPLACING REMOTE'S BATTERY

When the red light on the remote glows dimly, or fails to light at all when the remote is activated, the batteries need replacing.

1. Twist a coin, visor clip or screw drive in slot to open case.
2. Lift off top of case.
3. Carefully remove the circuit board.
4. Remove old battery and properly dispose them.
5. Replace battery with new Type 2032 battery – PLUS SIDE UP.
6. Re-assemble the remote.



WARNING

KEEP BATTERIES OUT REACH OF CHILDREN. Swallowing batteries can lead to serious injury or death. If you suspect someone has swallowed a battery, go to the hospital immediately. Do not induce vomiting or eat or drink anything.

For more information, call the National Battery Ingestion Hotline: 202-625-3333.

The battery identification number for this product is CR2032.

WARNING: Changes, modifications or adjustments not expressly approved by Nice North America LLC could void the user's authority to operate this equipment. There Are No User Serviceable Parts.

NOTICE: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada License-exempt RSS standard. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

MIGHTY MULE LIMITED WARRANTY

This product is warranted to the original consumer ("You") by Nice North America against defects in material and

workmanship for a period of twelve (12) months from the date of purchase.

This limited warranty only extends to you if the item was purchased directly from Nice North America or through an authorized sales partner. Nice North America will, at its option, either repair or replace any product that it confirms is defective and eligible for service under this warranty and will return the repaired or replaced product to you at Nice North America's cost. This warranty does not apply to damage to the product from negligence, abuse, abnormal usage, misuse, accidents, acts of god, normal wear and tear, failure to follow the manufacturer's instructions, or arising from improper installation, storage or maintenance. Some states do not allow the exclusion or limitation of incidental and consequential damages, so the above limitation or exclusion may not apply. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state. In order to be protected by this warranty, a copy of the receipt or other valid proof of purchase must be provided with any product that is being repaired or replaced under this warranty. In order to initiate warranty service for your product, please contact Tech Services at (800) 421-1587 for a Return Authorization Number ("RA") and other important details. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state. In order to be protected by this warranty, a copy of the receipt or other valid proof of purchase must be provided with any product that is being repaired or replaced under this warranty. In order to initiate warranty service for your product, please contact Tech Services at (800) 421-1587 for a Return Authorization Number ("RA") and other important details.

CUSTOMER SUPPORT

Mighty Mule Sales: 800-543-4283

Mighty Mule Technical Service 800-421-1587

For more information about the full line of Mighty Mule Automatic Gate Operators,
Gate Openers and Access Controls visit

www.mightymule.com

Niceforyou.com


©2023 Nice North America LLC.

Mighty Mule is a registered trademark of Nice North America LLC.

All rights reserved.





Documents / Resources



[MIGHTY MULE MMT103 3 Button Entry Remote](#) [pdf] Instruction Manual
MMT103 3 Button Entry Remote, MMT103, 3 Button Entry Remote, Entry Remote

References

-  [Nice North America - Home Automation Systems](#)
-  [Find Smart Gate Opener Solutions - Automatic Electric Gate Openers – Mighty Mule](#)
- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.