



Home » Support » Mikikin Q3 Rechargeable Desk Fan User Manual 📆

Contents [hide]

- 1 Mikikin Q3 Rechargeable Desk Fan
- 2 INTRODUCTION
- 3 SPECIFICATION
- 4 WHAT'S IN THE BOX
- **5 TROUBLESHOOTING**
- 6 PROS & CONS
- 7 WARRANTY
- **8 FREQUENTLY ASKED QUESTIONS**
- 9 How long does the battery last on the Mikikin Q3 Rechargeable Desk Fan?
 - 9.1 References



Mikikin Q3 Rechargeable Desk Fan



INTRODUCTION

Mikikin Personal Fan-The Perfect Companion to Keep You Cool in This Summer


• 180° foldable and ergonomic handle – comfortable to hold and can be used as your hand fan and desk fan.



- Quiet low frequency Suitable for use in quiet places such as churches, meetings, etc.
- 2000mAh battery capacity as big as other fans on the market, longer-lasting and suitable for outdoor use.
- Easy to carry -either carry it or put it on the table or fold it up and put it in your bag.

LED Display

The digital display is designed to ensure that the remaining power is readily visible, thereby preventing sudden power outages. It is exceedingly efficient.



180° Ultra-wide Angle

This desk fan is equipped with a unique geometric square guide body structure that is specifically engineered to collect wind from all angles. This design generates a high-speed, forceful airflow that effectively cools your personal space.

Simple One-Button Control 5th gear operating speed



• First gear: twelve hours

• Second gear: eight hours

• Third gear: six hours

• Fourth gear: four hours

• 5th gear (circulating wind): 10 hours

One USB Type-C port



The innovative Fold-up The hanging fan design allows you to experience the coolness at any time and in any location, freeing your hands. The elegant and portable desk fan ensures that you remain comfortable and cool while applying cosmetics. It is the ideal accessory for any cosmetics routine, regardless of whether you are at home or on the go, due to its compact design and high-speed airflow.

SPECIFICATION

• high-velocity airflow personal fan

• Battery Capacity: 2000 mAh

• Running Time: 4-12 hours

• Interface Type: USB Type C

• Input Power: 5V/1A

Rated power:3.5W

• Product weight: 8.8oz





WHAT'S IN THE BOX

- One table fan
- One user manual

TROUBLESHOOTING

Issue	Possible Cause	Solution

Issue	Possible Cause	Solution
Fan won't turn on	Battery completely draine	Charge the fan fully for at least 2 h ours
Fan stops suddenly	Battery low or overheatin	Recharge battery and allow fan to c ool before reuse
Battery percentage not displaying	Faulty digital display or so ftware glitch	Restart the fan or reset by turning o ff/on
Fan makes unusual noise	Dust or debris in blades o r motor	Clean blades and check motor for o bstruction
Unable to adjust sp eed settings	Faulty speed control dial or button	Check dial operation; reset fan pow er
Fan doesn't charge	Faulty USB cable or port	Try a different USB cable and charger
Charging indicator not working	LED light malfunction	Confirm charging by battery status or try a different charger
Fan tilt mechanism stuck	Debris or tight joint	Gently loosen and clean the hinge area
Fan airflow weak	Blades dirty or battery lo	Clean fan blades; recharge fully
Fan battery drains quickly	Battery degradation or us age at high speed	Reduce speed setting; consider rep lacing battery if old

PROS & CONS

Pros

- Intelligent battery display keeps you informed of power status
- Lightweight and highly portable with foldable design

- Five adjustable speeds suit any cooling preference
- Quiet operation ideal for office and bedroom use
- Versatile 180-degree swivel stand for multiple positioning options

Cons

- Battery life could be longer for heavy use
- Limited color options (only black)
- Plastic build may feel less durable for some users
- No remote control feature
- Charging cable not included in some packages

WARRANTY

The Mikikin Q3 Rechargeable Desk Fan comes with a **180-day** hassle-free replacement and refund policy provided by Mikikin. This warranty covers defects and performance issues arising under normal use conditions. Customers are encouraged to contact Mikikin's responsive customer service team within 12 hours for any problems or concerns to benefit from prompt assistance and solutions.

FREQUENTLY ASKED QUESTIONS

What is the brand and model of the rechargeable desk fan with power display?

This is the Mikikin Q3 Rechargeable Desk Fan, featuring a 2000mAh battery and a digital display for battery status.

How long does the battery last on the Mikikin Q3 Rechargeable Desk Fan?

The Mikikin Q3 can run for about 4.5 hours on a full 2-hour charge.

How many speed settings are available on the Mikikin Q3 Rechargeable Desk Fan?

The Mikikin Q3 offers 5 adjustable wind speeds ranging from sleep wind to

circulating wind for customized comfort.

Why does the battery indicator on my Mikikin Q3 Rechargeable Desk Fan flash continuously?

A flashing battery light means the fan is currently charging. If it continues flashing after extended charging, the battery or charger may be faulty.

How do I clean the Mikikin Q3 Rechargeable Desk Fan safely?

Turn off and unplug the fan before wiping it with a dry or slightly damp cloth. Avoid water contact with the motor or battery compartment.

How can I contact customer support for the Mikikin Q3 Rechargeable Desk Fan?

Mikikin offers a 180-day hassle-free replacement and refund policy. Contact their customer service for assistance with issues.

Is the Mikikin Q3 Rechargeable Desk Fan suitable for travel?

Absolutely. Its compact size, lightweight design, foldable stand, and rechargeable battery make it perfect for travel, camping, or office use.

References

- User Manual
 - B0C1VJ37FH, Mikikin, Mikikin Q3, Q3, Rechargeable Desk Fan, user
- Mikikin manual

Leave a comment

Comment *		
Name		
Email		
Website		
Save my name, email, and website in this browser for the next time I com	nment.	
Post Comment		
Search:		
e.g. whirlpool wrf535swhz	Search	

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.