




MINELAB MDS-10 Dual Sensor Detector User Guide

[Home](#) » [MINELAB](#) » MINELAB MDS-10 Dual Sensor Detector User Guide 




Contents


- [1 MDS-10 Unfolding Procedure](#)
- [2 Factory Reset](#)
- [3 Quick Start](#)
- [4 Documents / Resources](#)

MDS-10 Unfolding Procedure


1. Extend the Lower Shaft




2. Unfold the Detector




3. Unfold the Sensor Head



4. Position the Armrest






5. Extend the Middle Shaft




Attach Battery



a




Factory Reset




Quick Start


1. Turn On




2. MD Ground Balance



3. MD Test Piece





4. GPR Skyshot



5. GPR Test Target



6. Begin Detecting



Documents / Resources

	MINELAB MDS-10 Dual Sensor Detector [pdf] User Guide MDS-10, MDS-10 Dual Sensor Detector, MDS-10 Detector, Dual Sensor Detector, Detector
--	--