



[Home](#) » [Support](#) » **Minetom 17-ft Star String Lights User Manual** 

Contents [[hide](#)]

- [1 Minetom 17-ft Star String Lights](#)
- [2 INTRODUCTION](#)
- [3 SPECIFICATIONS](#)
- [4 WHAT'S IN THE BOX](#)
- [5 FEATURES](#)
- [6 SETUP GUIDE](#)
- [7 CARE & MAINTENANCE](#)
- [8 TROUBLESHOOTING](#)
- [9 PROS & CONS](#)
- [10 WARRANTY](#)
- [11 FREQUENTLY ASKED QUESTIONS](#)
- [12 VIDEO – PRODUCT OVERVIEW](#)
- [13 References](#)



Minetom 17-ft Star String Lights



INTRODUCTION

Charming decorative lighting is provided by the Minetom 17-ft Star String Lights, which cost **\$8.99** and require three AA batteries (not included). These lights, which come with 50 warm-white LED star lamps and a 17-foot long, waterproof cord, add romance and atmosphere to patios, weddings, parties, and bedrooms. They are easy and energy-efficient, with an integrated timer that automatically turns them on for six hours and off for eighteen. For peace of mind, they are safe to use both indoors and outdoors in protected spaces and have an IP44 waterproof rating. They remain cool to the touch. They are ideal for adding gentle, glowing charm to any occasion or area because they are lightweight (about 7.8 oz) and simple to hang.

SPECIFICATIONS

Brand	Minetom
Model	Star String Lights (50 LED)

Price	\$8.99
Power Source	3 × AA batteries (not included)
Length	17feet (≈5.2m)
LEDs	50 star-shaped LEDs
Bulb Size	~1.3" each
Light Color	Warm White (~3000K)
Wire Color	Thin clear copper wire
Built-in Timer	6h ON / 18h OFF cycle
Waterproof Rating	IP44
Indoor/Outdoor Use	Indoor or sheltered outdoor areas
Material	Waterproof plastic (stars), copper wire
Wattage	Approx. 2–3W (battery safe)
Weight	~7.8oz
Controls	Touch button on battery pack
Warranty	Amazon 30-day returns; Minetom support offered



WHAT'S IN THE BOX

- 1 × 17-ft Minetom star string lights (50 LEDs)
- 1 × User manual
- Battery box with integrated timer button

FEATURES

- **Battery Powered:** Runs on 3 AA batteries no outlet required for operation.



17ft Battery Operated Star String Lights

- **String Length:** 17 feet long and includes 50 charming star-shaped LED lights.

17 ft 50 LED Star String Lights



- **Light Tone:** Emits a cozy warm white glow around 3000K for a welcoming atmosphere.
- **Timer Function:** Built-in cycle runs 6 hours on and 18 hours off automatically.



Built-in Timer

Spare yourself remembering to turn it on and off each evening while saving the power simultaneously

6 Hours On + 18 Hours Off

- **Water Resistance:** IP44-rated star bulbs are safe for light splashes and damp environments.



- **IP65 Waterproof Star Lights**
Perfect for outdoor and indoor use
- **Cool Operation:** Low-voltage LEDs stay cool even after long hours of use.
- **Discreet Wire:** Clear copper wiring blends in for a clean, subtle display.
- **Lightweight Design:** Weighs only 7.8 oz easy to hang or move as needed.
- **Simple Controls:** Touch-button control is built into the battery pack for easy access.
- **Sturdy Build:** Durable plastic stars provide long-lasting decorative charm.
- **Safe Use:** Stays safe to touch even after hours of lighting.
- **Decor Versatility:** Perfect for decorating bedrooms, parties, trees, and more.
- **Auto Lighting:** Automatically turns on at night with no need to manually switch.
- **Efficient Battery Life:** Can last up to 48 hours on one set of batteries.
- **Portable Setup:** Lightweight and cordless use indoors or out with ease.



SETUP GUIDE

- **Unpack Items:** Remove the lights and instructions from the packaging.
- **Insert Batteries:** Place 3 AA batteries into the compartment, ensuring correct polarity.
- **Activate Timer:** Press the power button once to begin the automatic timer cycle.
- **Initial Delay:** Wait about 30 seconds for the lights to respond.
- **Hang the Lights:** Arrange across walls, beds, plants, or furniture as desired.
- **Place Battery Pack:** Tuck the battery pack away in a discreet, accessible spot.
- **Support Evenly:** Distribute the wire evenly so it stays supported and secure.
- **Timer Control:** Press the button again to restart or disable the timer function.
- **Battery Check:** Replace batteries when brightness begins to fade—usually

every few weeks.

- **Indoor Storage:** Store lights inside when not in use to preserve condition.
- **Water Precautions:** Do not submerge; safe only in lightly wet or protected outdoor spaces.
- **LED Replacement:** Change any damaged bulbs with similar-rated replacements.
- **Safety First:** Keep lights and battery pack away from children or pets.
- **Inspect Regularly:** Check the wire occasionally for wear or damage.

CARE & MAINTENANCE

- **Turn Off First:** Switch off the timer before performing any maintenance or cleaning.
- **Battery Removal:** Take out the batteries if storing the lights for more than a month.
- **Gentle Cleaning:** Wipe the star covers carefully with a soft, dry cloth.
- **Avoid Water Spray:** Keep away from jets of water or heavy rain exposure.
- **Routine Inspection:** Check bulbs and wires regularly for any signs of wear.
- **Safe Storage:** Use the original box to protect the stars and wiring during storage.
- **Battery Care:** Replace used batteries promptly to avoid corrosion or leakage.
- **Temperature Warning:** Keep away from excessive heat or freezing temperatures.
- **No Submersion:** Never immerse the lights or battery pack in water.
- **Careful Handling:** Treat LED bulbs gently to avoid damage.
- **Bulb Replacement:** Swap out faulty bulbs using ones with matching ratings.
- **Clean Contacts:** If needed, clean battery terminals with a dry cloth to maintain function.
- **Functional Button:** Make sure the timer button stays clean and responsive.
- **Recycle Responsibly:** Follow local guidelines when disposing of old batteries.

TROUBLESHOOTING

Issue	Cause	Solution
Lights won't turn on	No batteries or dead batteries	Install fresh AA batteries
Timer not working	Incorrect press sequence	Hold for 2s until LED blinks
LEDs dim quickly	Battery running low	Replace batteries
Some LEDs not lighting	Broken wire or bulb	Check connections; replace damaged bulbs
Water damage	Exposed to heavy rain	Only use in IP44-rated sheltered areas
Overheating	Overuse or battery leakage	Remove batteries, let cool
Button unresponsive	Poor contact or corrosion	Clean battery contacts
Wire tangled	Improper storage	Wrap loosely before storage
Timer resets	Battery interruption	Reprogram timer after battery change
Blinking or flicker	Loose battery or wiring	Re-seat batteries; adjust wiring

PROS & CONS

Pros:

- Pretty warm-white star glow
- Built-in timer enhances automation
- Battery-operated for flexible placement
- Waterproof stars ideal for sheltered outdoor use
- Lightweight and easy to arrange

Cons:

- Requires regular AA battery replacements
- Limited brightness—fairy-light level only
- Timer fixed pattern, no alternative durations
- Not for wet/outdoor exposed areas
- Thin wire can be fragile with frequent handling

WARRANTY

Covers a **30-day** return period via Amazon, with additional support from Minetom for quality issues. Replacement or refund offered for defects, missing parts, or non-functionality.

FREQUENTLY ASKED QUESTIONS

How long is the Minetom 17-ft Star String Light set?

The Minetom Star-50LED light set is 17 feet long and includes 50 warm white LED star-shaped lights.

What powers the Minetom 17-ft Star String Lights?

The lights are battery powered, requiring 3 × AA batteries (not included).

Does the Minetom Star String Light have a timer function?

It has a built-in timer that keeps the lights on for 6 hours, then automatically turns them off for 18 hours.

What is the light color and brightness of these star string lights?

The lights emit a warm white glow (approximately 3000K), providing a soft

and cozy ambiance ideal for bedrooms or romantic settings.

Do the Minetom Star Lights require remote control operation?

No remote is needed. The lights operate using touch-based button control on the battery pack.

Why aren't my Minetom Star String Lights turning on?

Make sure you've inserted 3 new AA batteries correctly and securely. Also, ensure the battery contacts are clean and free of corrosion.

The timer isn't working on my Minetom Star-50LED lights. What can I do?

Press and hold the power button until it blinks once to activate the timer mode. If it still doesn't work, replace the batteries and retry.

VIDEO – PRODUCT OVERVIEW

<https://manuals.plus/wp-content/uploads/2025/07/Minetom-17-ft-Star-String-Lights-User-Manual.mp4>

References

- [User Manual](#)

📎 17-ft Star String Lights, B0CRKCYNZX, Minetom, user

📁 Minetom manual

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.