



**Contents** [ [hide](#) ]

- [1 Minetom 33-ft Crystal Globe String-Light](#)
- [2 INTRODUCTION](#)
- [3 SPECIFICATIONS](#)
- [4 WHAT'S IN THE BOX](#)
- [5 FEATURES](#)
- [6 SETUP GUIDE](#)
- [7 CARE & MAINTENANCE](#)
- [8 TROUBLESHOOTING](#)
- [9 PROS & CONS](#)
- [10 WARRANTY](#)
- [11 FREQUENTLY ASKED QUESTIONS](#)
- [12 VIDEO – PRODUCT OVERVIEW](#)
- [13 References](#)



## **Minetom 33-ft Crystal Globe String-Light**



**INTRODUCTION**

Both indoor and covered outdoor spaces can benefit from the ambient elegance provided by the Minetom 33-foot Crystal Globe String Lights, which retail for **\$27.99**. These lights, which include 100 weatherproof LED globes on a 33-foot USB-powered strand, have 16 solid colors and 7 color-changing modes. They can be controlled with a 32-key remote control (up to 10 meters). Setting a 6-hour on/eighteen-hour off daily cycle is simple thanks to the integrated timer. The globes, which are about 1 inch wide and distributed around every 4 inches along the string, are composed of sturdy plastic that resembles crystal. They are perfect for decorating patios, tents, weddings, and vacation areas, and they have an IP44 waterproof classification.

**SPECIFICATIONS**

Brand	Minetom
Model	33-ft Crystal Globe String Lights
Price	\$27.99

Length	33 ft (≈10 m)
LED Count	100 crystal globe LEDs
Globe Diameter	~1 inch
Spacing	~4 inches between globes
Colors	16 solid + 7 color-changing modes
Control	32-key remote (up to 10 m range)
Power Source	USB-powered with UL-listed adapter
Waterproof Rating	IP44 (wire & globes waterproof)
Lifespan	~20,000 hours
Wattage	5 W
Wire Material	Transparent PVC
Indoor/Outdoor Usage	Indoor and sheltered outdoor use
Weight	1.9 lb
Package Size	6.6× 4× 42.6inches
Timer	Yes (automated 6h ON / 18h OFF cycle)

## WHAT'S IN THE BOX

- 1 × 33-ft USB-powered crystal globe string lights (100 LEDs)
- 1 × UL-listed power adapter
- 1 × 32-key remote control
- 1 × User manual

## FEATURES


- **Power Source:** Runs via USB with an included UL-certified adapter.

- **LED Count & Length:** Features 100 crystal-like LED globes evenly spaced over a 33-foot string (approximately 4 inches apart).




- **Color Options:** Offers 16 single colors plus 7 dynamic multicolor modes.
- **Remote Control:** Comes with a 32-button remote for adjusting mode, color, brightness, and timer settings.

# Upgraded 32-Key Remote Control



- **Timer Function:** Automatically cycles with 6 hours on and 18 hours off.
- **Dimmability:** Allows smooth adjustment of brightness across several levels.
- **Waterproof Design:** Both the globes and wiring meet IP44 standards for splash protection.



- **Durable Construction:** Crafted from shatter-resistant, crystal-like plastic for long-lasting use.
- **Extended Lifespan:** LEDs are rated for up to 20,000 hours.
- **Wiring:** Transparent PVC cable ensures a neat installation that blends with your decor.
- **Safe Operation:** Cool-running LEDs mean safe touch even after extended use.
- **Memory Feature:** Remembers your last used settings so you can easily resume your preferred setup.
- **Remote Range:** Effective control from up to approximately 10 meters (32 feet) away.
- **Ease of Installation:** Lightweight design simplifies hanging and positioning.
- **Safety Certified:** The included adapter is UL-listed for added safety and reliability.

## SETUP GUIDE

- **Unpack:** Remove the string lights and all accessories from the original packaging.
- **Connect:** Plug the USB cable into the UL-listed adapter.
- **Power Up:** Connect the adapter to a power outlet and wait about 10 seconds for the

LEDs to come to life.

- **Remote Operation:** Use the remote control to select your desired colors, modes, and brightness levels.
- **Timer Activation:** Press the “Timer” button on the remote to start the automatic 6-hour cycle.
- **Hang:** Use clips or hooks to hang the string lights evenly.
- **Position:** Arrange the globes so they do not tangle or overlap.
- **Keep Dry:** Ensure the USB adapter remains indoors and away from moisture.
- **Adjust:** Modify settings as necessary using the remote.
- **Cancel Timer:** To disable the timer, press the “Timer” button again or simply unplug the unit.
- **Storage:** Keep the remote close by when not in use, and unplug and pack the lights in a dry environment.
- **Avoid Stress:** Prevent sharp bends or undue tension on the wire.

## CARE & MAINTENANCE

- **Safety First:** Unplug the lights and allow them to cool before cleaning.
- **Clean Gently:** Use a damp cloth to wipe down the globes, avoiding any harsh chemicals.
- **Inspect:** Regularly check both the globes and wiring for signs of damage.
- **Protect Adapter:** Keep the USB adapter and its plug dry at all times.
- **Store Properly:** Coil the string loosely when storing it to avoid tight wraps that could damage the cable.
- **Sun & Heat:** Avoid exposing the globes to direct sunlight or excessive heat.
- **Remote Care:** Replace the remote’s battery when the signal starts to weaken.
- **Seal Check:** Periodically examine the IP44 seals to ensure they remain intact.
- **Weather Caution:** Disconnect the lights during storms or heavy inclement weather.
- **Eco Disposal:** Recycle the unit responsibly at the end of its service life.
- **Remote Maintenance:** Keep the remote control clean and dry.
- **No Submersion:** Do not submerge any components in water.
- **Off-Season Storage:** Store the lights indoors when not in use for long periods.
- **Cable Management:** Ensure the wiring does not get tangled with other cables.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No lights activate	No power or faulty adapter	Check connections; test other outlet
Remote unresponsive	Dead battery or distance too far	Replace CR2025 battery; stay within ~ 10m line-of-sight
Timer not functioning	Improper remote use	Press "Timer" correctly; observe LED blinking
Flickering lights	Power fluctuation or defective mode	Use stable power or reset mode
Some LEDs dark	LED failure or wire break	Inspect wire; replace LED strand if needed
Modes not cycling	Remote issue	Replace battery; reset lights via power cycle
Plastic globes fogging	Humidity ingress	Clean globes; ensure dry use environment
Dimmer nonresponsive	Mode not set properly	Use remote brightness controls
Wire insulation damaged	Sharp bends or abrasion	Inspect and protect wire; avoid harsh installation
Discoloration / dim glow	Aging LED or residue	Clean globes; replace string if necessary

## PROS & CONS

### Pros:

- Stunning 16-color + 7-mode lighting versatility
- Comprehensive 32-key remote with timer and dimmer

- USB-powered for flexible placement
- Durable, shatterproof globes and IP44 waterproofing
- Memory function for persistent settings

#### **Cons:**

- Requires nearby USB power outlet
- Not rated for full submersion (IP44 vs IP65)
- Remote range limited by line-of-sight
- Plastic globes less premium than glass
- Remote battery may need periodic replacement

## **WARRANTY**

Minetom offers a **1-year** manufacturer support policy, along with Amazon's standard 30-day return window. Customers can request replacements or refunds for defects, non-functionality, or missing components

## **FREQUENTLY ASKED QUESTIONS**

What is the total length and LED count of the Minetom Crystal Globe String Lights?

The Minetom Crystal Globe String Lights are 33 feet long and include 100 LED bulbs, spaced approximately 4 inches apart.

What colors and lighting modes does the Minetom Crystal Globe model offer?

It features 16 solid colors and 7 multicolor lighting modes, all adjustable via remote control for a wide variety of ambiance settings.

What power source is required for these globe lights?

These lights are USB-powered, but come with a UL-listed power adapter, so you can plug them into any standard outlet using the included cord.

How big are the bulbs on the Minetom Crystal Globe String Lights?

Each crystal globe bulb is about 1 inch wide and made of durable waterproof plastic, offering a high-end glowing aesthetic.

How far can I control the lights using the remote?

The 32-key remote works within a 10-meter (approximately 33 ft) range, allowing you to adjust settings without moving.

Why aren't my Minetom Crystal Globe String Lights turning on?

Ensure the USB connection is secure, and that the power adapter is plugged into a live outlet. Test the outlet with another device.

Some colors look dimmer than others. Is that normal?

Slight brightness differences between colors can occur. If the dimness persists across multiple colors, reset the unit or ensure you're using the correct brightness setting via remote.

How do I clean or store the string lights when not in use?

Gently wipe the bulbs with a dry cloth, avoid moisture near connectors, and coil the strand loosely to prevent tangling. Store in a cool, dry place.

## **VIDEO – PRODUCT OVERVIEW**

<https://manuals.plus/wp-content/uploads/2025/07/Minetom-33-ft-Crystal-Globe-String-Light-User-Manual.mp4>

## References

- [User Manual](#)

💎 33-ft Crystal Globe String-Light, B0CCXGJ4FY, Minetom, user

📁 Minetom manual

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos

are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.