Manuals+ — User Manuals Simplified.

Minetom Y-H-Y 001 Color Changing Fairy String Lights with Remote Instruction Manual

INSTRUCTION MANUAL

Note: this IM contains important information, please read it carefully and keep it for reference in future. (Please contact us via Amazon platform for any question/problem and we will respond in 24 hours for a refund, replacement or trouble-shooting.)

Contents

PARTS LIST

String Lights powered with 3*AA batteries (Batteries not included)
Remote Control (CR2025 battery included)
1pc of IM

HOW TO USE

1. Slide off the battery case cover;
2. Insert 3*AA batteries into the battery case in correct polarity;

3. Slide on the battery case cover;
4. Remove the clear pull tag of the remote control and press ON to turn on the lights. (the remote control should point to the battery case (with receiver built-in).
5. Then you can use the remote control to select the mode you prefer. For detailed remote function, please see image below.


6. You can also turn on/off the lights or choose a lighting mode as you like by press the button of the battery case.

SAFETY WARNINGS

The device is not a toy. Not intended for children under 14 years of age. Adult setup and supervision are required. Thoroughly inspect products before every use. If the product appears worn, frayed, splintered, cracked, or broken in any manner, discontinue use and discard immediately. Do not touch with wet hands. Used batteries should be disposed properly.

Printed in China

Documents / Resources

Minetom Y-H-Y 001 Color Changing Fairy String Lights with Remote [pdf] Instruction Manual
Y-H-Y 001, Y-H-Y 001 Color Changing Fairy String Lights with Remote, Color Changing Fairy String Lights with Remote, Changing Fairy String Lights with Remote, Fairy String Lights with Remote, String Lights with Remote, Lights with Remote, Remote

References

- **User Manual**