

Mini Game Box 800 Retro FC Handheld Game Console



# Mini Game Box 800 Retro FC Handheld Game Console User Manual

[Home](#) » [Mini Game Box](#) » Mini Game Box 800 Retro FC Handheld Game Console User Manual 

## Contents

- 1 Mini Game Box 800 Retro FC Handheld Game Console
- 2 INSTALLATION
- 3 ASSESORIES
- 4 BATTERY INSTALLATION
- 5 VIDEO OUT-CONNECTING TO A TV
- 6 CARE AND MAINTENANCE
- 7 TROUBLESHOOTING
- 8 Documents / Resources
  - 8.1 References



**Mini Game Box 800 Retro FC Handheld Game Console**



## USER MANUAL


## THANK YOU

- Thanks for purchasing play vision portable. play vision portable product designed for many hours of game-playing fun.
- This product is small and portable.so you can take it anywhere!
- Please read the following contents prior to connecting and playing to ensure proper use and care.

## INSTALLATION



## ASSESORIES



## BATTERY INSTALLATION

1. Make sure the unit is turned OFF
2. Remove cover on bottom of unit.
3. Remove exhausted batteries and dispose of them properly
4. Replace battery cover


**Note:** Be sure the batteries in both the handset and console are fresh or the unit will not function properly!

## BATTERY NOTICE

1. Do not short circuit battery contacts.
2. Do not dispose of batteries in fire.
3. Remove the batteries from the unit if it will not be used for an extended period of time.

**NOTE:** Manufacturer assumes no liability whatsoever caused by leaking or corroding BATTERY.

## VIDEO OUT-CONNECTING TO A TV



## NOTE

1. Before connect to a TV, make sure that your TV and the unit are turned off.
2. Switch the channel on TV to the Audio/Video channel.

## RESET FUNCTION

Whenever press the Reset button, it will return to the selection screen. If the game crash, please press the Reset

button to restart.

## **VOLUME CONTROL FUNCTION**

Turn the Volume Control at the side of the unit to increase/decrease the volume

## **CARE AND MAINTENANCE**

1. Do not disassemble or try to repair PVP GAME play vision portable or any of its components.
2. Do not store your PVP GAME play vision portable in a humid place, on the floor or any location where it may collect dirt, dust etc.
3. Do not drop, hit or otherwise abuse PVP GAME play vision portable or its components.
4. Make sure all connections to the PVP GAME play vision portable are made carefully and inserted into the correct locations only.
5. Do not spill liquids on your PVP GAME play vision portable or its components.
6. To clean your PVP GAME play vision portable with a soft slightly damp cloth. Always allow all the components to dry completely before using again.
7. To avoid the screen from heavy pressing or being touched by hard articles. Always clean the screen with soft and dry cloth, such as the one for spectacles.
8. Keeps the kids away from cable or connecting wire, or it may circle around their neck and cause the accident once the the kids overexert the wires and make the unit drop down to floor.

## **FOLLOW THE PRECAUTIONS BELOW WHENEVER USING YOUR PVP GAME PLAY VISION PORTABLE**


- When using your play vision portable, do not sit or stand too close to the television screen, Play as far back from the screen as possible.
- Do not play if you are tired or need sleep.
- Always play in a well-lit room.
- Be sure to take a 10 to 15 minutes break at least every hour while playing.

## **TROUBLESHOOTING**

PROBLEM	SOLUTION
No picture on the LCD or TV screen	<ul style="list-style-type: none"> <li>• Have Batteries been installed correctly?</li> <li>• Is the play vision portable turned on?</li> <li>• Is the TV turned on?</li> <li>• Is the TV set to AV input?</li> <li>• Are the play vision portable and TV connected properly?</li> <li>• Check whether the battery capacity is too low.</li> </ul>
No game sound	<ul style="list-style-type: none"> <li>• Have any of the cables become loose or disconnected?</li> <li>• Is the TV volume too low. or off?</li> <li>• Check whether the battery capacity is too low.</li> </ul>
Picture is blinking or distorted	Power off the play vision portable and try again.
No power	<ul style="list-style-type: none"> <li>• Have Batteries been installed correctly?</li> <li>• Check whether the battery capacity is too low.</li> </ul>

Information contained herein is subject to change without prior notice.

## Documents / Resources

	<a href="#">Mini Game Box 800 Retro FC Handheld Game Console</a> [pdf] User Manual 800 Retro FC Handheld Game Console, 800, Retro FC Handheld Game Console, FC Handheld Game Console, Handheld Game Console, Game Console, Console
---	---

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.