

MINISO
A16 Wireless
Speaker with
Microphone



MINISO A16 Wireless Speaker with Microphone User Manual

[Home](#) » [MINISO](#) » MINISO A16 Wireless Speaker with Microphone User Manual 

Contents

- [1 MINISO A16 Wireless Speaker with Microphone](#)
- [2 Product Usage Instructions](#)
- [3 Product Parameter](#)
- [4 Product indication chart](#)
- [5 All accessories](#)
- [6 Function operation introduction](#)
- [7 Function button \(microphone\)](#)
- [8 Trouble removal](#)
- [9 FAQ](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)

MINISO

MINISO A16 Wireless Speaker with Microphone



Specifications:

- **Bluetooth version:** 5.2
- **Pairing name:** MINISO-A16
- **Charging input:** 5V 500mA
- **Battery:** 700mAh
- **Charging port:** USB-C
- **Bluetooth Sound Luan time:** About 4 hours
- **Charging time:** About 2 hours

Product Usage Instructions

Function Operation Introduction:

TWS mode:

1. Turn on two Bluetooth speakers. When the Bluetooth speaker enters the automatic pairing state, the blue indicator blinks.
2. Double-click the on/off button of any speaker. The two speakers are connected to each other. If you hear a beep, the two speakers are connected successfully. (If not, repeat steps 1 and 2.)
3. Turn on the Bluetooth function of the mobile phone, search and connect with the speaker. After the connection is successful, the two speakers can play simultaneously.

Troubleshooting:

If the signal received by the Bluetooth speaker is weak or disconnected:

- This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- If it is not used for a long time, please pick up the product and charge it once every three months to avoid battery discharge loss.

- This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.
- This equipment should be installed and operated with a minimum distance of 5mm between the radiator and your body.

Cleaning and Maintenance:

Stop using the stock before cleaning and job protection. Wipe the stock with a clean, dry cloth.

Charging Instructions:

Push a charger that uses a brand manufacturer, is certified, and has an output voltage of 5V. Please avoid using an output ink with more than 5V fast charger to avoid high-voltage charging damage to the product.

All Accessories:

Bluetooth speaker *1, USB-C charging cable *1, manual *1

Dear customer

Thank you very much for using MINISO Bluetooth speaker products, carefully read this manual before use, and correct

Operation and use, better play the superior performance of the product. MINISO Bluetooth speaker design fashion gorgeous, sound quality Pure beauty, and multi-functional integrated design, the whole series has design patents, the industry's leading electrical system exploration Technology that allows you to enjoy excellent results anytime and anywhere in-home use, strict travel, business work, for you notebook computers, digital music playback bars and other audio-visual products provide a perfect sound quality experience, take you to listen to the beauty and wonderful music, feel healthy and happy life!

Matters needing attention

1. Please use and store spare parts and accessories in the temperature range of 5°C-35°C. When the ambient temperature is too high or too low, This may cause a fault.
2. Keep the device and its accessories in a cool, ventilated place without direct sunlight.
3. Do not disassemble, impact, squeeze or put the device into the fire to avoid explosion. If the battery bulges or leakage, do not continue to use.
4. Maintain a distance of at least 15 cm between the eye and the implanted medical device (such as a pacemaker, etc.) when using this device
5. Due to the characteristics of Bluetooth technology, the strength of the signal is related to the specific use environment, if there are more wireless nearby The signal is heavy, or there is strong electromagnetic interference, the signal received by the Bluetooth speaker is weak, or even disconnected.
6. If it is not used for a long time, please pick up the product and charge it once every three months to avoid battery discharge loss.
7. Stop using the stock before cleaning and job protection. Wipe the stock with a clean, dry cloth.
8. Push a charger that uses a brand manufacturer, is certified, and has an output voltage of 5V. Please avoid

Do not use the output ink more than 5V fast charger, so as to avoid high voltage charging damage to the product!


Product Parameter

- **Bluetooth version:**5.2
- **Charging port:** USB-C Bluetooth

- **pairing name:** MINISO-A16
- **Sound Luan time;** About 4 hours
- **Charging input:** 5V 500mA
- **Charging time:** about 2 hours
- **Battery:** 700mAh

Product indication chart

1. **Volume down/Previous:** Press the volume short and press the previous track long
2. **Switch/play pause key:** long press power on/off: short press play/pause; Double click disconnect Bluetooth
3. **Volume add/Next:** Short press volume add; Hold down the track
4. **M Mode key:** Short press to switch TF card /BT mode
5. **Headphone hole:** an external headphone cable with a diameter of 3.5mm
6. **TF card:** Insert TF card to play audio files inside
7. **Charging interface:** Insert the charging cable to charge the device
8. **Indicator light:** the blue light is on for 2 seconds and then blinks; After the connection is successful, the blue light is on: when charging, the red light is on; When fully charged, the red light goes off



All accessories

- Bluetooth speaker *1,
- USB-C charging cable *1,
- manual *1

Function operation introduction

Function↵	↵
Turn On↵	Press the Power button for 2 seconds↵
Turn Off↵	Press the Power button for 2 seconds↵
Charge indicator↵	When charging, the red light is on, and the full light is off↵
BT connector↵	Turn on the Bluetooth function of the user's mobile phone (or other Bluetooth devices), and search or scan, at this time the mobile phone will search for all nearby Bluetooth devices, click the name of the searched machine :MINISO-A10 successfully paired and connected, the machine indicator is steady on, indicating that the pairing and connection are successful!↵
volume +↵	Press the Volume plus button to increase the sound↵
volume -↵	Press the volume down button to reduce the sound↵
Previous song↵	Long press the volume down button. Previous↵
Next song↵	Press and hold the volume button and move on↵
pause↵	Short press on/pause↵
TF card↵	TF card can be inserted to play audio files on the card.↵

TWS mode


1. Turn on two Bluetooth speakers. When the Bluetooth speaker enters the automatic pairing state, the blue indicator blinks.
2. Double-click the on/off button of any speaker. The two speakers are connected to each other. If you hear a beep, the two speakers are connected successfully. (If not, repeat steps 1 and 2.)
3. turn on the Bluetooth function of the mobile phone, search, and connect the speaker, after the connection is successful, the two speakers can play simultaneously.

Note: The Bluetooth speaker mode has a memory function, and it will be automatically couched when it is turned on again. If you need to disconnect the TWS mode, double-click the switch button again to disconnect the TWS connection.

Function button (microphone)

1. **On/Off key:** Long press on/off, short press play/pause
2. **Volume add:** short press volume add, long press the next song;
3. **Volume reduction:** short press volume reduction, long press the previous song;
4. **M mode key:** short press brief adjustment – class adjustment – Reverberation adjustment: long press brief on/brief off

5. **Microphone key:** Short press the microphone key to enter the sound effect key can be switched at will (mode 1-mode 5), ① shout mode ② male to female ③ Female to male ④ Warcraft sound mode ⑤ doll sound mode; Press and hold the voice on/Voice off;
6. **Indicator light:** when waiting for connection, the blue light is on, and the red light flashes quickly (the microphone and the speaker are not connected, the microphone cannot switch the sound effect; After the connection is successful, the blue light is steady on: the red light is on when charging, and the red light is off when fully charged;
7. **Charging interface:** Insert the charging cable to charge the device



Trouble removal

1. The Bluetooth speaker cannot be paired with the hand lattice
A: Please check whether the speaker is in pairing mode, and check whether the mobile phone Bluetooth search function is turned on; Check the Bluetooth menu on your device and delete/cancel the speaker, reconnecting the speaker according to the instructions.
2. The Bluetooth speaker won't start
A: Please check the battery level of the speaker and try to recharge it.
3. Bluetooth speakers can replace the battery
A: No, the speaker uses a non-removable polymer carp battery.
4. Whether it can be used at a high volume for a long time
A: To improve the service life of Bluetooth speakers, it is not recommended to use high volume for a long time.
5. The Bluetooth speaker is disconnected from the phone at 10 meters
A: Since Bluetooth is a wireless technology, it is very sensitive to the object asked by the headset and the

connected device, please check Check for metal or other objects that affect the connection within the connection range.

6. No sound is heard after the speaker is connected to a computer or mobile phone

A: Please check whether the computer output channel is set as a Bluetooth audio device and whether the computer's Bluetooth supports A2DP protocol and check the volume of the computer/mobile phone.

7. After the Bluetooth speaker is connected to the mobile phone, can I use the speaker to control the app on the handset

A: The software Settings of device applications may be different so that the functions of individual applications are not supported by the speaker Control.

FCC Warning

Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement:

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance 5mm between the radiator and your body.

FAQ

Q: How long does it take to charge the product?

A: The product takes about 2 hours to fully charge.


Q: How long is the Bluetooth sound playtime?

A: The Bluetooth sound playtime is about 4 hours.

Q: How do I know if the two Bluetooth speakers are successfully connected in TWS mode?

A: When the two speakers are successfully connected in TWS mode, you will hear a beep after double-clicking the on/off button of any speaker.

Documents / Resources

	MINISO A16 Wireless Speaker with Microphone [pdf] User Manual A16-MIC, 2ANVRA16-MIC, 2ANVRA16MIC, A16 Wireless Speaker with Microphone, A16, Wireless Speaker with Microphone, Speaker with Microphone, Microphone, Speaker
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.