



MINISO E22004 Foldable Wireless Headset with Stereo Sound User Manual

[Home](#) » [MINISO](#) » MINISO E22004 Foldable Wireless Headset with Stereo Sound User Manual 

MINISO


E22004 Foldable Wireless Headset with Stereo Sound User Manual

FOLDABLE WIRELESS HEADSET WITH STEREO SOUND
PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT AND KEEP IT PROPERLY

Contents

- [1 Product Parts](#)
- [2 Product Parameters](#)
- [3 Functions](#)
- [4 Cautions](#)
- [5 Troubleshooting](#)
- [6 FCC Warning](#)
- [7 ISED Warning](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

Product Parts



1. Volume +
2. Power Button
3. Volume –
4. MIC
5. LED
6. AUX C>Type-C Charging Port

Product Parameters

BT Version	V5.1	Frequency Range	20Hz-20KHz
BT Pairing Name	MINISO-E22004	Sensitivity	102±3
Function	Media player, phone call.	Charging Port	TYPE-C
Input	DC 5V	Transmission Distance	10M
Battery Capacity	200mAh	Charging Time	2.5h
Music Playback Time	22h	Talk Time	22h
Standby time	100h	Impedance	32Ω

Functions

Function	Instruction
Turn On	The long press power button for 3 seconds till the blue light turns on
Turn Off	Long press the power button for 3 seconds till red light flashes
Pairing Mode	Red and blue lights flash alternately, the headset enters connection status
Previous Track! Lower Volume	Short press “–” button to go to the previous track, long press “-” to lower volume, blue light flashes once every 5 seconds
Next Track! Raise Volume	Short press the “+” button to go to the next track, long press the “+” to raise the volume, and blue light flashes once every 5 seconds
Play	Press the power button, blue light flashes once every 5 seconds
Pause	With the press power button, blue light flashes once every 5 seconds
Answer Call	When the phone rings, press the power button, blue light flashes once every 5 seconds
Hang Up Call	When you finish a phone call, press the power button, blue light flashes once every 5 seconds
Cancel Call	When you are calling someone, press the power button, blue light flashes once every 5 seconds
Reject Call	When the phone rings, long press the power button, blue light flashes once every 5 seconds
AUX Port	You can listen to audio from external devices by plugging in the audio cable

Cautions

1. Reasonable control of the volume and time of usage is required to avoid hearing damage.
2. For your safety, do not use it in potentially hazardous conditions.
3. Do not listen to music, call up, or answer the phone while driving to avoid danger caused by distraction.
4. Keep it out of reach of children to avoid danger caused by improper use.
5. Do not throw to avoid damage caused by dropping.
6. Do not store or use it under -20°C or above 45°C to avoid shortening the lifespan of earphones and batteries.
7. Do not modify, disassemble or repair the product.
8. Irreplaceable battery. It should be disposed of according to local rules & regulations or be recycled by a professional institute. Do not throw away or toss into the fire.
9. When not in use for a long time, charge the earphones once every 3 months to extend their lifespan.
10. Avoid contact with water and other liquids to prevent them from penetrating into the product.

Troubleshooting

Can the battery of the wireless earphones be replaced?

Answer: No. The lithium polymer battery in the earphones is irreplaceable.

Can I operate the Apps on my phone through the earphones after connecting the wireless earphones to the phone?

Answer: Some apps may not support being operated through earphones due to their settings.

1. Fail to pair the wireless earphones with your cellphone. Solution: Check if the earphones are in pairing mode and whether the phone BT function is on. Check the list on your phone, remove the earphones from the list, and follow the instructions in the user manual to pair the earphones with your phone again.
2. Cannot turn on the wireless earphones.
Solution: Check the battery to see if it is low.
3. The wireless earphones got disconnected from the phone within 10 meters.
Solution: BT is wireless so it is very sensitive to objects between the earphones and the connected device. Check if there are any metal or other objects that may affect the connection within the effective distance.
4. Cannot hear audio playing when the earphones are connected to the computer or phone.
Solution: Check whether the computer's audio output is already connected to the wireless device and whether the Bluetooth in the computer supports the A2DP protocol. Make sure the volume is up on your phone or computer.

FCC Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet the general RF exposure requirement. The device can be used in portable exposure conditions without restriction.

ISED Warning

This device contains license-exempt transmitters)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The device has been evaluated to meet the general RF exposure requirements. The device can be used in portable exposure conditions without restriction.



UK
CA C € RoHS




FC



www.miniso.com

Documents / Resources

	<p>MINISO E22004 Foldable Wireless Headset with Stereo Sound [pdf] User Manual E22004, 2A3ZO-E22004, 2A3ZOE22004, E22004 Foldable Wireless Headset with Stereo Sound, Foldable Wireless Headset with Stereo Sound, Foldable Wireless Headset, Wireless Headset, Headset</p>
---	---