


MINISO K11 Bluetooth Headset



MINISO K11 Bluetooth Headset User Manual

[Home](#) » [MINISO](#) » MINISO K11 Bluetooth Headset User Manual 

Contents

- [1 MINISO K11 Bluetooth Headset](#)
- [2 Product Structure](#)
- [3 Accessories](#)
- [4 Parameters](#)
- [5 Functions](#)
- [6 Troubleshooting](#)
- [7 FCC Warning](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



MINISO K11 Bluetooth Headset



PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT AND KEEP IT PROPERLY

Product Structure

1. Earphone Touch Button
2. Sound Output Hole
3. Earphone Charging Contact
4. Charging Case LED Light
5. Type-C Port



Accessories

Device*1, User Manual*1, Type-C Charging Cable*1, Medium Ear Tips*2, Big Ear Tips*2

Parameters

| | | | |
|------------|------------|---------------------------|--------|
| BT Version | 5.3 | Charging Port | Type-C |
| BT Name | MINISO-K11 | Earphone Battery Capacity | 25mAh |

| | | | |
|-----------------------|-----|--------------------------------|--------|
| Music Playback Time | 4h | Charging Time | 1.5h |
| Transmission Distance | 10m | Charging Case Battery Capacity | 250mAh |

Functions

| Function | Charging Case Instructions |
|----------------------------------|--|
| Turn On | Take the earphones out of charging case |
| Turn Off | Put the earphones into charging case |
| Pairing Mode | For first time connection, open the upper lid charging case, the earphones enter into pairing mode automatically. Search for MINISO-K11 and choose to connect, there is a prompt after the earphones are connected successfully. The next time you turn on, the earphones will connect automatically with the last device. |
| Manual Pairing | If the automatic is not successful (single earphone with no sound or the earphones are disconnected), you can do the manual connection. 1. Erase the Bluetooth connection record of the phone with earphones, and turn off the phone's Bluetooth. 2. Take the earphones out after putting them into the charging case for 10 seconds, and wait for 5 seconds. 3. Turn on the phone's Bluetooth, and search for MINISO-K11 to connect. |
| Earphones Instructions | |
| Play/Pause | Press left/right touch button twice |
| Next Track | Press right touch button three times |
| Previous Track | Press left touch button three times |
| Answer/End Call | Press left/right touch button twice |
| Reject Call | Press left/right touch button for 2 seconds |
| Activate Phone's Voice Assistant | Press left touch button for 2 seconds |
| Turn On Manually | / |
| Turn Off Manually | / |
| Indicator Light | 1, When charging case charging: white light blinks 2, When charging case fully charged: white light constantly on |

Cautions

1. Reasonable control of the volume and time of usage is required to avoid hearing damage.
2. For your safety, do not use in potentially hazardous conditions,
3. Do not listen to music, call up, or answer the phone while driving to avoid danger caused by distraction.
4. Keep out of reach of children to avoid danger caused by improper use.
5. Do not throw to avoid damage caused by dropping.
6. Do not store it under 0°C or above 40°C to avoid shortening the lifespan of earphones and battery.
7. Do not modify, disassemble or repair the product.
8. Irreplaceable battery. It should be disposed of according to local rules & regulations or be recycled by a professional institute. Do not throw it away or toss it into the fire.
9. When not in use for a long time, charge the earphones once every 3 months to extend their service life.

Troubleshooting

1. Wireless earphones fail to be paired with the phone.

Solution: Check if the earphones are in pairing mode, and whether the phone has BT function on, Check the list on your phone, remove the earphones from the list, and follow the instructions of the user manual to pair the earphones with your phone again.

2. Cannot turn on the wireless earphones.

Solution: Check the battery to see if it is low.

3. Can the battery of the wireless earphones be replaced?

Answer: No. The lithium polymer battery in the earphones is irreplaceable.

4. The wireless earphones got disconnected from the phone within 10 meters,

Solution: BT is wireless so it is very sensitive to objects between the earphones and the connected device. Check if there are any metal or other objects that may affect the connection within the effective distance.

5. Cannot hear audio playing when the earphones are connected to the computer or phone.

Solution: Check whether the computer's audio output is already connected to the wireless device and whether the Bluetooth in the computer supports A2DP protocol. Make sure the volume is up on your phone or computer.

6. Can I operate the Apps on my phone through the earphones after connecting the wireless earphones to the phone?

Answer: Some apps may not support being operated through the earphones due to their settings.

FCC Warning

This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications, However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement


This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

IC Warning

This device complies with Industry Canada license-exempt RSS standard(s), Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Documents / Resources

| | |
|---|--|
|  | MINISO K11 Bluetooth Headset [pdf] User Manual K11, K11 Bluetooth Headset, Bluetooth Headset, Headset |
|---|--|

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.