



MINISO LT-BT2219 Retro Wireless Speaker User Manual

[Home](#) » [MINISO](#) » MINISO LT-BT2219 Retro Wireless Speaker User Manual 

Contents

- [1 MINISO LT-BT2219 Retro Wireless Speaker](#)
- [2 PRODUCT PARAMETERS](#)
- [3 PRODUCT OVERVIEW](#)
- [4 FUNCTION](#)
- [5 ACCESSORIES](#)
- [6 TROUBLESHOOTING](#)
- [7 FCC](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

MINISO

MINISO LT-BT2219 Retro Wireless Speaker



DEAR CESTOMER

Thank you for using Miniso Wireless Speaker. Please read this manual carefully before use. Using it properly for best product performance. MINISO Wireless Speaker has stylish appearance, true-to-life sound and multiple functions. The whole series have the patent of appearance design. The system adopting the industry-leading technology enables you to enjoy the excellent sound effects anytime at home, outdoors, during a trip or during work. It provides perfect experience when you play music on your laptops, digital music players and other audio-visual players, leading you to a better life with beautiful music!


CAUTIONS

1. Store and use it at room temperature
2. Do not expose it to rain or moisture.
3. Do not throw the product to avoid damage caused by dropping
4. Do not disassemble, modify or repair the product yourself
5. This product is equipped with an irreplaceable built-in lithium battery.
6. To prevent its performance from being interfered, keep it away from strong magnetic objects.
7. If you are not going to use it for a long time, charge the speaker once every 3 months to extend the lifespan of battery.

PRODUCT PARAMETERS

BLUETOOTH	V5.1	BLUETOOTH PAIRING NAME	MINISO-LT-BT2219
CHARGING INPUT	5V---1A	BATTERY	3.7Vlithium battery 500mAh
CHARGING PORT	MICRO USB	TRANSMISSION DISTANCE	Around 10m
MUSIC PLAYBACK TIME	Around 3H	CHARGING TIME	Around 2.5H

PRODUCT OVERVIEW



- 1. Power Button
- 2. LED Indicator Light
- 3. Charging Port

FUNCTION

Function	Instructions
Play/ Pause	Short press power button
Next Track	Double press power button
Pre ious Track	Press power button three times
Low Battery Alert	A prompt when the battery is low
Pairing Timeout Shutdown	If there is no connec tion after 10 minutes from turning on, the product will turn off automa tically
Charging Indicator Light	The red light is constantly on when getting charged, and turns off after fully charg ed

ACCESSORIES

- Speaker
- Charging Cable
- User Manual

TROUBLESHOOTING

1. The wireless speaker is unable to be paired with the cell phone. Solution: Confirm if the wireless speaker is in pairing mode, and if the Bluetooth on your phone is turned on. Then delete the product in the list, pair it with your phone again according to the User Manual.
2. The wireless speaker cannot to be turned on. Solution: Confirm the battery level. Charge the speaker if it is needed
3. Can the battery of the wireless speaker be replaced?
Solution: No, this is lithium polymer battery, which is irreplaceable.
4. Can I use the wireless speaker at a high volume for a long time? Solution: To extend the life span of the wireless speaker, it is not recommended to play it at a high volume for a long time.
5. The link between the wireless speaker and the cell phone has been disconnected within 10 meters.
Solution: Bluetooth is wireless so that it is very sensitive to objects between the speaker and the connected device. Check if there are any metal or other objects that may affect connection within the effective distance.
6. Cannot hear audio playing when the speaker is connected to the computer or phone.
Solution: Check whether the computer's audio output is already connected to wireless device and whether the Bluetooth in the computer supports A2DP protocol. Make sure the volume is up on your phone or compute.
7. Can I operate the Apps of my phone through the speaker after pairing the wireless speaker with the phone?
Answer: Some apps may not support being operated through the speaker due to their setting

FCC

WARNING This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions: This device may not cause harmful interference, and This device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures
Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

The device has been evaluated to meet general RF exposure requirements without restriction
the device can be used in portable

Documents / Resources



[MINISO LT-BT2219 Retro Wireless Speaker](#) [pdf] User Manual
LT-BT2219, LTBT2219, 2BABOLT-BT2219, 2BABOLTB2219, LT-BT2219 Retro Wireless Speaker, Retro Wireless Speaker, Wireless Speaker, Speaker