

MINISO SMK-646M8AG
Wireless Keyboard
Mouse Set



MINISO SMK-646M8AG Wireless Keyboard Mouse Set User Manual

[Home](#) » [MINISO](#) » MINISO SMK-646M8AG Wireless Keyboard Mouse Set User Manual 

Contents

- [1 MINISO SMK-646M8AG Wireless Keyboard Mouse Set](#)
- [2 Specifications](#)
- [3 Usage](#)
- [4 Accessories](#)
- [5 Troubleshooting](#)
- [6 FCC Warning](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

MINISO

MINISO SMK-646M8AG Wireless Keyboard Mouse Set



Specifications

- Keyboard Dimensions: 39.1cm*13.5*4.1cm
- Mouse Dimensions: 6.7cm*10.5cm*3.8cm
- Keyboard's Battery: AAA'?
- Mouse's Battery: M*1
- Keyboard's Working Currant: 1 SmA
- Mouse's Working Current: 8mA
- Keyboard's Working Voltage: 3V
- Mouse's Working Voltage: 1.5V

Compatible Operating Systems: Windows 2000, Windows XP, Windows ME, Windows VISTA, Windows 7/8/10/11

Usage

1. Take the USB receiver from the bottom of the mouse, plug into USB port of the computer. Open battery cover of the mouse, then put 1 AA. battery.
2. Open battery cover of the keyboard, then put 2 AAA batteries. Wait for the indicator light to turn on, after connection is successful, you can start to use.
3. Shortcut Combination: By combining FN + F1 to F12 to switch rapidly between computer, multimedia, volume adjustment and other functions.

Accessories

1. Keyboard
2. Mouse
3. USB Receiver
4. User Manual

Cautions

1. Do not use it in a damp place.
2. Avoid hitting or dropping the product to prevent damage or malfunction.
3. Do not disassemble or repair the product by yourself.
4. To prevent leakage and damage, remove the battery from the product if you won't be using it for a long time.
5. Make sure that the USB port is in good contact to avoid affecting the normal use of the product.
6. It is recommended to replace the battery regularly to avoid low power, which will affect the product performance.

Troubleshooting

If the product is not working property, try the following:

1. Check if the USB head plugged property into the port.
2. Check the settings on the computer.
3. Make sure the product or receiver is connected directly to the computer, and not through external devices such

as a hub or extension cord.

4. Restart the computer.

WEEE Warning

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

FCC Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without resbiction.

IC WARNING

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Documents / Resources



[MINISO SMK-646M8AG Wireless Keyboard Mouse Set](#) [pdf] User Manual
WOX-SM-M8AG, WOXSM8AG, SM M8AG, SMK-646M8AG Wireless Keyboard Mouse Set, S
MK-646M8AG, Wireless Keyboard Mouse Set, Keyboard Mouse Set, Mouse Set, Set

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.