



# minisopuru DS808 Displaylink Triple Display Docking Station Instruction Manual

[Home](#) » [minisopuru](#) » minisopuru DS808 Displaylink Triple Display Docking Station Instruction Manual 



Minisopuru Displaylink Docking Station Driver  
DS808 Displaylink Docking Station:

## Contents

- 1 **PLEASE NOTE:**
- 2 Detailed steps to install displaylink driver
- 3 Documents / Resources
  - 3.1 References

## PLEASE NOTE:

Before using the docking station, be sure to install DisplayLink software on your device to ensure proper media display functionality

If the displaylink driver is not installed, the display 2 and display 3 area interfaces of the dock will not work

For each system driver download, please click the corresponding link

**Windows:** <https://synaptics.com/products/displaylink-graphics/downloads/windows>

**Corporate Installers for Windows**

<https://synaptics.com/products/displaylink-graphics/downloads/corporate>

**Macos**

<https://synaptics.com/products/displaylink-graphics/downloads/macOS>

**Android**

<https://synaptics.com/products/displaylink-graphics/downloads/android>

**Ubuntu**

<https://synaptics.com/products/displaylink-graphics/downloads/ubuntu>


**Chrome**

The DisplayLink software driver is inboxed in ChromeOS from build R51 (released in June 2016). All Chromebooks using ChromeOS build R51 or later will work with DisplayLink docks and adapters without

additional driver installation.

**NOTE:**


**Linux/Unix not supported.**




The detailed steps are as follows: Take Mac OS as an example (download and install other drivers in the same way)

**Download the displaylink driver detailed steps:**


1. Search website: <https://synaptics.com>, click product—DisplayLink Graphics or Click on the top right – download




2. Then select the system you need to download the driver



3. click to download, then click Accept









## Detailed steps to install displaylink driver


1. Open the downloaded file:




2. Follow the prompts to complete the installation




3. After completing the installation according to the prompts, click done





4. When Drive is running, an icon like this will appear at the top



When the icon disappears due to reasons such as restarting, updating the system, etc., click on the LaunchPad and click the app to activate it .



Documents / Resources

	<a href="#">minisopuru DS808 Displaylink Triple Display Docking Station</a> [pdf] Instruction Manual DS808 Displaylink Triple Display Docking Station, DS808, Displaylink Triple Display Docking Station, Display Docking Station, Docking Station, Station
	<a href="#">minisopuru DS808 Displaylink Triple Display Docking Station</a> [pdf] Installation Guide DS808, B0CGXQPYGF, B0BJ28RQ2N, B0B98YM1VM, DS808 Displaylink Triple Display Docking Station, Triple Display Docking Station, Display Docking Station, Docking Station

References

-  [macOS Catalina 10.15: Screen Recording permission – DisplayLink Support](#)
-  [Troubleshooting: Ubuntu – DisplayLink Support](#)
-  [Troubleshooting: Windows – DisplayLink Support](#)
-  [Tips and Tricks – DisplayLink Support](#)
-  [Troubleshooting: General – DisplayLink Support](#)
-  [Troubleshooting: Android – DisplayLink Support](#)
-  [Corporate Deployment – DisplayLink Support](#)
-  [Engineering Exceptional Experiences | Synaptics](#)