



# Mircom DSPL-420-16TZDS Main Display Module Owner's Manual

[Home](#) » [Mircom](#) » Mircom DSPL-420-16TZDS Main Display Module Owner's Manual 

## Contents

- [1 Mircom DSPL-420-16TZDS Main Display Module](#)
- [2 Description](#)
- [3 Features](#)
- [4 Power Consumption](#)
- [5 Ordering Information](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)



## Mircom DSPL-420-16TZDS Main Display Module



## Description

The DSPL-420-16TZDS is a main display / control interface for a main panel in a Flex-Net, MMX, or a classic FX-2000. It is designed to mount in any standard display window cut out found on the doors in the Flex-Net, MMX, and FX-2000 series. This display is functionally equivalent to the Flex-Net and classic FX2000 main display, but more compact.

The DSPL-420-16TZDS has a 4-line, 20-character back-lit LCD display with 4 cursors buttons and an Enter button to navigate the LCD menu items, as well as Menu, Cancel and Information buttons. The display also features 16

configurable bi-coloured LEDs, 4 Queue Buttons with LED Indicators, and 8 control buttons, each with its own LED Indicator. The display also includes LEDs to indicate AC On, Ground Fault and CPU Fault.

Features


- 16 Configurable Bi-coloured LEDs
- 4 line by 20-character LCD display
- Backlit display
- User-friendly Menu
- Common Control buttons with selector switches and LEDs
- Four Status Queues: Alarm, Supervisory, Trouble and Monitor
- LEDs to indicate AC On, Ground Fault and CPU Fault

Power Consumption

Normal Operation Voltage	Amps
Stand by	10 mA
Alarm	46 mA

**NOT TO BE USED FOR INSTALLATION PURPOSES.**  
THIS INFORMATION IS FOR MARKETING PURPOSES ONLY AND NOT INTENDED TO DESCRIBE THE PRODUCTS TECHNICALLY.

Figure 1: Indicator and Control locations on the DSPL-420-16TZDS



## Ordering Information

Model	Description
DSPL-420-16ZDS	16 Zones 4 Line by 20 Character Backlit LCD Display

### THIS INFORMATION IS FOR MARKETING PURPOSES ONLY AND NOT INTENDED TO DESCRIBE THE PRODUCTS TECHNICALLY.

For complete and accurate technical information relating to performance, installation, testing and certification, refer to technical literature. This document contains intellectual property of Mircom. The information is subject to change by Mircom without notice. Mircom does not represent or warrant correctness or completeness.

#### Canada

25 Interchange Way Vaughan, Ontario L4K 5W3 Telephone: (905) 660-4655 Fax: (905) 660-4113

[www.mircom.com](http://www.mircom.com)


#### U.S.A.

4575 Witmer Industrial Estates Niagara Falls, NY 14305

Toll Free: (888) 660-4655 Fax Toll Free: (888) 660-4113

[firealarmresources.com](http://firealarmresources.com)

## Documents / Resources

	<p><a href="#">Mircom DSPL-420-16TZDS Main Display Module</a> [pdf] Owner's Manual DSPL-420-16TZDS Main Display Module, DSPL-420-16TZDS, Main Display Module, Display Module, Module</p>
---	--

## References

-  [Fire Alarm Resources | Download fire alarm documents](#)
-  [Mircom - Smart Buildings. Smarter Solutions.](#)