

# Mircom LT-6773 TX3 Cloud Gateway Instruction Manual

## Contents

- [1 Mircom LT-6773 TX3 Cloud Gateway](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Installation](#)
- [5 Activation](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)

## Mircom LT-6773 TX3 Cloud Gateway

### Specifications

- **Product:** TX3 Cloud Gateway
- **Connectivity:** Ethernet
- **Compatibility:** TX3 system
- **Serial Number Format:** XXXX-XXXX-XXXX (combination of letters and numbers)

### Product Usage Instructions

#### Installation

##### Items Required

- Ethernet cable
- Power adapter and cable

#### Preparation

1. Connect the Ethernet cable to LAN port 1 of the unit, ensuring it is connected to the internet.
2. Attach the power adapter and cable to the unit.
3. Note: HDMI/DP/USB3.0 ports are for internal use only.

#### Activation

This process activates the TX3 Cloud Gateway to work with your TX3 system.

1. Contact Mircom sales department to purchase a TX3-Vision account and job site license.
2. Log in to TX3 Vision website ( <https://tx3vision.mircom.com/> ).
3. Select the licensed job site.
4. Click on the Gateway Panel configuration.

5. Click on Command > Activate Device.
6. Enter the serial number found on the gateway unit.
7. Restart the device by turning it off and then on.
8. Wait for successful activation.
9. Click Finished.

## FAQ

- **Q: Where can I find the serial number of the TX3 Cloud Gateway?**

A: The serial number can be found on the gateway unit itself, formatted as XXXX-XXXX-XXXX.

- **Q: Can I use HDMI/DP/USB3.0 ports for customer use?**

A: No, these ports are intended for internal use only and not for customer use.

## TX3 Cloud Gateway Installation

### Manual

The TX3 Cloud Gateway connects a TX3 system to the TX3 Vision Configurator as shown below.

## Installation

### 1. Items Required

1. TX3 Vision Cloud Gateway unit (TX3-CLOUD-GATEWAY)
2. Power Adapter (included with TX3 Vision Cloud Gateway unit)
3. Ethernet cable

### 2. Preparation

1. Connect the Ethernet cable to LAN port 1 of the unit, ensuring it is connected to the internet.
2. Attach the power adapter and cable to the unit.

**Note:** HDMI/DP/USB3.0 are intended for internal use only, not for customer use.

## Activation

This process activates the TX3 Cloud Gateway, enabling it to work with your TX3 system.


1. Contact the Mircom sales department to purchase a TX3-Vision account and job site license.
2. Log in to the TX3 Vision website ( <https://tx3vision.mircom.com/> ).
3. Once logged in, you will see the job site for which you have purchased the license.
4. Select the licensed job site.
5. Click on the icon.
6. From the drop-down menu click on Configuration.
7. Click the arrow on the right of the Gateway Panel.
8. Click on Command > Activate Device.
9. Enter the serial number of the gateway, which can be found on the gateway unit.

The purpose of the serial number is to identify and activate the device; it is in the format XXXX-XXXX-XXXX and consists of both letters and numbers.

10. Click on Next.
11. Restart the device by turning off its power and then turning it back on by pressing the power button located on the front of the device. Wait for the device to be activated successfully.
12. Click Finished.

---

## Documents / Resources

	<p><a href="#">Mircom LT-6773 TX3 Cloud Gateway</a> [pdf] Instruction Manual LT-6773 TX3 Cloud Gateway, LT-6773, TX3 Cloud Gateway, Cloud Gateway, Gateway</p>
---	--

## References

- [▶ TX3 Vision](#)
- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.