




ML DESIGN ML-1460 TV Lowboard Instruction Manual

[Home](#) » [ML DESIGN](#) » ML DESIGN ML-1460 TV Lowboard Instruction Manual 

Contents

- [1 ML DESIGN ML-1460 TV Lowboard](#)
- [2 Product Specifications](#)
- [3 Product Overview](#)
- [4 Assembly](#)
- [5 Installation](#)
- [6 FAQs](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)



ML DESIGN ML-1460 TV Lowboard






















Product Specifications

- Model: ML-1460
- Material: Wood
- Dimensions: 24x18x34 inches

- Weight: 62 lbs


Product Overview



					
A 24x	B 24x	C 34x	D 4x	E 6x	F 6x
					
G 1x	H 4x	I 4x	J 25x	K 18x	L 24x
					
CL 1x	CR 2x	DL 1x	DR 1x	N 12x	M 2x


Assembly




1




Teile / Części	Nr. / Liczba	Stk. / ilość
	A	6
	N	6
	CL	1
	CR	1



2




Teile / Części	Nr. / Liczba	Stk. / ilość
	A	1
	B	1
	C	2



3




Teile / Części	Nr. / Liczba	Stk. / ilość
	B	6
	C	4




4




Teile / Części	Nr. / Liczba	Stk. / ilość
	A	2
	B	2

5




Teile / Części	Nr. / Liczba	Stk. / ilość
	A	10
	B	6
	C	4

6




Teile / Części	Nr. / Liczba	Stk. / ilość
	B	4
	C	4




Teile / Części	Nr. / Liczba	Stk. / ilość
	C	8
	J	8

8




Teile / Części	Nr. / Liczba	Stk. / ilość
	C	12
	J	12

9




Teile / Części	Nr. / Liczba	Stk. / ilość
	K	16




10




Teile / Części	Nr. / Liczba	Stk. / ilość
	E	6
	F	6
	H	4
	I	4
	K	2


11




Teile / Części	Nr. / Liczba	Stk. / ilość
	A	5
	B	5
	J	5



Teile / Części	Nr. / Liczba	Stk. / ilość
	N	6
	DL	1
	DR	1



Teile / Części	Nr. / Liczba	Stk. / ilość
	D	4
	L	24



Teile / Część	Nr. / Liczba	Stk. / ilość
	M	2

Installation

1. Choose a suitable location for the TV low board.
2. Make sure the surface is level before placing the assembled unit.
3. Attach the wall anchors or anti-tip mechanism provided for stability.
4. Carefully place your TV on the lowboard ensuring it is centered and secure.

FAQs

Q: How do I clean the TV lowboard?

A: Wipe down the surface with down the surface with a soft cloth dampened with water or avoid harsh chemicals that may damage the finish.


Q: Can I customize the color of the TV lowboard?

A: While the product comes in a standard color, you may be able to paint or stain it to your desired color following proper preparation and techniques.

Q: What is the weight capacity of the TV lowboard?

A: The TV lowboard has been tested to support TVs up to 50 inches in size and a maximum weight of 100 lbs.

Documents / Resources

	<p>ML DESIGN ML-1460 TV Lowboard [pdf] Instruction Manual ML-1460 TV Lowboard, ML-1460, TV Lowboard, Lowboard</p>
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.