

## Mobvoi TicNote Voice Recorder Instructions




### Contents [ [hide](#) ]

- [1 Mobvoi TicNote](#)
- [2 Start Recording](#)
- [3 Recording File Sync](#)
- [4 Trouble Shooting](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)

## Mobvoi TicNote


1. Recording Mode Switch
2. Device Status Display

### 3. Power Button




### 4. Charging Port


### 5. Microphone



### 6. Magnetic Case



### 7. Magnetic Ring



## 8. Magnetic Charging Cable



## 9. Waiting to bind the Mobvoi TicNote App



## 10. OTA Updating



## 11. Wi-Fi is turned on



## 12. Earphone Mode



## 13. Charging Status




14. Battery Level 20%




15. Speaker Mode



16. Battery Level = 100%



### Device Status Display



### Quick Guide


- Search for “Mobvoi TicNote” in the App Store or Google Play to download the app.
- Create your Mobvoi TicNote account.



- Tap (0.5s) the power button to turn on your TicNote.
- The device displays a pending binding status, indicating that your TicNote is ready




- Open the “Mobvoi TicNote” app and follow the on-screen instructions to complete the binding process.
- Once binding is successful, the device will display the Bluetooth icon shown above.



## Start Recording

### Speaker Mode



### Recording Mode

- Speaker Mode
  - When the switch is toggled down, it is in Speaker Mode.
  - In this mode, you can hold TicNote in your hand or place it on a desk to start recording.
- Earphone Mode
  - When the switch is toggled down, it is in Speaker Mode.
  - In this mode, TicNote can capture the vibration of the phone, providing accurate records.
  - **Note:** To use this mode, make sure your phone is in regular call mode (not on a bluetooth call), and use the included magnetic case to attach TicNote to the back of your phone

# Recording File Sync

## File Sync Mode

- Bluetooth Mode
  - Bluetooth mode is the default file sync method for TicNote. Once TicNote is connected to the app, it will automatically begin the transfer.
- Wi-Fi Fast Transfer
  - For large recording files, TicNote offers the ability to sync files to the app via Wi-Fi fast transfer. When fast transfer is enabled, TicNote will activate a hotspot, and once the app successfully connects to the hotspot, TicNote will automatically sync the files to the app.

## Trouble Shooting

**Reset TicNote without losing data or changing settings, when it becomes unresponsive or freezes.**

- Press and hold the power button for 15 seconds, and the binding icon will reappear.

**Please scan to access more detailed instructions of Mobvoi TicNote.**



<https://ticnote.com/userguide>



@Mobvoi TicNote



@Mobvoi



@mobvoi



@Mobvoi\_Official



@mobvoiofficial


## Customer Support

[www.mobvoi.com](http://www.mobvoi.com)

[support@mobvoi.com](mailto:support@mobvoi.com)



## Documents / Resources

	<a href="#">Mobvoi TicNote Voice Recorder [pdf]</a> Instructions TicNote Voice Recorder, TicNote, Voice Recorder, Recorder
---	---

## References

- [User Manual](#)

📁 Mobvoi, Recorder, TicNote, TicNote Voice Recorder, Voice

📁 Mobvoi Recorder

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.