



MoKo HB188 Universal Foldable Bluetooth Keyboard User Manual

[Home](#) » [MOKO](#) » MoKo HB188 Universal Foldable Bluetooth Keyboard User Manual 

Contents


- [1 MoKo HB188 Universal Foldable Bluetooth Keyboard](#)
- [2 INDICATOR LIGHTS DESCRIPTION](#)
- [3 SPECIFICATIONS](#)
- [4 SAFETY INSTRUCTIONS](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)



MoKo HB188 Universal Foldable Bluetooth Keyboard



INDICATOR LIGHTS DESCRIPTION



1. Caps Lock Indicator: The green light will flash. Bluetooth Status Indicator: Blue light will flash after pressing the FN +O keys together.
2. Power Indicator: Green light will be on for 5 seconds.
Charging Indicator: Red light will turn on when the keyboard is charging and turns off once fully charged.
Battery Power Display Indicator: Press "Fn+m!" , flashing Green. (Every blinking represents 25% battery. That is to say, flashing once means the remaining battery is 25%; flashing twice, the remaining battery is 50%; flashing three times, 75%; flashing four times, 100%.) Low Battery Indicator: Red light will flash when it is time to recharge.
3. Micro Charging Port: Used for charging the keyboard.

SPECIFICATIONS

Bluetooth Specification	Bluetooth 3.0
Unfolded Dimensions	328.06×101.99×5.8mm
Foldable Dimensions	158x101x13mm
Operating Range	Up to 10 meters
Net Weight	176G
Modulation System	GFSK
Stand-by Time	30 days
Charge Time	< 2 hours
Uninterrupted Work Time	40 hours
Lithium Battery Capacity	110 mAh
Lithium Battery Life	3 years
Key Life	3 million clicks
Front side of keyboard	ABS
Back side of keyboard	PU case

KEYS AND FUNCTIONS

For the Android or iOS tablets. Press Fn key and hot key together to activate action. For the Windows tablets. Press the “Fn” + “Shift” and hot key together to activate action.

	FN on Android	FNonWin	FN+Shift on Win	FN on iOS
0	Home	ESC	Web Browser	Home
Q	Search	F1	Search	Search
	Select all	F2	Select all	Select all

	FN on Android	FNonIM-1	FN+Shift on Win	FN on iOS
IJ	Copy	F3	Copy	Copy
li)	Paste	F4	Paste	Paste
<i>i</i>	Cut	F5	Cut	Cut
l, _	Previous track	F6	Previous track	Previous track
►	Play/pause	F7	Play/pause	Play/pause
► ►	Next track	F8	Next track	Next track
l(]-	Volume down	F9	Volume down	Volume down
l(]+	Volume up	F10	Volume up	Volume up
lE-	N/A	N/A	N/A	Keyboard Display
:=,	Back	N/A	N/A	N/A

Hint: Press FN and Delete keys together means delete the letters after the cursor.

SPECIAL NOTE

1. This keyboard doesn't support the Windows Mobile.
2. For Android users: The Caps Lock indicator may not light up, but will still function normally.

TURNING KEYBOARD ON AND OFF

1. To turn on, simply unfold the keyboard.

2. To turn off, fold the keyboard.

HOW TO PAIR THE KEYBOARD WITH IPAD

Step 1. To turn on • simply unfold the keyboard.

Step 2. Press the “FN +@” keys together to enter pairing mode. The blue Bluetooth indicator light will begin to blink.

Step 3. On the iPad, select: Settings – Bluetooth- On.

Step 4. The iPad will display “Foldable Keyboard” as an available device.

Step 5. Select “Foldable Keyboard” on the iPad. click on it, the keyboard will now be paired to iPad and the Bluetooth indicator will turn off.

Step 6. Press “FN + E / iOS” keys on the keyboard switch to the iOS operating system.

HOW TO PAIR THE KEYBOARD WITH PHONE OR TABLETS

Step 1. To turn on, simply unfold the keyboard.

Step 2. Press the “FN +@” keys together to enter pairing mode. The blue Bluetooth indicator light will begin to blink.

Step 3. On your device, go to “Settings”. Activate its Bluetooth function and search for the keyboard device.

Step 4. The device will display “Foldable Keyboard” as an available device.

Step 5. Select “Foldable Keyboard” on your device, click on it, the keyboard will now be paired to your device and the Bluetooth indicator will turn off.

Step 6. Press “FN + Q / Android .W / Windows,E / iOS” keys on the keyboard according to the operating system you are using.

PAIRING WITH DESKTOP

Step 1. Connect the Bluetooth dongle to the USB port on your computer. The Bluetooth driver will be installed automatically. (Bluetooth dongle not included)

Step 2. To turn on, simply unfold the keyboard.

Step 3. Press the “FN +~” keys together to enter pairing mode. The blue Bluetooth indicator light will begin to blink.

Step 4. Click the Bluetooth icon positioned on the right corner of your desktop, and start searching for the keyboard device. Add the “Foldable Keyboard” as a Bluetooth device after it is found.

Step 5. Once the “Foldable Keyboard” has successfully connected to your device, the Bluetooth indicator will turn off.

Step 6. Press “FN +W Windows” keys on the keyboard switch to the Windows operating system.

SPECIAL NOTE:

1. Only one device can be actively paired at one time.
2. For other Bluetooth enabled device, please verify the Bluetooth Standard&compatibility before attempting to connect to the keyboard.
3. After pairing for the first time, your device will connect to the keyboard automatically when opening the keyboard.
4. In case of connection failure, delete the pairing record from your device, and try the above procedures again.

POWER SAVING MODE

The keyboard will enter sleep mode after being idle for 30 minutes. To active it, press any key and wait for 3 seconds.

HOW TO CHARGE

1. Use the included USB cable for charging. Connect one end to a USB charger. and the other to the keyboard.
2. In charging, the power indicator will turn red. Generally, it takes approximately 2 hours for a full charge.
(charger is not included)

CAUTION

When not in use for a prolonged period of time, it is recommended that you turn off the keyboard to conserve the battery life.

TROUBLESHOOTING


If you are unable to connect the keyboard to your tablet, please try the following:

1. Starting with a full charge on both devices ensures that process won't be interrupted by a low battery.
2. Make sure your tablet's Bluetooth is on.
3. Make sure that the keyboard is within the effective operation distance of 33 feet (10 M).

SAFETY INSTRUCTIONS

1. Keep the keyboard away from sharp objects that could damage it.
2. Do not put heavy objects on the keyboard.
3. Do not stretch, twist or apply force to the keyboard.
4. To clean the keyboard, gently wipe it by using a moist cotton cloth.
5. Make sure the keyboard is turned off before cleaning. Do not use liquid cleanser.
6. Please do not spill coffee, tea or other liquids on the keyboard.

Documents / Resources

	MoKo HB188 Universal Foldable Bluetooth Keyboard [pdf] User Manual HB188 Universal Foldable Bluetooth Keyboard, HB188, Universal Foldable Bluetooth Keyboard , Foldable Bluetooth Keyboard, Bluetooth Keyboard, Keyboard
---	---

References

- [User Manual](#)