

# mongoose LT604 GPS Battery Powered Tracker User Manual

Home » MONGOOSE » mongoose LT604 GPS Battery Powered Tracker User Manual



#### **Contents**

- 1 mongoose LT604 GPS Battery Powered
- **Tracker**
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 Included
- **5 BATTERY & CHARGER**
- **6 PLACEMENT & SECURITY OF THE TRACKER**
- **7 BLUE & GREEN LEDs**
- **8 ACTIVATION & SET-UP 'WIZARD'**
- 9 MAIN MENU & TEXT COMMAND LIST
- **10 ONLINE WEBSITE**
- 11 Contact
- 12 Documents / Resources
  - 12.1 References



mongoose LT604 GPS Battery Powered Tracker



## **Product Information**

# **Specifications**

• Model: LT604

• Power Source: Battery

• Connectivity: 4G

• Water Resistance: Water resistant (not waterproof)

# **Product Usage Instructions**

# **Battery and Charger**

- 1. DO NOT LEAVE CHARGING UNATTENDED.
- 2. Only use the charger lead supplied.
- 3. The mobile APP displays current charge capacity.
- 4. Charging time varies according to the battery state. Allow a minimum of 12 hours.
- 5. **NOTE:** Do not use the USB lead connected to other equipment such as a computer to charge charging may not occur or be considerably extended.

#### SIM Card Installation and On/Off Switch

1. Lift the rubber cover.

- 2. Insert the SIM card and turn on.
- 3. Close the cover.
- 4. Test SIM card voice, text, and data functions in a phone for activation before use in GPS tracker.

#### **LED Indicators**

The LEDs flash when searching for a signal and light solid once it has mobile and GPS signals. After a short while, the LED's will turn off to preserve battery life. The tracker must be outdoors or very close to a window to receive GPS signals. Observe the LED's.

- BLUE & GREEN LEDs:
  - Unlit: Reception is off (No power or unit asleep).
  - · Lit solid: Working normally.
- · Red LED:
  - Charger connected and internal battery charging.

# **Activation & Set-Up Wizard**

- 1. Download the mobile app from the App Store for Apple iOS or Play Store for Android.
- 2. Search for "4G MONGOOSE GPS".
- 3. **Note:** For this tracker to function accurately, ensure your mobile phone GPS location services are switched on.
- 4. Open the app and follow the activation wizard to complete the set-up process.

## **APN Configuration**

- 1. Ensure the SIM card provider's APN settings are correctly configured for accurate location tracking.
- Refer to the provided APN examples for Australia and New Zealand or contact your SIM card provider for the correct APN details.

## The Activation & Set-Up Wizard

The wizard must be completed to unlock all the tracker and app features. To access the wizard:

- 1. Open the app.
- 2. The wizard will guide you through the process.
- 3. Enter the default password (default is 222444).

## The Logon Screen

• When the activation wizard has been completed, the next time you open the app, a logon screen will appear.

**Note:** Keep logon details confidential to prevent unauthorizeduse and access.

#### **Main Menu & Text Command List**

- Real Time (Live Tracking): Opens the map to show the current or last reported location. Keep the map open to see tracker's live progress.
- History: Replay on-screen today, yesterday, or any 24-hour period travel history.

## Included

- 1 x GPS battery powered tracker
- 1 x Charger lead
- Free download mobile tracking APP ( Android and Apple IOS)
- · Free tracking website

This product requires a mobile SIM card (not included). Data only SIM cards are not compatible.
This product is water resistant, not waterproof.

# **BATTERY & CHARGER**

- DO NOT LEAVE CHARGING UNATTENDED.
- Only use the charger lead supplied.
- The mobile APP displays current charge capacity.
- · Charging time varies according to the battery state.
- Allow a minimum of 12 hours.

**NOTE:** Do not use the USB lead connected to other equipment such as a computer to charge – charging may not occur or be considerably extended.

## **PLACEMENT & SECURITY OF THE TRACKER**

- The tracker has built-in magnets to assist with attaching the tracker to a vehicle, trailer, equipment or asset.

  The tracker must have direct 'line of sight' to the GPS satellites. It must not be placed under or surrounded by metal or electronic equipment which can block GPS and mobile reception.
- If GPS reception is obscured, tracking data may not be collected or be inaccurate.
- We strongly recommend experimentation in different placements before deciding on a long term location.
- Ideally, the tracker should be concealed for its security.
- Remember, you will need access to the tracker for recharging purposes. \*DO NOT use the LT604 permanently connected to power charging.

#### SIM CARD INSTALL and ON/OFF SWITCH







On/Off

Lift the rubber cover Insert the SIM car & turn on

Close the cover

TEST SIMCARD voice, text, data function in phone for activation before use in GPS TRACKER

The LEDs flash when searching for signal and light solid once it has mobile and GPS signals After a short while, the LED's will turn off to preserve battery life. The tracker must be outdoors or very close to a window to receive GPS signals. Observe the LED's.

## **BLUE & GREEN LEDs**

- Unit: Reception is off (No power or unit asleep)
- Lit solid: Working normal
- Flashing once every 3 sec's: Searching for signal (Green Mobile) (Blue GPS)
- Red LED: Charger connected and internal battery charging

## **ACTIVATION & SET-UP 'WIZARD'**

• DOWNLOAD THE MOBILE APP





- Go to App Store for Apple IOS
- Go to Play Store for Android
- Search for



– 4G MONGOOSE GPS

Note: For this tracker to function accurately, ensure your mobile phone GPS location services are switched on.

#### **TESTING VIA THE MOBILE APP**

Using the mobile APP, check for correct operation without using the wizard.

- Download and open the APP on your mobile phone
- Press 'SKIP' at the bottom of the 'wizard' screen to go to LOGON screen
- Enter the trackers ID (serial number) and default 222444 password
- Map shows the current location (tracker is a Green triangle Blue is your phone)
- If location is not correct, press 'MENU'
- · Select 'Set APN' and enter SIM cards APN
- Turn Ignition on for vehicle so it sends location then allow a few minutes and check location which should now be correct
- Please ask tracker owner to download the APP and complete the Activation 'Wizard' detailed in this manual to UNLOCK all FEATURES and complete set up.

# Here are some APN examples

Australia		New Zealand		
Telstra	telstra.internet or telstra.wap	Vodafone	vodafone.net.nz	
Vodafone	live.vodafone.com	Spark	internet	
Optus	connect or yes internet or connect me	2 Degrees		
Aldi	mdata.net.au	Kogan		live.vodafone.co m
Boost	internet	The Warehouse	warehouse	
Moose	yes internet	Skinny	- wapaccess.co.nz	
AmaySim	internet	Slingshot		

Contact your SIM card provider if your provider is not listed above or to verify the correct APN or search internet for updates APN details.

## THE ACTIVATION & SET-UP WIZARD

# The wizard must be completed to unlock all the tracker & APP features

Open the APP, the wizard guides you through the process.

- ID (serial number) of the tracker (on tracker & carton)
- Phone number of the SIM card used in the tracker
- Your mobile phone number ('master user') \*
- Trackers SIM card 'APN' ...... See next page \*
- Choose your own unique 6-digit 'logon' password (default is 222444)

<sup>\*</sup> With some input data, the wizard opens your mobile phones text messages displaying the text code being sent. Just press send. A reply text message will be received confirming the action.

# **DUAL PASSWORDS – Double Data Protection & Security**



- There are 2 separate unique programmable passwords.
  - Password 1: LOGON
- The logon password is to allow entry to the mobile APP and online website. This password is chosen by you when completing the 'activation wizard'.
  - · Default is 222444
  - Password 2: TEXT COMMANDS
- This password is for text commands sent from the APP or your mobile phone. This password is chosen by you by selecting 'text password' in the 'command list'.
  - · Default is 123456

# THE LOGON SCREEN


When the activation wizard has been completed (unlocks all the trackers & APP features), the next time you open the APP this logon screen appears.



- For users of a single tracker, enter the trackers ID (serial number) and your password. (ID is found on the tracker and carton)
- For users of multiple trackers who have been issued a Mongoose GPS account, enter the account name and password.
- Tick the 'remember me' box for quick and easy future logons without having to enter tracker or account details.
- When you press 'LOGON', you will be taken to the 'real time' tracking map to show a vehicles current/last reported location. For account holders, the map will show a vehicle from the last logon.

**Note:** Keep logon details confidential to prevent unauthorized use and access.

# **MAIN MENU & TEXT COMMAND LIST**



# Real Time (Live Tracking)

• Opens the map to show the current or last reported location. Keep the map open to see trackers live progress.

# History

• Replay on-screen today, yesterday or any 24 hour period travel history.

# **Text Commands**

• Select how you wish the tracker to operate

# Messages

• See what messages have been sent to you

# **Setup Wizard**



- Geo-Fence 'Account' User Menu
  - Set a permitted radius of travel from a defined spot. Multiple geo-fences can be set. Each time the vehicle exits or enters, alerts the APP and website
- · Tracker Info'
  - Details such as tracker name, trackers SIM number, master users number, vehicle registration number etc.



- APN may need to be changed if you change SIM card provider.
- · Account User Info'
  - Details of your company and contacts.

# 'Account' menu also includes;

- Home: Takes you to the main menu
- List: Select a tracker to be viewed
- Monitor: View all your trackers at the same time
- Message: Text messages sent to you from tracker.

# TRACKER TEXT COMMAND LIST

Command	Function
Arm / Disarm	Turns text alerts on or off. When ON, text alerts are sent for ignition on, shock (vibration) sensor or GPS position change.
Get Location Data	Provides latitude/longitude as a text message – click on blue text to open you r phones Google maps to show location
Tracking Frequency	Sets how often the tracker updates its location when moving.

Time Zone	Set hours ahead of GMT your tracker is located. Adjust for daylight saving when applicable.
Vibration Sensitivity	Set vibration (shock) level 1~9. 1 is most sensitive. See full manual for explan ation and on/off command
Speed Alert	Sets a max'permitted speed. Speeding sends a text alert
Move Alert	Sets a radius of permitted movement. Beyond this limit sends a text alert
Master User Number	The main users mobile phone number
Authorised Number	2 other permitted users
Text Command Password	Choose your own 6-digit number (default 123456).  This does not change your logon password
Geo-Fence	A permitted radius of travel. alerts are sent to APP and website when exiting or entering a geo-fenced area
Factory Reset	Resets settings to factory default

Commands are sent from the APP to the tracker as a password protected text messages from your mobile phone. The APP opens your phones text messages showing the text code being sent to the tracker....... Just press send. A reply text will be received confirming the action.

# **ONLINE WEBSITE**



Go to: www.mongoosegps4g.com

To logon to the website, select either IMEI (serial number) or USER NAME (Account), then use the same logon details as the mobile APP.

## **NOTES**

- This GPS tracking product may not function correctly if it cannot 'see' the GPS satellites such as undercover, in parking buildings, surrounded by tall buildings, heavy overcast weather, etc.
- For this tracker to function correctly and accurately, ensure your mobile phone GPS location services are switched on.
- The APP and website are owned & operated by a 3rd party and are free to use by purchasers of Mongoose GPS tracker products. Mongoose is not liable if access becomes unavailable.
- Be aware that use of this product may infringe the rights or invade the privacy of others.
- We are not responsible for the non-operation of this product should the mobile service providers of the GPS and mobile signals become unavailable for whatever reason.
- We are not responsible for the operation of your mobile device or the compatibility with this GPS tracking device.
- Keep the unit dry. Clean with dry cloth. Do not clean with chemicals or detergent, etc.
- Do not disassemble, tamper or attempt repairs. Do not paint or apply metal foil stickers.
- No internal serviceable parts. Tampering, abuse and misuse will void warranties.

Please download the full owners' manual as it contains detailed operating instructions and explanations as well as a greater range of operation commands <a href="https://www.mongoose.com.au">www.mongoose.com.au</a> or <a href=

#### Contact

# Australia

Email: <u>sales@mongoose.com.au</u>

- New Zealand
  - Email: sales@mongoose.co.nz
  - GPS tracking website: www.mongoosegps4g.com

## **Documents / Resources**



mongoose LT604 GPS Battery Powered Tracker [pdf] User Manual

LT604 GPS Battery Powered Tracker, LT604, GPS Battery Powered Tracker, Battery Powered Tracker, Powered Tracker, Tracker

# References

- O Home
- O Mobile made for you. One NZ.
- Mongoose New Zealand Automotive Technologies
- Mongoose Australia Automotive Technologies Home Page
- <u>omongoosegps4g.com</u>
- User Manual

Manuals+,