




MONGOOSE MCK741H 7 Wireless Monitor and Camera User Manual

[Home](#) » [MONGOOSE](#) » MONGOOSE MCK741H 7 Wireless Monitor and Camera User Manual 

MONGOOSE MCK741H 7 Wireless Monitor and Camera User Manual



Contents

- [1 Product technical parameters](#)
- [2 Product introduction](#)
- [3 Operation and usage](#)
- [4 Connection](#)
- [5 Installation instructions](#)
- [6 Accessories](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

Product technical parameters

Monitor

1. **Screen:** 7 inch 16:9 digital panel
2. **Resolution:** 1024*RGB*600
3. **Wireless video input:** 1-4CH wireless video input and recording
4. Using digital wireless encryption technology to code connection, with strong anti-interference ability
5. 2.4G wireless transmission distance: 200M in open area
6. **Power supply:** DC12V~24V
7. **Power consumption:** 3W
8. **Speaker:** built-in
9. **Memory card:** 16-128G
10. **Trigger:** 4CH
11. **Working temperature:** -20 C-70 C
12. **Storage temperature:** -30 C-85 C

Camera

1. **Image sensor:** CMOS 1/2.7"
2. **Pixel:** 1920*1080 pixels
3. **Operation frequency range:** 2400-2483.5MHZ
4. **Transmission distance:** 200M in open area
5. **System:** PAL/NTSC automatically
6. **Spread spectrum mode:** FHSS(Adaptive frequency hopping)
7. **Audio:** with
8. **Transmission bandwidth:** 8MHZ BER<1E-3
9. **Working temperature:** -20 C-70 C, RH85% MAX
10. **Storage temperature:** -30 C-85 C, RH95% MAX
11. **SNR:** 46.5dB
12. **Transmission sensitivity:** -89dBm
13. **Shell material:** black aluminium alloy
14. **Waterproof level:** IP69K

Product introduction

Introductions of monitor panel



1. 2.4G antenna
2. Display screen
3. Metal LOGO plate
4. **Menu setting:** Left selection; Long press to choose 1/2/4 display mode
5. **MENU:** Open or Menu setting: Right selection exit the menu
6. **Menu setting:** Right selection
7. Power Key
8. **Flip set:** Turn Up, Down, Left and Right
9. **Reverse Line:** On/Off
10. Confirm, Long press to Pairing button

Camera introduction




1. 2.4G antenna
2. U-sharp bracket and sun shade
3. Night vision infrared light
4. Night vision sensor


Operation and usage

Press the **MENU** key on the panel to enter into the main Menu setting interface.






Camera pairing

Open the main menu interface, select camera setting and pairing camera, then press the button "  "on the front panel to confirm and enter into cameras pairing or cancel pairing, press the **MENU** key to exit after finished. As following picture.





System setting

Open the main menu and select system settings, press the button  "to confirm. Then press"  "or" "to enter into the calendar, date stamp, default setting and card format setting. Press MENU key to exit. As following picture.





Record setting

Open the main MENU interface and select record settings, then press the button  "to confirm. Press"  "or" "to enter into the record mode and record time setting, and press the MENU key to exit. As following picture.



Video playback


Open the main MENU interface to select playback, then press the button  "to confirm and enter into the file list to select the required playback file, press the button  "to confirm playback, and press MENU key to exit. As following

picture.



Connection

Power extension cableX2



1. Monitor
2. Camera
3. Trigger wire (cam1)/Trigger wire(cam2)/Trigger wire(cam3)/Trigger wire(cam4)
4. **Red Electronic Wire:** DC 12-24V power input
5. **Black Electronic Wire:** GND

Installation instructions


1. Please make sure that the monitor is paired with the camera and the image is displayed well before installing the camera.
2. After installing the camera, please check the display image is normal or not, if blue screen or jam occurs, check whether the antenna is in good connection or mount long antenna outside where receiving good signal such as the roof.
3. The monitor should be installed in a position that does not affect the driving field.
4. Monitors and cameras should be mounted secured to avoid falling while driving.
5. As you need to check the monitor while driving, please pay attention to safety.

Accessories

1. Power cable 2PCS
2. User manual 1 PCS
3. Hex wrench 4MM 1PCS 3MM1PCS
4. 2.4G antenna 2PCS
5. 3M extension cable for 2.4G antenn
6. 2.4G wireless camera 1 PCS



Documents / Resources



[MONGOOSE MCK741H 7 Wireless Monitor and Camera](#) [pdf] User Manual
MCK741H 7 Wireless Monitor and Camera, MCK741H, 7 Wireless Monitor and Camera, Wirele
ss Monitor and Camera, Monitor and Camera, Camera