



MONITOR AUDIO WM-BOX In Wall Back Box User Guide

[Home](#) » [MONITOR AUDIO](#) » MONITOR AUDIO WM-BOX In Wall Back Box User Guide 



AUDIO WM-BOX In Wall Back Box User Guide

Contents

- [1 WM-BOX In Wall Back Box](#)
- [2 Unboxing](#)
- [3 Attach brackets](#)
- [4 Fix to struts](#)
- [5 Create holes for wiring](#)
- [6 Insert wiring](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

WM-BOX In Wall Back Box



WM-BOX Quick Start Guide


? [monitoraudio.com/support](https://www.monitoraudio.com/support)




<https://www.monitoraudio.com/en/support/>

	External Dimensions (H x W x D)	Weight
WM-BOX	854 x 284 x 160 mm 335/8 x 11 3/16 x 6 5/16 "	5.9 kg 3 lb 0 oz


Unboxing




Attach brackets



Fix to struts



Create holes for wiring



Insert wiring



Monitor Audio Ltd, 24 Brook Road, Rayleigh,
Essex, UK, SS6 7XJ | +44 1268 740 580

info@monitoraudio.com

monitoraudio.com

© Monitor Audio | WM-BOX | Version 1 2023

Documents / Resources

	MONITOR AUDIO WM-BOX In Wall Back Box [pdf] User Guide WM-BOX In Wall Back Box, WM-BOX, In Wall Back Box, Wall Back Box, Back Box, Box
--	--

References

- [Monitor Audio | Hi-Fi, Cinema & Architectural Speakers](#)
- [Support | Help | Monitor Audio](#)
- [User Manual](#)