




MONOKEI 201 Standard Keyboard User Guide

[Home](#) » [MONOKEI](#) » MONOKEI 201 Standard Keyboard User Guide 

Contents

- [1 MONOKEI 201 Standard Keyboard](#)
- [2 What's Included](#)
- [3 Connecting Your Keyboard](#)
- [4 Status Indicators](#)
- [5 Windows Hotkeys](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



MONOKEI 201 Standard Keyboard



What's Included


These accessories come with every Standard keyboard.



USB-C cable



Alternate & accent
keycaps



Switch puller



Keycap puller

Connecting Your Keyboard

Turning your device on


Turn on the Standard by flipping the switch located on the bottom of the keyboard.

Wired


Connect the Standard using the provided USB-C cable to your device.

Wireless


Press + P to initiate the pairing process. LED 1 will display a blinking white indicator during the pairing process.



Turning your device on



Wired



Wireless

Status Indicators

Charging your keyboard



Power On
Indicator blinks for 1s.



Charging
Indicator turns off when
charging is complete.



Low Battery
Indicator blinks 5 times.

Connecting your Keyboard



Broadcasting Mode
Indicator blinks in 0.5s intervals
for 3 minutes.



Device Paired
Indicator blinks for 1s.

Using your Keyboard



Caps Lock





Toggle Win / macOS Layout
Indicator blinks for 1s.






















Switching Devices
Indicator blinks for 1s.


Windows Hotkeys



Press  with any of these keys:

- | | |
|--|---|
|  <i>Decrease Display brightness</i> |  <i>Print Screen</i> |
|  <i>Increase Display brightness</i> |  <i>Toggle Win Key (hold for 2s)</i> |
|  <i>Swap Ctrl / Caps Lock</i> |  <i>Reset Device (hold for 10s)</i> |
|  <i>Previous Track</i> |  <i>Switch to macOS Layout (hold for 2s)</i> |
|  <i>Play and Pause</i> |  <i>Initiate Pairing</i> |
|  <i>Next Track</i> |  <i>Switch to Device 1 (hold for 0.5s)</i> |
|  <i>Volume Mute</i> |  <i>Switch to Device 2 (hold for 0.5s)</i> |
|  <i>Volume Down</i> |  <i>Switch to Device 3 (hold for 0.5s)</i> |
|  <i>Volume Up</i> |  <i>Switch to Device 4 (hold for 0.5s)</i> |
| |  <i>Switch to Device 5 (hold for 0.5s)</i> |

Documents / Resources

	<p>MONOKEI 201 Standard Keyboard [pdf] User Guide 201, 2A7O3201, Standard Keyboard, 201 Standard Keyboard</p>
---	---