

Monotremp MT538 Book Light User Guide

Home » Monotremp » Monotremp MT538 Book Light User Guide 🖺

Contents

- 1 Monotremp MT538 Book Light
- **2 INTRODUCTION**
- **3 SPECIFICATIONS**
- **4 FEATURES**
- **5 SETUP GUIDE**
- **6 CARE & MAINTENANCE**
- **7 TROUBLESHOOTING**
- 8 PROS & CONS
- **9 WARRANTY**
- 10 FREQUENTLY ASKED

QUESTIONS

11 References

Monotremp

Monotremp MT538 Book Light



INTRODUCTION

For those who enjoy reading before bed, the Monotremp MT538 Book Light is a small, rechargeable reading aid. This book lamp, which was introduced in 2024 and is made in China, lets customers personalize their reading experience with three brightness settings and three color temperatures. The MT538 is perfect for books, e-books, and tablets because of its lightweight design (1.3 oz) and flexible metal gooseneck, which guarantee easy positioning and a firm grasp. Its USB-rechargeable feature allows you to power it up in just 1.5 hours, and its long-lasting battery lasts up to 80 hours on a single charge. In addition to providing a firm grip, the clip-on design's soft, non-slip sponge guards against book page damage. The MT538 is a great option for readers looking for a portable, practical, and aesthetically pleasing light source for reading at night because it is reasonably priced at \$7.99.

SPECIFICATIONS

Product Name	Monotremp MT538 Book Light	
Price	\$7.99	
Base Material	Metal	
Product Dimensions	2.7"D x 1.3"W x 7.5"H	
Item Weight	37 grams (1.3 oz)	
Lamp Type	Reading Light	
Light Source Type	LED	
Shade Color	Black	
Brightness & Modes	3 Brightness Levels × 3 Color Temperatures	
Battery Type	1 Lithium-lon battery (included)	
Battery Life	4 – 80 hours depending on brightness setting	
Charging Time	1.5 hours (Micro USB)	
Clip Opening	1.2 inches (padded with soft sponge)	
Gooseneck	Flexible, metal for durability	
Connectivity Technology	USB	
Controller Type	Push Button	
Included Components	Book Light, USB Charging Cable, User Manual	
Is Waterproof	No	
Country of Origin	China	
Item Model Number	MT538	

FEATURES

• Three Brightness Settings: Three levels of brightness to accommodate various reading situations.

9 LIGHTING MODES






- Long Battery Life: Runs up to 80 hours on a single charge, depending on brightness settings.
- Fast Charging: Fully recharges in just 1.5 hours using the provided micro USB connector.



• Lightweight Design: Weighs only 1.3 oz, making it easy to clip onto books without adding bulk.



• Flexible Gooseneck: 360-degree adjustable metal gooseneck for precise light direction.



- Sturdy Metal Construction: Durable metal gooseneck with a lightweight plastic lamp head and clip.
- Wide Clamp Opening: Opens up to 1.2 inches, fitting books, tablets, e-readers, and thin surfaces.
- Soft Padded Clip: Non-slip sponge padding protects book pages from damage.
- Eye Comfort: LED light source provides uniform, flicker-free illumination.
- Travel-Friendly & Compact: Foldable design makes it easy to store and transport.
- USB Rechargeable: No need for disposable batteries; includes a USB charging cable.
- Private Reading Mode: Lower brightness allows late-night reading without disturbing others.
- Energy Efficient: LED technology provides bright light with minimal power consumption.
- Push-Button Control: Single button adjusts brightness and color temperature.
- Versatile Use: Ideal for reading, traveling, office work, and as a nightlight.

SETUP GUIDE

- **Unpack the Light:** Ensure all components, including the USB charging cable and instruction manual, are included.
- Charge Before Using: Fully charge the light in approximately 1.5 hours using the USB cable.
- Turn On the Light: Press the button once to power on.

- Adjust Brightness: Press the button multiple times to cycle through brightness levels.
- Alternate Color Temperature: Long-press the button to switch between warm, neutral, and cool lighting.
- Attach with Clip: Open the 1.2-inch clamp and fasten it to a book, table, or e-reader.
- Adjust Light Position: Use the flexible gooseneck to direct the light where needed.
- Recharge as Needed: If the light dims, recharge using a USB cable.
- Use as a Nightlight: Set to a low brightness and place on a bedside table.
- Avoid Overcharging: Unplug once fully charged to extend battery life.
- Use with an E-Reader: Clip onto a Kindle, iPad, or tablet for reading in low light.
- Steer Clear of Direct Eye Exposure: Avoid shining the light directly into your eyes.
- Fold for Storage: The flexible gooseneck allows compact storage.
- Use While Traveling: Carry in your bag for use in trains, planes, and hotel rooms.
- Turn Off After Use: Press the button to conserve battery life.

CARE & MAINTENANCE

- Frequent Charging: Charge at least once a month if not in regular use.
- Use a Soft Cloth to Clean: Wipe the lamp head and gooseneck with a dry or slightly damp cloth.
- Avoid Water Exposure: This book light is not waterproof.
- Avoid Overbending the Gooseneck: Excessive bending may weaken the metal structure.
- Store in a Cool, Dry Place: Keep away from heat and moisture.
- Maintain a Clean USB Port: Dust or debris can interfere with charging efficiency.
- Use Suggested Chargers: Use only a 5V USB charger to prevent damage.
- Prevent Battery Drain: Recharge before the battery is fully depleted.
- Check for Loose Connections: Ensure the USB port and battery connections are secure if flickering occurs.
- Handle the Clip Carefully: Avoid excessive force when opening the clip.
- Avoid Dropping the Light: Plastic components may break upon impact.
- Turn Off When Not in Use: Prevents accidental activation and extends battery life.
- Keep Out of Children's Reach: Small parts may pose a choking hazard.
- Avoid Extreme Cold: Low temperatures can affect battery performance.
- Replace Battery if Needed: Purchase a new battery from the manufacturer if necessary.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Light not turning on	Battery is drained	Recharge using the included USB cable.
Dim light output	Low brightness setting	Adjust brightness levels.
Light flickering	Loose connection or low bat tery	Ensure the USB cable is properly connected or re charge.
Won't clip onto book properly	Clip too small for book thick ness	Use with thinner books or adjust the placement.
Light doesn't stay in position	Weak gooseneck positionin	Bend the metal gooseneck firmly for stability.
Not charging	Faulty USB cable or port	Try a different USB port or cable.
Overheating issue	Extended use at high bright ness	Reduce brightness or let it cool down.
Short battery life	Battery not fully charged	Charge fully before use.
Color temperature not chan ging	Button not responding	Press the mode button firmly or reset.
Light won't turn off automati cally	No auto-timer feature	Manually turn off using the power button.

PROS & CONS

Pros:

- 1. Customizable brightness and color temperature for a comfortable reading experience.
- 2. Ultra-lightweight (1.3 oz) and foldable design for easy travel.
- 3. Long-lasting battery life of up to 80 hours per charge.
- 4. Flexible metal gooseneck for precise lighting angles.
- 5. Soft, non-slip clip prevents damage to book pages and e-books.

Cons:

- 1. Not waterproof, limiting outdoor use.
- 2. Clip opens only 1.2 inches, which may not fit thicker books.
- 3. Only one LED light source, limiting brightness range.
- 4. Requires a USB cable for charging, not wireless.
- 5. No auto-dimming or timer function.

WARRANTY

The **Monotremp MT538 Book Light** comes with a **1-year manufacturer's warranty** covering defects in materials and craftsmanship. If the product malfunctions within the warranty period, Monotremp offers a replacement or refund. Accidental damage, misuse, and battery wear are not covered under warranty.

FREQUENTLY ASKED QUESTIONS

What are the available brightness levels of the Monotremp MT538 Book Light?

The Monotremp MT538 features 3 brightness levels that you can adjust to suit your reading needs.

What color temperature options does the Monotremp MT538 offer?

This book light provides 3 color temperatures: warm, natural, and cool light.

How long does the battery last on a full charge?

Depending on brightness settings, the Monotremp MT538 Book Light lasts between 4 to 80 hours on a full charge.

How long does it take to fully charge the Monotremp MT538?

It takes approximately 1.5 hours to fully recharge the battery using the included micro USB cable.

Why is my Monotremp MT538 Book Light not turning on?

Ensure the battery is charged. Try using a different USB cable and charging adapter. If the issue persists, reset the book light by leaving it unplugged for a few hours.

Why does my Monotremp MT538 turn off automatically?

This could be due to low battery power. Recharge the device and check if it stays on longer.

Why is my Monotremp MT538 Book Light flickering?

Flickering can be caused by a loose connection in the charging port or low battery. Try recharging the device or adjusting the gooseneck to see if the issue persists.

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.