


MONSGEEK M1 HES Wired Mechanical Keyboard User Manual

[Home](#) » [MONSGEEK](#) » MONSGEEK M1 HES Wired Mechanical Keyboard User Manual 

MONSGEEK M1 HES Wired Mechanical Keyboard




Contents

- 1 Thank you for supporting MonsGeek
- 2 Overview
- 3 Packing List
- 4 System Requirement
- 5 Connectivity Method
- 6 Indicator Description
- 7 Shortcuts to Adjust Travel Distance
- 8 M1 HES HotKeys
- 9 M1 HES System Commands (Windows)
- 10 M1 HES Backlight Settings
- 11 Key/Lighting Effects Customization Instruction
- 12 MONSGEEK Warranty and Service Statement
- 13 Customer Support
- 14 Documents / Resources
- 15 Related Posts

Thank you for supporting MonsGeek

To provide you with a better user experience, please read this manual carefully before using the product

Overview



Packing List



System Requirement

Windows “XP | Vista / 7 / 8 / 10 or higher version

Connectivity Method

Connect the keyboard to your computer by plugging in the USB cable into an available USB port to start using it.


Indicator Description

Status	Indicator Pos1t1on	Indicating Mode
Caps	Caps key	Steady White
Lock Win	Left Win key	Steady White

Shortcuts to Adjust Travel Distance

- Fn+1** Switch Travel Distance = 2mm
- Fn+2** Switch Travel Distance = 0.5mm
- Fn+3** Switch Travel Distance = 0.5mm + Ultra Sensitive Mode
- Fn+4** Customize switch actuation distance through MonsGeek Driver (2mm by default)

M1 HES HotKeys





FN+	F1	=	My Computer
	F2		E-mail
	F3		Windows Search
	F4		Browser Homepage
	F5		Media

FN+	F6	=	Pause/Playback
	F7		Previous Song
	F8		Next Song
	C		Calculator
	M		Mute

FN+	<	=	Decrease Volume
	>		Increase Volume
	p		Print SC
	I		Insert
	W		Swap WAS D with ↑↓←→

M1 HES System Commands (Windows)



Rotary Knob

Default is volume function;
Rotate counterclockwise to decrease the volume;
Rotate clockwise to increase the volume.

Press the middle to switch to brightness function;
Rotate counterclockwise to decrease brightness;
Rotate clockwise to increase brightness.

Lock Windows Key

Press Fn and Left Win Key

Restore Factory Settings


Hold down Fn and press – Key for 5S

Revert Ctrl into Menu Key (Memorable)

Hold down Fn and press Right Ctrl Key for 3S

Win System ⇌ Mac System

Hold down Fn and press 0 Key for 3S



F1 Decrease display brightness

F2 Increase display brightness

F3 Open mission control

F4 Activate Siri

F7 Skip back (Audio)

F8 Pause/Play (Audio)

F9 Skip forward (Audio)

F10 Mute

F11 Decrease Volume

F12 Increase Volume

Left Win Option


Left Alt Command

Right Alt Command

Fn + (F1~12)

F1 ~ F12

M1 HES Backlight Settings



Fn+- Slower Animation Fn+Home

Fn+= Faster Animation Fn+Pgup

Fn+ L Light On/ Off Fn+End

Fn+↑Bright Fn+PgDn

Fn+↓ Dim Fn+

Fn+← Set Animation Direction to Left

Fn+→ Set Animation Direction to Right

Effect1, Effect2, Effect3, Effect4, Effects

Effect6, Effect7, Effect8, Effect9, Effect10

Effect11, Effect12, Effect13, Effect14, Effect15

Effect16, Effect17, Effect18, Effect19, Effect20

This shortcut allows you to set the backlight color to 7 single color with RGB loop effect

Key/Lighting Effects Customization Instruction

1. The key/lighting effects customization can be programmed by MonsGeek driver.
2. The lighting effects can also achieve audio visualizer effects with MonsGeek driver.
3. Please download the MonsGeek Driver on our website.
4. Users can download the driver via www.monsgeek.com.

MONSGEEK Warranty and Service Statement

1. MONSGEEK offers a One-Year warranty for customers in mainland China. For other regions, please contact your seller {MonsGeek distributor} for specific warranty details.
2. If the warranty period expires, customers are responsible for repair costs. MONSGEEK provides instructions for self-repair if preferred, but users assume full responsibility for any losses incurred during the process.
3. Disassembling the keyboard without manufacturer/seller's instruction will void the warranty immediately.
4. Return and warranty policies may vary across platforms and are subject to the specific distributor's terms at the time of purchase.

Customer Support

Company: Shenzhen Yinchon Technology Co., Ltd

Address: 33 Langbi Rd, Bitou Community 1st Industrial Zone, Bao'an District, Shenzhen, China

Tel: 0755-23216420
Website: www.monsgeek.com
Origin: Shenzhen, China



WARNING:
Water and Beverages can't be poured into the Keyboard.



Precautions Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive forces, etc.



Documents / Resources



[MONSGEEK M1 HES Wired Mechanical Keyboard](#) [pdf] User Manual
M1 HES Wired Mechanical Keyboard, M1 HES, Wired Mechanical Keyboard, Mechanical Keyboard, Keyboard

[Manuals+](#)