




MONSGEEK M3W RGB 87 Keys Mechanical Keyboard User Manual

[Home](#) » [MONSGEEK](#) » MONSGEEK M3W RGB 87 Keys Mechanical Keyboard User Manual 

Contents

- [1 MONSGEEK M3W RGB 87 Keys Mechanical Keyboard](#)
- [2 INTRODUCTION](#)
- [3 Packing List](#)
- [4 Connectivity Method](#)
- [5 LED Indicators](#)
- [6 M3W RGB HotKeys](#)
- [7 M3W RGB Backlight Settings](#)
- [8 M3W RGB Wireless/Wired Connection Guide\](#)
- [9 Bluetooth Pairing](#)
- [10 Battery Level Check](#)
- [11 Key/Lighting Effects Customization Instruction](#)
- [12 MONSGEEK Warranty and Service Statement](#)
- [13 Documents / Resources](#)
 - [13.1 References](#)
- [14 Related Posts](#)



MONSGEEK M3W RGB 87 Keys Mechanical Keyboard



Specifications

- Compatible with Windows XP/Vista/7/8/10
- Connectivity: USB
- Model: M3W RGB

Connectivity Method



To start using the keyboard, connect it to your computer by plugging in the USB cable into an available USB port.

INTRODUCTION

Thank you for supporting MonsGeek

To provide you with a better user experience, please read this manual carefully before using the product.

Packing List



System Requirement

Windows®XP | Vista / 7 / 8 / 10 or higher version

Connectivity Method


Connect the keyboard to your computer by plugging in the USB cable into an available USB port to start using it.

LED Indicators

Status	Indicator	Re-Connecting	Pairing	Connected
Bluetooth device 1	LED for Key E	Blue light blinks slowly	Blue light blinks fast	Blue light stays on for 2 seconds and then turns off
Bluetooth device 2	LED for Key R	Blue light blinks slowly	Blue light blinks fast	Blue light stays on for 2 seconds and then turns off
Bluetooth device 3	LED for Key T	Blue light blinks slowly	Blue light blinks fast	Blue light stays on for 2 seconds and then turns off
2.4G wireless device	LED for Key Y	Green light blinks slowly	Green light blinks fast	Green light stays on for 2 seconds and then turns off
Wired mode	LED for Key U	N/A	N/A	Red light stays on for 2 seconds and then turns off

Status	Indicator	Indicating Mode
Low Battery	Right LED for Key Spacebar	White light blinks slowly
Charging		Steady white
Fully Charged		LED off
Caps	LED for Key Caps	Steady white
Lock Win	LED for Key Win	Steady white

M3W RGB HotKeys




Fn+	F1	=	My Computer
	F2		E-mail
	F3		Windows Search
	F4		Browser Homepage
	F5		Multimedia Player

Fn+	F6	=	Play/Pause
	F7		Previous Song
	F8		Next Song
	C		Calculator
	M		Mute

Fn+	<	=	Decrease Volume
	>		Increase Volume
	W		Swap W A S D with ↑ ↓ ← →

M3W RGB System Commands (Windows)



Lock Win Key

Press Fn and left Win key


Restore Factory Settings

Hold down left Win and right Win key for 5s

Evert Ctrl into Menu Key

Hold down Fn and right Ctrl key for 3s

M3W RGB System Commands (Mac)



F1 Decrease display brightness

F2 Increase display brightness

F3 Open mission control

F4 Activate Siri

F7 Previous song

F8 Pause/Play

F9 Next song

F10 Mute

F11 Volume down

F12 Volume up

Left Win Option

Left Alt Command


Right Alt Command

Right Win Option

Fn + (F1~12)

F1 ~ F12


M3W RGB Backlight Settings




Fn+-	Slower Animation
Fn+=	Faster Animation
Fn+L	Light On / Off
Fn+ ↑	Bright
Fn+ ↓	Dim
Fn+←	Set Animation Direction to Left
Fn+→	Set Animation Direction to Right

Fn+Ins	Effect1、Effect2、Effect3
Fn+Home	Effect4、Effect5、Effect6
Fn+Pgup	Effect7、Effect8、Effect9、Effect10
Fn+Del	Effect11、Effect12、Effect13
Fn+End	Effect14、Effect15、Effect16
Fn+Pgdn	Effect17、Effect18、Effect19、Effect20
Fn+\	This shortcut allows you to set the backlight color to 7 single color with RGB loop effect

M3W RGB Wireless/Wired Connection Guide\



Fn+	E	=	Bluetooth Device 1	 The switch is located under the CAPS key	Top: Mac (built-in power supply on)
	R		Bluetooth Device 2		Middle: Default Windows (built-in power supply off)
	T		Bluetooth Device 3		Bottom: Windows (built-in power supply on)
	Y		2.4G Wireless Device		
	U		Wired Mode		

Bluetooth Pairing

After turning on the keyboard, press FN+E/RfT to enter Bluetooth mode. Press and hold the FN+E/RfT combination key for 3 seconds to put the keyboard in pairing mode, with the blue indicator light flashing quickly. Once the connection is established, the indicator light will stay on for 2 seconds. If the device fails to connect, the indicator light will turn off and the keyboard will enter sleep mode.

2.4G Pairing

After turning on the keyboard, press FN+Y to enter 2.4G mode. Then press and hold the FN+Y combination key for 3 seconds to enter pairing mode. Then insert the receiver, and the indicator light will flash quickly. Once pairing is successful, the LED indicator will stay on for 2 seconds. If no available device is found within 30 seconds, the LED indicator will turn off and the keyboard will enter sleep mode.

Battery Level Check

Press the Fn + Space combination keys to check the battery level in wireless mode. If the battery level is below 30%, the LED for number keys 1-2 will show a red light. If it's between 30-100%, the LED for number keys 1-9 will show a green light.

And when the battery is fully charged, the LED for number keys 1-0 will show a green light.

1	2	3	4	5	6	7	8	9	0
Less than 30%	Less than 40%	Less than 50%	Less than 60%	Less than 70%	Less than 80%	Less than 90%	Less than 100%	Full charged	

Red light

Green light

Key/Lighting Effects Customization Instruction

1. The driver can be connected and lighting and key can be customized under the three working modes of the keyboard.
2. The three working modes of the keyboard can be matched to drive the music's rhythm.
3. Please download the MonsGeek Cloud Driver on our website.
4. Users can download the driver via www.monsgeek.com

MONSGEEK Warranty and Service Statement

1. MONSGEEK offers a One-Year warranty for customers in mainland China.
For other regions, please contact your seller (MonsGeek distributor) for specific warranty details.


2. If the warranty period expires, customers are responsible for repair costs.
MONSGEEK provides instructions for self-repair if preferred, but users assume full responsibility for any losses incurred during the process.
3. Disassembling the keyboard without the manufacturer/seller's instruction will void the warranty immediately.
4. Return and warranty policies may vary across platforms and are subject to the specific distributor's terms at the time of purchase.

- Company: Shenzhen Yincheng Technology Co., Ltd
- Address: 33 Langbi Rd, Bitou Community 1st Industrial Zone, Baoan District, Shenzhen, China
- Tel: 0755-23216420
- Website: www.monsgeek.com
- Origin: Shenzhen, China


WARNING: Water and Beverages can't be poured into the Keyboard.

Precautions Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive force, etc.

Documents / Resources

	<p>MONSGEEK M3W RGB 87 Keys Mechanical Keyboard [pdf] User Manual</p> <p>M3W RGB 87 Keys Mechanical Keyboard, M3W RGB, 87 Keys Mechanical Keyboard, Keys Mechanical Keyboard, Mechanical Keyboard, Keyboard</p>
---	---

References

-  [- MonsGeek](#)
-  [- MonsGeek](#)
-  [MonsGeek - Make Cool Gears Accessible.](#)
- [User Manual](#)