




# MONSGEEK MG108 Mechanical Keyboard User Manual

[Home](#) » [MONSGEEK](#) » MONSGEEK MG108 Mechanical Keyboard User Manual 

## Contents


- [1 MONSGEEK MG108 Mechanical Keyboard](#)
- [2 MG 108 Hotkey](#)
- [3 MG108 System Commands \(Windows\)](#)
- [4 MG108 System Commands \(Mac\)](#)
- [5 MG 108W Operation Mode Switch](#)
- [6 Customization Instruction](#)
- [7 MONSGEEK Warranty and Service Statement](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)



**MONSGEEK MG108 Mechanical Keyboard**



## MG 108 Hotkey




Fn+	F1		File Explorer
	F2	=	E-mail
	F3		Windows Search


Fn+	F4		Browser Homepage
	F5	=	Media
	F6		Pause / Playback

Fn+	F6		Previous Song
	F7	=	Next Song
	w		SwapW As D <b>with</b> ↑ ↓ ← →

## MG108 System Commands (Windows)





## MG108 System Commands (Mac)



F1	Decrease display brightness	F7	Skip back (Audio)	F11 Volume down	Right Alt Command
F2	Increases display brightness	F8	Pause/Play (Audio)	F12 Volume up	
F3	Open mission control	F9	Skip forward (Audio)	Left Win Option	Fn+ (F1 ~ F12)
F4	Activate Siri	F10	Mute	Left Alt Command	F1 ~F12

## MG 108W Operation Mode Switch

- The built-in battery will start to power when the back switch is in non-USB mode (either Mac or Win). The keyboard will switch to USB wired mode automatically once the USB cable is plugged in.
- The switch will complete when the LED indicator flashes 3 times.



## Customization Instruction

1. The key and backlight customization must be completed with the MonsGeek driver.
2. Please download the driver from [www.monsgeek.com/download](http://www.monsgeek.com/download).

### Note:

MG108W Battery Level Indicator

- **Low Battery:** Slow flashing white LED
- **Charging:** Constant white LED
- **Fully Charged:** LED off

## MONGEEK Warranty and Service Statement

1. MONGEEK provides a One-Year warranty for customers in mainland China. For other regions, please contact your seller (MonsGeek distributor) for a specific warranty policy.
2. If the warranty window expires, customers need to pay for repairs. MONGEEK will also provide instructions if users prefer to repair the keyboard by themselves. However, users shall take full responsibility for any loss that happened during self-repair.
3. Disassembling the keyboard without the manufacturer/seller's instruction will immediately void the warranty.
4. The return and warranty policy may vary in different platforms and are subject to the specific distributor at the time of purchase.


### Precautions:

Man-made damage is not limited to immersion, falling off, pulling off the wires with excessive force, etc.

### MONGEEK

[www.monsgeek.com](http://www.monsgeek.com).

## Documents / Resources

	<a href="#">MONGEEK MG108 Mechanical Keyboard</a> [pdf] User Manual MG108 Mechanical Keyboard, MG108, Mechanical Keyboard, Keyboard
---	--