



MONSGEEK MG75 Hotkey Mechanical Keyboard User Manual

[Home](#) » [MONSGEEK](#) » MONSGEEK MG75 Hotkey Mechanical Keyboard User Manual 

Contents


- [1 MONSGEEK MG75 Hotkey Mechanical Keyboard](#)
- [2 Hotkey](#)
- [3 System Commands \(Windows\)](#)
- [4 System Commands \(Mac\)](#)
- [5 Operation Mode Switch](#)
- [6 Customization Instruction](#)
- [7 Warranty and Service Statement](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



MONSGEEK MG75 Hotkey Mechanical Keyboard



Hotkey




Fn+	F1	=	My Computer
	F2		E-mail
	F3		Windows Search
	F4		Browser Homepage
	F5		Media

Fn+	F6	=	Pause /Playback
	F7		Previous Song
	F8		Next Song
	I		Ins
	P		Print SCR

Fn+	C	=	Calculator
	M		Mute
	<		Decrease Volume
	>		Increase Volume
	W		Swap W A S D with ↑ ↓ ← →

System Commands (Windows)



LED Indicator

1.CAPSLock

2.Mac OSX Mode

*Battery Level Indicator(MG75W)

Slow flashing white LED when in low battery
LED light on when in charging
LED light off after a full charging

3.Lock Win

Lock Windows Key

Press Fn and
left Win key

Restore Factory Settings

Hold down FN
and ~ key for 5s

Revert Ctrl into Menu Key (Memorable)

Hold down Fn and
right Ctrl key for 3s


2.4G Mode (MG75W)

Hold down Fn and Y key

USB Mode (MG75W)

Press Fn and U key

System Commands (Mac)



- **F1:** Decrease display brightness
- **F2:** Increases display brightness
- **F3:** Open mission control
- **F4:** Activate Siri
- **F7:** Skip back (Audio)
- **F8:** Pause/Play (Audio)
- **F9:** Skip forward (Audio)
- **F10:** Mute
- **F11:** Volume down
- **F12:** Volume up
- Left Win Option
- Left Alt Command
- Right Alt Command

Fn + (F1 ~ F12)

- F1 ~ F12

Operation Mode Switch

- The built-in battery will start to power when the back switch is in the non-USB mode (either Mac or Win). The keyboard will switch to USB wired mode automatically once the USB cable is plugged in.
- The switch will complete when the LED indicator flashes 3 times.



Customization Instruction

1. The key/lighting effects customization can be programmed with MonsGeek Driver.
2. Please visit monsgeek.com/download/ to download the driver.

Note:

- MG75 Battery Level Indicator
- **Low Battery:** Slow flashing white LED
- **Charging:** Constant white LED
- **Fully Charged:** LED off

Warranty and Service Statement

1. MONSGEEK provides a One-Year warranty for customers in mainland China. For other regions, please contact your seller (MonsGeek distributor) for a specific warranty policy.
2. If the warranty window expires, customers need to pay for repairs. MONSGEEK will also provide instructions if users prefer to repair the keyboard by themselves. However, users shall take full responsibility for any loss happens during self-repair.
3. Disassembling the keyboard without the manufacturer/seller's instruction will immediately void the warranty.
4. The return and warranty policy may vary on different platforms and are subject to the specific distributor at the time of purchase.

Precaution

Man-made damage is not limited to immersion, falling off, pulling off the wires with excessive force, etc.

www.monsgeek.com.

Documents / Resources



[MONSGEEK MG75 Hotkey Mechanical Keyboard](#) [pdf] User Manual
MG75 Hotkey Mechanical Keyboard, MG75, Hotkey Mechanical Keyboard, Mechanical Keyboard, Keyboard

References

- [User Manual](#)