



[Home](#) » [Monster](#) » **MONSTER 4×4 MacHine RC Rock Crawler Instruction Manual** 

Contents [[hide](#)]

- [1 MONSTER 4×4 MacHine RC Rock Crawler](#)
- [2 INSTALLING BATTERIES IN THE TRANSMITTER](#)
- [3 INSTALLING THE VEHICLE BATTERY](#)
- [4 HOW TO CHARGE](#)
- [5 HOW TO USE](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)




MONSTER 4×4 MacHine RC Rock Crawler




INSTALLING BATTERIES IN THE TRANSMITTER

1. Open the battery compartment.
2. Insert 2 x 1.5V AA batteries with correct + and – polarities.
3. Close the cover.



INSTALLING THE VEHICLE BATTERY


1. Loosen the screw to open the battery cover.
2. As shown in Figure 2, remove the battery cover, connect the rechargeable battery pack to the connector, and close the battery cover.




HOW TO CHARGE

- **A.** Loosen the screw to open battery cover.
- **B.** Separate the rechargeable battery pack from the connector.
- **C.** Connect the USB charging cable with the rechargeable battery first (The battery connector will only fit in one way, do not force the connectors together), then plug the large end of the USB 2A cable into a 5Vd.c charger (not supplied) or a USB port only. The red LED light on the USB charging cable will light up, and the green LED light will flash when charging. argng
- **D.****The** green LED light will light up and will be off after it has finished charging. Disconnect the USB charging cable from the USB port and then disconnect the rechargeable battery with the USB charging cable

Attention: Do not charge the battery immediately after each play. Let the battery cool down for a while.



-  Rechargeable lithium battery pack +USB charging cable (Included).



HOW TO USE

1. Turn on the vehicle first and then turn on the transmitter. Turn on the vehicle first and then turn on the transmitter.
2. Pull the trigger of the transmitter to match the vehicle.
3. When the vehicle is functioning, that means they are matched.
4. If you have more than two vehicles, please pair them one by one. When the second vehicle is pairing, please always keep the first vehicle and transmitter on.

5. Please turn off both the vehicle and transmitter and restart all pairing processes if you are changing to play with another 2.4GHz transmitter.

How to move forward or backward: Pull the throttle trigger, and the vehicle will move forward.

6. Push the throttle trigger, and the vehicle will

7. Turn left or right: Turn the steering wheel clockwise, and the vehicle will turn right.

Turn the steering wheel anticlockwise, and the vehicle will turn left.



WARNING:

- BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (AND -1.
- DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE CHARGED.
- BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION.
- THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED.
- REMOVE BATTERIES FROM THE TOY WHEN NOT IN RE NOT TO BE SHORT-CIRCUATED REMOVE BATTERIES FROM THE TOY WHENNOTIN USE FOR AN EXTENDED TIME OR WHEN BATTERIES BECOME EASTEAA
- ATERYINSTALLATIONE AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT FIN FIR

WARNING

- THE BATTERY CHARGER USED WITH THE ELECTRIC TOY SHALL BE REGULARLY EXAMINED FOR DAMAGE TO THE SUPPLY CORD, PLUG, ENCLOSURE, OR OTHER PARTS, AND IN THE EVENT OF DAMAGE. IT SHALL NOT BE USED UNTIL THE DAMAGE HAS BEEN REPAIRED.

CAUTION

- THE PRODUCT HAS A RECHARGEABLE LITHIUM-ION BATTERY.
- ONLY CHARGE THE PRODUCT BY PLUGGING THE LARGE END OF THE USB CABLE INTO A SVO.C. 2A CHARGER (NOT SUPPLIED OR A USB PORT ONLY. ONLY CHARGE THE PRODUCT USING THE SUPPLIED CHARGING CABLE

WARNING: CHOKING HAZARD

- SMALL PARTS NOT SUITABLE FOR CHILDREN UNDER 3 YEARS

WARNING

- THE TOY IS ONLY TO BE CONNECTED TO CLASS I EQUIPMENT BEARING THE SYMBOL 

WARNING

- THIS TOY PRODUCES FLASHES THAT MAY TRIGGER EPILEPSY IN SENSITISED INDIVIDUALS

WARNING

- FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS, AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.

The product may vary from the image shown.

Please keep packing for future reference

Read the instructions before operating the product.

Performance Tips

- Do not drive the vehicle through water
- Do not drive the vehicle into any hard object.



Documents / Resources



[MONSTER 4x4 MacHine RC Rock Crawler \[pdf\]](#) Instruction Manual
4x4 MacHine RC Rock Crawler, MacHine RC Rock Crawler, RC Rock Crawler, Rock Crawler, Crawler

References

- [User Manual](#)

4x4 MacHine RC Rock Crawler, Crawler, MacHine RC Rock Crawler, Monster, RC Rock Crawler, Rock Crawler

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.