



Motorola Solutions GMKN4067 PROGRAMMING CABLE User Guide

[Home](#) » [Motorola Solutions](#) » Motorola Solutions GMKN4067 PROGRAMMING CABLE User Guide

Motorola Solutions GMKN4067 PROGRAMMING CABLE User Guide



MOTOROLA SOLUTIONS

Contents [[hide](#)]

- [1 GENERAL INFORMATION](#)
- [2 OPERATION](#)
- [3 SERVICE](#)
- [4 CABLE CONNECTIVITY](#)
- [5 CONNECTOR DETAIL](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

GENERAL INFORMATION

The GMKN4067 Programming Cable provides a 4-wire RS232 interfaces (For example, RxD, TxD, CTS, RTS) between a computer and a mobile radio when the radio is to be programmed or flashed.

OPERATION

The radio Basic Service Manual includes programming procedures. Refer to the relevant procedures for the radio being programmed and connect the radio to the computer as directed.




Do not disconnect the cable in the middle of a procedure. This may leave the radio incorrectly configured and degrade the radio performance.

SERVICE

The GMKN4067 Programming Cable is not repairable. Order a replacement cable as necessary.


CABLE CONNECTIVITY

To Radio Accessory Connector 20 pins



CONNECTOR DETAIL

To the computer



To Radio Accessory Connector

MOTOROLA, MOTO, MOTOROLA SOLUTIONS and the Stylized M logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners. © 2001 and 2021 Motorola Solutions, Inc. All rights reserved.



Documents / Resources



[Motorola Solutions GMKN4067 PROGRAMMING CABLE](#) [pdf] User Guide
GMKN4067, PROGRAMMING CABLE