


MPOW BH129C Bluetooth Music Receiver User Manual

Home » MPow » MPOW BH129C Bluetooth Music Receiver User Manual





Bluetooth Music Receiver



User Manual


Contents

- 1 Specifications
- **2 Product Diagram**
- **3 HANDS-FREE CALL**
- 4 FAQ
- **5 FCC STATEMENT**
- **6 CORRECT DISPOSAL OF THIS**
- **PRODUCT**
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**

Specifications

Frequency Range	2.402-2.48GHz
Output Power Category	Class 1
Bluetooth Mode	HFP/HSP/A2DP/ AVRCP
Bluetooth Range	up to 30 feet
Power Supply	Li-Po 180mAh
Charge voltage	DC 5.0v

Product Diagram



- 1. Power ON/OFF
- 2. Audio Output
- 3. Micro USB Charging Port
- 4. Microphone

- 5. Previous Song/Volume Down
- 6. Next Song/Volume Up
- 7. Indicator Light
- 8. Play/Pause; Answer/Hang up

Power On/Off

Power on

Turn the power switch to the "ON" side, this receiver will power on automatically. Red light will stay on for 1s then the red and blue lights flash alternately.

Power off

Turn the power switch to the "OFF" side, red light will stay on for 1s and then this receiver will power off automatically.

Note:If there is no operation or connection after the product powers on, it will automatically enter sleep mode after 10 minutes. Short press " button for 1 second to wake it up. When the product disconnects with the mobile phone, it will automatically enter sleep mode after 20 minutes. Short press " button for 1 second to wake it up.

Pair To Your Device

For the first time using the receiver, you should pair it to your smart device first.

- 1. Power on the receiver, it will enter into pairing mode. The red and blue lights flash alternately.
- 2. Turn on the Bluetooth function of your smart device.
- 3. Search for the Bluetooth device "BH129" and connect to it.
- 4. Enter the code "0000" if needed. If it pairs successfully, the indicator light will blink once every two seconds.
- 5. Connect the receiver to your non-Bluetooth headphone/Home Speakers or Car Stereo System with 3.5mm audio cable.
- 6. Now you can enjoy music through your headphones, Speakers, or Stereo System, or answer hands-free calls after connecting with smartphones.

Connect Two Smart Devices

- 1. Pair the Bluetooth receiver to the first device.
- 2. After successfully pairing, turn off the Bluetooth function of the first device.
- 3. The receiver will enter pairing mode again.
- 4. Pair the Bluetooth receiver to the second device.
- 5. After successfully paring, turn on the Bluetooth function of the first device. Select the "BH129" and click "connect".
- 6. Two devices will both connect the Bluetooth receiver at the same time.

Note: When the receiver is on it will connect to the last connected device automatically. (Please make sure the Bluetooth function of your device is enabled before turning on the receiver.)

HANDS-FREE CALL

Answer A Call

1. When there is an incoming call, short press the button " To answer it.

When get through, long press " | I | "for 1s that you can choose to answer the call through Bluetooth or phone.

- 2. If there is a second incoming call while you are speaking:
- 3. Short press the button " hang up the first call, and answer to the new call.
 - · Long press the button " " for about 1s, hang on the first call, and answer the new call.

Reject A Call

Long press the button " I " for about 1s.

End A Call

Short press the button " I or just hang up your phone.

Redial The Last Called Number

Double press the button " I " to redial the last called number.

Play Music

- 1. Play/Pause: Short press the button "
- 2. Next Song: Short press the button " + "
- 3. Previous Song: Short press the button "-"
- 4. Volume Up: Long press the button "+"
- 5. Volume Down: Long press the button "-"

Voice Assistant

Long press the " button for about 1s to start or end the voice assistant function.

Wipe Out Bluetooth Connection History When the receiver is off, long-press the button " off about 8s, the system will wipe out the Bluetooth Connection history.

Note: You can only wipe out the audio connection history of the receiver through this operation. Can't wipe out the Bluetooth history of your smart devices.

Charge The Receiver

When the receiver is in low power state, it will alarm automatically that the red light flashes 15 times quickly. After that, the red light will flash once every two seconds instead. In this case, please charge it through USB charging port with DC 5V power supply input. During charging the red indicator will stay on. When it finishes charging, the red indicator will go off.

FAQ

Q1: The product can't pair with the Bluetooth of your smart device.

- 1. Please make sure the product have entered pairing mode.
- 2. Make sure there is only one Bluetooth-enabled device around you.
- 3. Wipe out the paring history of your Bluetooth-enabled devices and receiver, then try again.

Q2: The Bluetooth range or the sound quality is not good.

- 1. Bluetooth signal can be blocked by surrounding objects and reduce the audio quality, please put it in the right position without a barrier between the receiver and your smart devices.
- 2. Wipe out the paring history of the product, then try again.

FCC STATEMENT

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Note 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

CORRECT DISPOSAL OF THIS PRODUCT



(Waste Electrical& Electronic Equipment)

This Marking shown on the product or its literature indicates that it should not be disposed of with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of waste and recycle it responsibly to promote the sustainable reuse of material resources. Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their suppliers and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.



Documents / Resources



MPOW BH129C Bluetooth Music Receiver [pdf] User Manual

BH129C, 2AMH2-BH129C, 2AMH2BH129C, BH129C, Bluetooth Music Receiver, Music Receiver, Bluetooth Receiver, BH129C, Receiver

References

MPOW - Power of Technology and Art

Manuals+,