



## msi DS4100 Gaming Keyboard User Manual

[Home](#) » [MSI](#) » msi DS4100 Gaming Keyboard User Manual 



DS4100  
GAMING KEYBOARD

### Contents

- [1 Introduction](#)
- [2 Package Contents](#)
- [3 Specifications](#)
- [4 Media Function](#)
- [5 Hotkey Function](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)

### Introduction

Thank you for choosing the well-designed gaming keyboard, MSI DS4100, to be your companion. This exquisite gaming keyboard will surely give you a delightful and professional experience in PC games.

This guide provides instructions and illustrations to help you get the most from the keyboard, and it is recommended to read this guide before using it.

### Package Contents

- GAMING Keyboard
- User Guide

#### System Requirements

- PC with available USB port
- Windows 10/ 8.1/ 8/ 7







## Specifications

- Interface: USB
- Cable Length: 1.8M braided cable
- Dimensions: 452 x 201 x 18 mm













### Introductions to Function Keys

#### LED Indicators Adjustment


Use the keyboard hot keys listed below to customize the backlit configurations.

	Switch between 7 backlit colors
	Increase the backlit brightness (4 levels )
	Decrease the backlit brightness (4 levels )
	Switch between 7 different backlit colors automatically
	Increase the flashing frequency of breathing mode
	Decrease the flashing frequency of breathing mode

## Media Function

 Media Player	 Volume Down	 Volume Up
 Mute	 Stop	 Previous Track
 Play/Pause	 Next Track	 Email
 Home Page	 Lock / Unlock all media function	 Calculator

## Hotkey Function



Exchange the function between [W]/[S]/[A]/[D] and the direction keys [↑]/[↓]/[←]/[→]




Disable the function of Windows Key. The G LED located on the upper right side of the keyboard illuminates when Windows key is disabled.

### Micro-Star International Co.LTD.

No.69, Lide St., Zhonghe Dist., New Taipei City 235, Taiwan (R.O.C.)

tel: +886-2-32345599 / fax: +886-2-32345488

## Documents / Resources

	<a href="#">msi DS4100 Gaming Keyboard</a> [pdf] User Manual DS4100, DS4100 Gaming Keyboard, DS4100, Gaming Keyboard, Keyboard
---	---

## References

-  [Your Ultimate Resource for Millions of User Manuals](#)
- [User Manual](#)

### Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.