



msi MPG Sekira 100R Mid-Tower Computer Case User Guide

[Home](#) » [MSI](#) » msi MPG Sekira 100R Mid-Tower Computer Case User Guide 

Contents



- [1 msi MPG Sekira 100R Mid-Tower Computer Case](#)
- [2 Accessories](#)
- [3 Specification](#)
- [4 Case Features](#)
- [5 Side & Front View](#)
- [6 IO Panel / IO](#)
- [7 SSD , HDD Installation/ SSD](#)
- [8 Motherboard Installation](#)
- [9 Cables Connection](#)
- [10 Graphics Card Installation](#)
- [11 PSU Installation](#)
- [12 Documents / Resources](#)
- [13 Related Posts](#)

msi

msi MPG Sekira 100R Mid-Tower Computer Case




Accessories

Item	Name	Used for
	1 to 3 fan splitter cable	Connect 3 fans
	Cable ties	Cable management
	Screw M3 5mm x17	Motherboard / SSD
	Screw #6-32 6mm	PSU / PCIe Card
	Screw #6-32 6mm	HDD


Specification

	MPG SEKIRA 100R	MPG SEKIRA 100P
Pre-installed	Front: 3x 120 mm ARGB fans Rear: 1 x 120 mm ARGB fan	Front: 3x 120 mm Black fans Rear: 1x 120 mm Black fan
Case Dimensions (mm)	420(D) x 215(W) x 473(H)	
Motherboard Support	E-ATX/ ATX / Micro-ATX / Mini-ITX	
Drive Bays	2x 2.5" SSD trays 2x 3.5" + 2.5" combo tray s	
IO Panel	1x Power button 1x Reset button 1x Power indicator 1x USB 3.2 Gen 2 Type-C port 2x USB 3.2 Gen 1 Type-A ports 1x Mic in jack 1x Audio out jack 1x LED switch button	
Clearance	CPU Cooler Hight: Max 170 mm Graphics Card Length: Max 340 mm PSU Length: Standard ATX 250 mm	
Fan Support	Front: Up to 3x 120 mm or 2x 140 mm Top: Up to 2x 120 mm or 2x 140 mm R ear: Up to 1x 120 mm	
Radiator Support	Front: Up to 360 mm Top: Up to 240 mm Rear: Up to 120 mm	
Material	Left Side: Tempered Glass Right Side: Metel Front: Aluminum+Tempered Glass / Aluminum Top: Metel	


Case Features



Side & Front View




IO Panel / IO




1. Power button
2. Reset button
3. Power indicator
4. USB 3.2 Gen 1 Type-C
5. USB 3.2 Gen 1 Type-A
6. Mic in
7. Audio out
8. LED switch button / LED

- Short press the LED switch button to change mode.
- Long press the LED switch button for 3 seconds to turn LED off.


SSD , HDD Installation/ SSD




Opening the Top Cover, Left & Right Side Cover





Motherboard Installation




Cables Connection



Graphics Card Installation



PSU Installation



Documents / Resources

 MPG SEKIRA 100R MPG SEKIRA 100P User Guide 使用手冊  TM by Copyright © 2019 MSI	msi MPG Sekira 100R Mid-Tower Computer Case [pdf] User Guide MPG Sekira 100R Mid-Tower Computer Case, MPG Sekira 100R, Mid-Tower Computer Case, Computer Case, Case
 MPG SEKIRA 100R MPG SEKIRA 100P User Guide 使用手冊  TM by Copyright © 2019 MSI	msi MPG SEKIRA 100R Mid-Tower Computer Case [pdf] User Guide MPG SEKIRA 100R Mid-Tower Computer Case, MPG SEKIRA, 100R Mid-Tower Computer Case, Tower Computer Case, Computer Case, Case