



MSR Access Series Installation Guide

[Home](#) » [MSR](#) » MSR Access Series Installation Guide 📄

MSR Access Series Installation Guide



Contents

- 1 PACKAGE INCLUDES:
- 2 PREPARE FOR SETUP
- 3 ASSEMBLE TENT FRAME
- 4 SETUP VESTIBULE
- 5 STAKE VESTIBULE
- 6 USE TIPS
- 7 Documents / Resources
- 8 Related Posts


PACKAGE INCLUDES:

- Frame assembly

- tent body
- rainfly
- stakes

PREPARE FOR SETUP

1. Stake out four corners tightly.




ASSEMBLE TENT FRAME

1. Insert pole tips of main frame into floor grommets.
2. Attach clips to tent pole.



SETUP VESTIBULE

1. Place cross pole under main frame and insert pole tips into mid grommets.
2. Attach clips to tent pole.
3. Place clip below red washer.



STAKE VESTIBULE

1. Lay rainfly over tent, aligning seams to frame. Insert pole tips into rainfly grommets.
2. Stretch out vestibules till taut, stake down.



USE TIPS

All tents require staking; unsecured tents are susceptible to wind damage. In some conditions, additional stakes and cord may be required. Re-adjustment of stakes and rainfly may be necessary to keep tent tight and weatherproof.

© 2020 Cascade Designs, Inc.
4000 First Avenue South
Seattle, WA 98134 USA
1-800-531-9531 1-206-505-9500



Documents / Resources

| | |
|---|---|
|  A thumbnail image of the MSR Access Series Installation Guide. It shows a small diagram of a tent and four numbered steps (1-4) illustrating the assembly process. The text "ACCESS SERIES" is visible at the top of the thumbnail. | <p>MSR Access Series [pdf] Installation Guide Access Series</p> |
|---|---|

Manuals+