



myFirst Camera Insta 2 Instant Camera Hybrid Instant Camera User Manual

[Home](#) » [myFirst](#) » myFirst Camera Insta 2 Instant Camera Hybrid Instant Camera User Manual 

myFirst Camera Insta 2 Instant Camera Hybrid Instant Camera User Manual



Contents

- [1 Things to do before you start](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

Things to do before you start

Charge your camera Charging time up to 2.5 hours



Insert a memory card Storage support up to 32 GB



A: Place a roll of thermal paper into the holder like this 





OR

B: Place a roll of thermal sticker into the holder like this .




Use the paper roll that is provided
OR choose the right measurement of paper roll for your camera



Follow step by step. Please tick  when completing a task.


1. Power on

Press and hold  to turn on the camera.




2. Take a photo

Press the big  to take a photo.





3. Gallery mode

Press  to look at the photo you have just taken.





4. Camera mode

Press  again to go back to the camera mode.





5. Take a video

Press and hold the big  to take your first video. Press it again to stop





6. Video playback

Press  to check your first video. Press  to start or stop playback



7. Browse gallery


Press  or  to browse your other photos in the gallery




8. Delete a photo/video you have just taken

Press  to pop up a menu. Use  and  to select whether you want to delete it.



Press the big  to confirm your selection.





9. Print a photo


In gallery mode, press  to print the current photo.



10. Take a photo and print it out


Press  to go back to the camera mode.





Press  to take a photo, and it will be printed out automatically.




11. Take a selfie


Press  to switch to the selfie lens.



Look at the screen, and press the big  to take a selfie.




OR

Or you can just press  to take a selfie, and it will be printed out automatically.




12. Filters and templates




In the camera mode, press  or  to browse filters and templates.




Press  and take 3 photos continuously



Press  and take a photo after 3 secs.




Press  to start taking a photo in every 3 seconds. Double click it to exit



Templates



Frames



Grids





Filters


13. Set date and time for your camera


Go back to camera mode. Press  to pop up the setting menu.






Press  2 times to move the selector to “Date and Time”.





Hit the big  to enter the submenu.




Use  and  to change the number or time display format.





Press  to move to the next item, or press  to move to the previous item.




Hit the big  to save and exit the setting of “Date and Time”.



14. Other settings

Use  and  to move the selector up and down.



Press the big  to enter a submenu. Hit it again to save and exit the submenu.



Or press  to leave a submenu without saving any change.





[myFirst Camera Insta 2 Instant Camera Hybrid Instant Camera](#) [pdf] User Manual
Camera Insta 2, Instant Camera Hybrid Instant Camera