



n-com B602 Single Motorcycle Intercom User Guide

[Home](#) » [N-Com](#) » n-com B602 Single Motorcycle Intercom User Guide 

n-com B602 Single Motorcycle Intercom



Contents

- 1 INTRODUCTION
- 2 N-COM EASYSET
- 3 VOICE PROMPTS
- 4 KEY
- 5 MODE
- 6 BASIC FUNCTIONS
- 7 PAIRING MODE
- 8 MOBILE PHONE
- 9 MUSIC
- 10 INTERCOM
- 11 Documents /
Resources
 - 11.1 References
- 12 Related Posts

INTRODUCTION

This QUICK GUIDE does not replace the product user manual. Instructions on installing in the helmet, complete operating instructions, video tutorials and all specifications are available on the website www.n-com.itatsectionSupport.

Read all the user instructions carefully before using the product.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by N-Com is under license. Other trademarks and trade names are those of their respective owners.

N-COM EASYSET



Update and customize your N-Com system with N-Com EASYSET.

Install on PC or Mac (see www.n-com.it,inthesupportsection). App for Android and iOS smartphones can be downloaded free on Google Play/App Store.







VOICE PROMPTS



The N-Com system comes with voice prompts that provide information about the system and its functions. The default language is English. To change the language, use the System Configuration Menu (refer to the complete user manual), the N-Com EASYSET app for smartphones, or the N-Com EASYSET program on your PC/MAC.

 MANUALS	 TUTORIALS
--	--

KEY

		
		
Press and hold the button for the number of seconds indicated.	Press and release the button for the number of times indicated.	Voice prompts or acoustic signal


MODE

	Complete Mode
	Simple Mode


The B602 system is equipped with two modes, Complete Mode and Simple Mode.
Available functions depend on which Mode is selected.
The system's default mode is Complete Mode.
The compatibility with the two Modes for each function is indicated below

BASIC FUNCTIONS


PAIRING MODE




CONFIGURATION MENU



FACTORY RESET




PAIRING MODE




MOBILE PHONE


MOBILE PHONE PAIRING




MOBILE PHONE PAIRING




ANSWER



VOICE ASSISTANT





HANG UP/REJECT





MUSIC


PLAY/PAUSE



SKIP/REW





MUSIC SHARING



INTERCOM


INTERCOM PAIRING




INTERCOM CONNECTION



INTERCOM PAIRING






INTERCOM CONNECTION



For additional information, www.n-com.it



Documents / Resources

 B602 <small> Quick guide Component Code reader Accessories Spare parts </small>	n-com B602 Single Motorcycle Intercom [pdf] User Guide B602 Single Motorcycle Intercom, B602, Single Motorcycle Intercom, Motorcycle Intercom, Intercom
--	--

References

- [Home | N-Com](#)