$\underline{\textbf{Manuals+}} \ - \ \textbf{User Manuals Simplified}.$



nacon 5 Pro Wireless Controller User Guide

Home » nacon » nacon 5 Pro Wireless Controller User Guide 🖺

nacon 5 Pro Wireless Controller



Contents

- 1 Important Information
- **2 THANK YOU FOR YOUR**

PURCHASE!

- 3 Getting started
- 4 Wired / Wireless connection
- **5 Charging the Battery**
- **6 Vibration**
- **7 Additional Statement**
- **8 Trigger Stopper**
- 9 Bluetooth® pairing
- **10 Customer Support**
- 11 Documents / Resources
 - 11.1 References
- **12 Related Posts**

Important Information

"PlayStation", "PS5", "PS4" and "PlayStation Shapes Logo" are registered trademarks or trademarks of Sony Interactive Entertainment Inc. All other trademarks are the property of their respective owners. Manufactured and distributed under license by Sony Interactive Entertainment.

THANK YOU FOR YOUR PURCHASE!


This guide will help you to get started with your REVOLUTION 5 PRO controller.

For technical support, please contact Consumer Service at: https://my.nacongaming.com/support

Getting started

Connect your Revolution 5 Pro controller to your PS5® console by using the USB-C cable or the included USB dongle (2.4GHz RF receiver). An icon will appear, in the top Right of your TV screen, showing the controller is connected.

Wired / Wireless connection



Charging the Battery

To charge the battery, connect the USB cable to the console and to the controller. Make sure that the controller is powered OFF as this will charge the battery in the shortest time. If you want to use the controller and charge at the same time, then the battery will "trickle" charge and the charge time will be extended.

NOTE: When charging always use the cable provided.

Vibration

The controller is equipped with a vibration engine which is only compatible with PC* and PS4™ games. In PS5® mode on PS5® games played on the PS5® console, the controller will not vibrate


Additional Statement

- 1. This controller uses 2.4GHz radio frequency range, so you may notice some issues if other products use the same radio frequency range.
- 2. Nacon validated operability between the PlayStation®5 console (CFI-1000 series) and this controller.
- 3. It is recommended to insert the USB dongle into the USB port at the front of your PlayStation®5 console (CFI-1000 series).

Trigger Stopper

To activate or deactivate the trigger stopper, follow these steps:


- 1. Press down the button to unlock it.
- 2. Press and hold the button, and then slide up or down to activate/deactivate the stopper.



Bluetooth® pairing

To pair the controller to Bluetooth® true wireless earbuds or headset follow these steps:

- 1. Put the controller and true wireless earbuds/headset next to each other.
- 2. Put the Bluetooth® true wireless earbuds/headset in to pairing mode.
- 3. Press and hold the Bluetooth® button on the controller for 6 seconds.
 - The controller will go in to pairing mode and the halo ring will flash blue.
 - When the controller is paired, the halo ring will stop flashing.
 - Future connections of the same true wireless earbuds/headset, will pair automatically.



NOTE: This controller cannot connect directly to the console, via Bluetooth.

Customer Support

Thank you for choosing this product by **NACON.** The full instruction manual and declaration of conformity can be downloaded at: https://my.nacongaming.com/support

WWW.NACONGAMING.COM











Licensed for sale in the European Union, United Kingdom, Australia, New Zealand, United States. Manufactured by Nacon. All the trademarks belong to their respective owners.





Documents / Resources



nacon 5 Pro Wireless Controller [pdf] User Guide5 Pro Wireless Controller, 5 Pro, Wireless Controller, Controller

References

- Support MyNacon
- Contattaci Nacon
- User Manual

Manuals+, Privacy Policy