



nacon EVOL X PRO Light Controller User Guide

[Home](#) » [nacon](#) » nacon EVOL X PRO Light Controller User Guide 

Contents

- 1 nacon EVOL X PRO Light Controller
- 2 Product Specifications
- 3 Product Usage Instructions
- 4 Frequently Asked Questions (FAQ)
- 5 Package contents
- 6 Product specifications
- 7 Controller elements
- 8 How to use this controller on Xbox
- 9 How to use this controller on PC
- 10 How to change the LED effects
- 11 How to map the shortcuts
- 12 Recycling
- 13 Important precautions
- 14 Ergonomics
- 15 Technical support
- 16 Legal Notices
- 17 EU Declaration of Conformity
- 18 UK Declaration of Conformity
- 19 FCC: Declaration of Conformity
- 20 ABOUT COMPANY
- 21 SUPPORT :
- 22 Documents / Resources
 - 22.1 References



nacon EVOL X PRO Light Controller



Product Specifications

- Wired controller for the Xbox console
- 3.5mm audio jack socket
- Detachable USB-C to USB-A 3m cable
- Compatible with Xbox console and PC
- **Weight:** 220g
- **Height x width x depth:** 154 x 97 x 48 mm
- **Cable length:** 3 m approx.
- **Input/Output:** 5V DC 500mA : DC power supply

Product Usage Instructions

How to Use the Controller on Xbox

- Connect the USB cable to an unused port on your Xbox console.
- Take care not to touch the sticks or triggers when switching on the controller.
- If your console is off, press the Xbox button on your controller to turn on the console or press the X button on your Xbox.
- Once the status LED (no. 2) is solid white, you're ready to play!
- The controller will switch off as soon as the USB cable is unplugged.

How to Use the Controller on PC

The Evol-X PRO controller is a Plug-n-Play device. The necessary driver software will be automatically installed when the controller is first connected to your computer.

How to Change the LED Effects

- The controller includes 20 preset light effects. To switch between them, do a short press on the multi-function button.
- Keep pressing the button to cycle through the different effects. Stop when you find the one you want.
- Note that when you reach the end of the LED effects, the LEDs will turn off. Press the button again to turn them back on.

How to Map the Shortcuts

- Press and hold the multi-function button for 3 seconds. The status LED will flash.
- Press the shortcut button that you want to map, followed by the button that you want to assign to that shortcut.
- Repeat the process for each shortcut. To reset the mapping on the shortcut, double press it.
- To finish the mapping, press and hold the multi-function button for 3 seconds.

Frequently Asked Questions (FAQ)

• Recycling Instructions

Please recycle this product responsibly according to local regulations.

• Important Precautions

1. This product is designed for indoor use only. Do not expose it to direct sunlight or bad weather.
2. Avoid exposing the product to splashes, rain, drips, or moisture. Do not immerse it in liquid.
3. Avoid exposure to dust, high levels of humidity, extreme temperatures, or mechanical shocks.
4. Do not use or open if the equipment is damaged. Do not attempt to repair it yourself.
5. When cleaning the outside, only use a soft, clean and damp cloth. Do not use detergents.

Thank you for purchasing this NACON® product.

This product has been designed to enhance your gaming experience. Please keep this user manual in a safe place for future reference.

Package contents



1 Controller



**1 USB-C to USB-A
3m cable**



**1 Warranty &
Compliance insert**

Product specifications

- Wired controller for the Xbox console.
- 3.5mm audio jack socket.
- Detachable USB-C to USB-A 3m cable.
- Compatible with Xbox console and PC.
- **Weight:** 220g.
- **Height x width x depth:** 154 x 97 x 48 mm.
- **Cable length:** 3 m approx.
- **Input/Output** 5V DC 500mA : DC power supply.

Controller elements



1. USB-C Cable
2. Status LED
3. MENU button
4. Right bumper RB
5. A / B / X / Y action buttons
6. 38° Right analog stick with digital button
7. 3.5 mm audio jack socket

8. D-pad
9. SHARE button
10. XBOX button
11. 38° Left analog stick with digital button
12. Left bumper LB
13. VIEW button
14. Rear Right trigger RT
15. Rear Left trigger LT
16. Left shortcut
17. Multi-function button
18. Right shortcut

How to use this controller on Xbox

- Connect the USB cable to an unused port on your Xbox console. Take care not to touch the sticks or triggers when switching on the controller. If your console is off, press the Xbox button on your controller to turn on the console or press the X button on your Xbox.
- Once the status LED (no. 2) is solid White. You're ready to play!
- The controller will switch off as soon as the USB cable is unplugged.

NOTE: from time to time we may update the software, of our products, to enhance the gaming experience. Please check our website www.nacongaming.com regularly for any updates.

How to use this controller on PC

The Evol-X PRO controller is a Plug-n-Play device. The necessary driver software will be automatically installed when the controller is first connected to your computer. Here is the detailed procedure to follow:

- Turn on your computer, wait for it to start, and go to your Windows desktop.
- Find an unused USB port on your PC and plug the USB cable of your Evol-X PRO controller into it.
- Windows will detect the new device and, after a few seconds, start installing the appropriate drivers. The process will be indicated by a small icon in the task bar.
- The installation takes more or less time depending on the speed of your system. At the end of the process, the following message will appear: «You can now use your Evol-X PRO. »

How to change the LED effects

- The controller includes 20 preset light effects and to switch between them you just have to do a short press on the multifunction button.
- Keep pressing the button to cycle through the different effects. When you find the one you want stop pressing the button. Note that when you reach the end of the LED effects the LEDs will turn off. Just press the button again to turn them back on.

How to map the shortcuts

- Press and hold the multi-function button for 3 seconds.
- The status LED will flash.
- Then press the shortcut button that you want to map, followed by the button that you want to assign to that shortcut.
- Repeat the process for each shortcut.
- To reset the mapping on the shortcut double press it.
- To finish the mapping, press and hold the multi-function button for 3 seconds.

Recycling

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it should be taken to an applicable collection point for the recycling of electrical and electronic equipment. By ensuring that this equipment is disposed of correctly you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more information please contact your local council or waste disposal service EU, UK and Turkey only.

Turkey

AEEE Yönetmeliğine Uygundur.

If you require further information about this legislation please click on the link

<http://www.tukcev.org.tr/assets/yonetmelikler/AEEYYonetmeligi.pdf>

Important precautions

1. This product is designed for indoor use only. Do not expose it to direct sunlight or bad weather.
2. Do not expose the product to splashes, rain, drips or moisture. Do not immerse it in a liquid.
3. Do not expose to dust, high levels of humidity, extreme temperatures or mechanical shocks.
4. Do not use and do not open if the equipment is damaged. Do not attempt to repair it.
5. When cleaning the outside, only use a soft, clean and damp cloth. Detergents can damage the finish and get inside the product.
6. Do not carry the product while holding it by the cable.
7. This product is not designed for people (including children) suffering from a physical, sensory or mental disability, or for users without the necessary and relevant experience or knowledge (unless they have been given advice and instructions on how to use the device from a person responsible for the user).
8. Do not leave the product unattended, do not leave this product within the reach of children. Not suitable for children under 7 (the cable can get wrapped around the neck).
9. This product shall not be connected to power supply source exceeding 15W. rated 5VDC 500mA.
10. The maximum operating temperature must not exceed 35°C.

Ergonomics

Keeping your hand in the same position for a prolonged period of time can result in pain. If this happens repeatedly, please consult your doctor. As a precaution, take a 15-minute break every hour.

Technical support

- Email: support@nacongaming.com

- Website: www.nacongaming.com

Legal Notices

Windows™ 7/8/10/11 are registered trademarks of Microsoft Corporation.

EU Declaration of Conformity

- Product: XBXEVOL-X PRO
- Manufacturer: Nacon
- Nacon declares that this product is in compliance with the Union harmonisation legislation:
 - Directive 2014/30/EU for Electromagnetic Compatibility.
 - Directive 2011/65/EU the restriction of the use of certain hazardous substances in electrical and electronic equipment.
- The full text, of the EU Declaration of Conformity, is available at the following website:
my.nacongaming.com/en-GB/support

UK Declaration of Conformity

- Product: XBXEVOL-X PRO
- Manufacturer: Nacon
- Nacon declares that this product is in compliance with the United Kingdom legislation:
 - Electromagnetic Compatibility Regulations 2016.
 - The restriction of the use of certain hazardous substances in electrical and electronic equipment regulations 2012.
- The full text, of the UK Declaration of Conformity, is available at the following website:
my.nacongaming.com/en-GB/support

FCC: Declaration of Conformity

United states

This product complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

ABOUT COMPANY

- **Bigben Interactive DEUTSCHLAND GmbH**
Walter Gropius Str. 28, 50126 Bergheim, Deutschland
- **Bigben Interactive Belgium s.a./n.v.**
 - Boulevard d'Angleterre 2 / Bte 4
 - 1420 Braine l'Alleud, Belgium
- **Bigben Interactive NEDERLAND b.v.**
's-Gravelandseweg 80, 1217 EW Hilversum, Nederland
- **Nacon Gaming ESPAÑA S.L.**
Calle Velázquez, 31 3º Dcha, 28001 Madrid, España
- **Bigben Interactive ITALIA s.r.l**
Corso Sempione 221, 20025 Legnano – MI, Italia
- **Nacon Gaming Inc.**
1124 8TH Street, Kirkland, WA 98033 USA
- **Nacon Pty. Ltd.**
Level 2/20 Bond Street, Sydney NSW 2000 Australia
FABRIQUÉ EN CHINE / MADE IN CHINA
WWW.NACONGAMING.COM

SUPPORT :


- **UK,**
 - support@nacongaming.com
 - **Tel.:** +44 08081010970
- **DEUTSCHLAND, Montag bis Freitag von 09:00 bis 18:00 Uhr**
 - **Tel.:** 02271-9047997
 - **Mail:** support.de@nacongaming.com
- **BELGIQUE**
support.be@nacongaming.com
- **NEDERLAND**
support.nl@nacongaming.com
- **ESPAÑA**
 - support.es@nacongaming.com
 - **Tel.:** +34 900993359
- **ITALIA**
 - support.it@nacongaming.com
 - **Tel.:** +39 800172494
- **USA/CANADA**
support.us@nacongaming.com
- **AUSTRALIA**

support.us@nacongaming.com

- MEXICO

soporte@nacongaming.com

Documents / Resources

	<p>nacon EVOL X PRO Light Controller [pdf] User Guide EVOL X PRO Light Controller, EVOL X PRO, Light Controller, Controller</p>
---	---

References

- [🌐 Support - MyNacon](#)
- [🎮 Manettes, Jeux vidéo, RiG, Equipements gaming - Nacon](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.