nacon GC-100XF PC Gaming Controller





nacon GC-100XF PC Gaming Controller Instruction Manual

Home » nacon » nacon GC-100XF PC Gaming Controller Instruction Manual

Contents

- 1 nacon GC-100XF PC Gaming Controller
- 2 Guarantee
- 3 Product specifications
- 4 Contents of the package
- **5 Control elements**
- 6 First connection with the PC
- 7 Important Safeguards & Precautions
- **8 Technical Specification**
- 9 Documents / Resources
 - 9.1 References



nacon GC-100XF PC Gaming Controller



NACON™ GC-100XF gaming controller for PC.

Thank you for purchasing this NACON product. In case of a malfunction please refer to the support information at the end of this manual. We highly appreciate any feedback which helps us to improve our products. Please keep this instruction manual for future reference.

Guarantee

This product bearing the NACON trademark is guaranteed by the manufacturer for 2 years from the date of purchase, and will, during this period be replaced with the same or a similar model, at our option, free of charge, if there is a defect due to faulty material, or workmanship.

For any warranty request or claim, please keep your proof of purchase for the duration of the warranty. Without this document, we won't be able to process your request. The original packaging must be kept for all distance purchases (mail order & Internet).

This guarantee does not cover defects arising from accidental damage, misuse or wear and tear. This does not affect your statutory rights.

To access the declaration of conformity, please visit: www.my.nacongaming.com/en-GB/support.

Product specifications

Gaming controller for Windows PCs 2 analogue sticks, 4 keys, 2 triggers, 2 high triggers, digital pad, BACK and START keys and D/X selection button. Switchable DirectInput8 and XInput mode for 100% compatibility with all PC games Soft touch treatment and rubber inlays for perfect grip 2 vibration motors Compatible with Windows Vista®/7/8/10

Contents of the package

- NACON GC-100XF gaming controller
- Quick IB

Control elements



- 1. Left analogue stick
- 2. Right analogue stick
- 3. D-Pad
- 4. Action buttons 1-4
- 5. Left trigger and shoulder button
- 6. Right trigger and shoulder button
- 7. BACK button
- 8. START button
- 9. HOME button
- 10. D/X switch

First connection with the PC

The NACON GC-100XF controller is also a Plug-and-play device. In other words, the necessary driver software will be automatically installed when the controller is first connected to your computer. Here is the detailed procedure to follow:

- Turn on your computer, wait for it to start, and go to your Windows desktop.
- Find a USB port on your PC that's not in use and connect the USB cable from your NACON GC- 100XF controller to it.
- Windows will detect the new device and, after a few seconds, start installing the appropriate drivers. The process will be indicated by a small icon in the task bar.
- Installation takes more or less time depending on the speed of your system. At the end of the process, the following message will appear: "You can now use your GC-100XF."

D/X switch

Modern PC games and your controller communicate in different ways. Your GC-100XF supports the two most common communication modes: DirectInput and XInput. Sometimes, a game only supports one of these two protocols. As these cannot be executed simultaneously, your GC-100XF is equipped with a D/X switch (10) which

lets you select one of these two protocols, thus guaranteeing you the possibility of playing all games.

Note: after changing the protocol, please wait a few moments for the controller to switch to the new protocol.

Recycling

When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/EC. Please inform yourself about the local separate collection system for electrical and electronic products.

Important Safeguards & Precautions

- 1. This product is designed for indoor use only. Do not expose it to direct sunlight or bad weather.
- 2. Do not expose the product to splashes, rain, drips or moisture. Do not immerse it in a liquid.
- 3. Do not expose to dust, high levels of humidity, extreme temperatures or echanical shocks.
- 4. Do not use and do not open if the equipment is damaged. Do not attempt to repair it.
- 5. When cleaning the outside, only use a soft, clean and damp cloth. Detergents can damage the finish and get inside the product.
- 6. Do not carry the product while holding it by the cable.
- 7. This product is not designed for people (including children) suffering from a physical, sensory or mental handicap, or for users without the necessary and relevant experience or knowledge (unless they have been given advice and instructions on how to use the device from a person responsible for the user). Do not leave the product unattended, do not leave this product within the reach of children. Not suitable for children under 7 (the cable can get wrapped around the neck).
- 8. The maximum operating temperature must not exceed 35°C.

Ergonomics

Holding your hand in the same position for a longer period can lead to aching and pain. If this occurs repeatedly please consult your doctor. As a precaution we recommend that you take a 15 minute break every hour.

Technical Specification

USB controller

• Weight: 266g

• Height x Width x Depth: 154 x 119 x 54mm

• Cable length: ca. 2m

• Consumption: 5V === 500mA

• ===: DC power supply

Technical Helpline Information

• UK

Email: support@nacongaming.com

Tel.: (+44)08081010970

Australia

Email: <u>support.us@nacongaming.com</u>

Tel.: (+61)1300512410

America

Email: <u>support.us@nacongaming.com</u>

• Europe Other

Email: <u>www.nacongaming.com</u>
Website: <u>www.nacongaming.com</u>

Legal lines

Windows® Vista®/7/8/10 are a registered trademarks of Microsoft Corporation.

MANUFACTURER

NACON - 396 - 466 Rue de la Voyette, CRT2 - 59273 Fretin, France

DISTRIBUTORS

• Bigben Interactive DEUTSCHLAND GmbH

Walter Gropius Str. 28, 50126 Bergheim, Deutschland

• Bigben Interactive Belgium s.a./n.v.

Waterloo Office Park / Bâtiment H Drève Richelle 161 bte 15, 1410 Waterloo, Belgium

• Bigben Interactive NEDERLAND b.v.

's-Gravelandseweg 80, 1217 EW Hilversum, Nederland

SUPPORT:

FRANCE, du lundi au vendredi: 10h00-18h00 ou <u>support.fr@nacongaming.com</u>

• UK, <u>support@nacongaming.com</u>

Tel.: +44 08081010970

• **DEUTSCHLAND**, Montag bis Freitag

von 09:00 bis 18:00 Uhr **Tel.**: 02271-9047997

Mail: support.de@nacongaming.com

- BELGIQUE, support.be@nacongaming.com
- NEDERLAND, support.nl@nacongaming.com
- ESPAÑA, support.es@nacongaming.com

Tel.: +34 900993359

• ITALIA, support.it@nacongaming.com

Tel.:+39 800172494

- USA/CANADA, support.us@nacongaming.com
- AUSTRALIA, support.us@nacongaming.com
- MEXICO, <u>soporte@nacongaming.com</u>

MADE IN CHINA
WWW.NACONGAMING.COM

Nacon®, 396 – 466 Rue de la Voyette, CRT2 59273 Fretin, France ©2O21 Nacon® 852 538 461 R.C.S. Lille Métropole – 59814 Lesquin Cedex. All the trademarks belong to their respective owners

Documents / Resources



nacon GC-100XF PC Gaming Controller [pdf] Instruction Manual GC-100XF PC Gaming Controller, GC-100XF, PC Gaming Controller, Controller

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.