

 **nacon**
MG-X PRO
Wireless
Game
Controller



nacon MG-X PRO Wireless Game Controller Instruction Manual

[Home](#) » [nacon](#) » nacon MG-X PRO Wireless Game Controller Instruction Manual 

Contents

- [1 nacon MG-X PRO Wireless Game Controller](#)
- [2 Product Usage Instructions](#)
- [3 Warranty](#)
- [4 Product features](#)
- [5 Control elements](#)
- [6 Precautions for use regarding the battery](#)
- [7 Technical specifications](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



nacon MG-X PRO Wireless Game Controller



Specifications:

- Product: Nacon MG-X PRO controller for Android phones
- Asymmetrical joysticks
- Built-in rechargeable battery via USB-C
- 20 hours of battery life
- Compatible with Android 6.0 and later
- Bluetooth 4.2+BLE connection to a smartphone
- Universal compatibility up to 6.7" maximum opening size

Product Usage Instructions

Turning the Controller On/Off:

To turn on the controller, press the Nexus button. The controller will automatically connect to the last synced phone. To turn it off, press and hold the Home button for 6 seconds. Note that the controller will turn off after 15 minutes of inactivity to conserve battery.

Low Battery Indicator:

When the battery is low, the battery LED will flash red slowly. If the battery is very low, the LED will flash red quickly.

Recharging the Controller:

To recharge the controller's internal battery, connect the provided USB-C cable to the charging port located below the D-pad. Plug the other end into a free USB port on your PC. The red LED will stop flashing when charging

begins. Once fully charged, the LED will turn green and then turn off when unplugged.

Positioning Your Phone:

When using the Nacon MG-X PRO controller with your phone, securely place your device in the dedicated slot for optimal gameplay.

FAQ:

Q: Is the Nacon MG-X PRO controller compatible with Apple products?

A: No, this controller is not compatible with Apple products.

Thank you for purchasing this NACON® product

This product has been designed to enhance your gaming experience. Please keep this user manual in a safe place for future reference.

Warranty

To access the declaration of conformity, please go to: <https://my.nacongaming.com/support>

Product features

- Nacon MG-X PRO controller for Android phones
- Asymmetrical joysticks
- Built-in battery, rechargeable via USB-C
- 20 hours of battery life
- Compatible with Android 6.0 and later
- Bluetooth connection to your smartphone (Bluetooth 4.2+BLE)
- Universal compatibility up to 6.7"
- Maximum opening size 163 mm

Control elements



Turning the controller on/off

- To turn on the controller, simply press the Nexus button, and the controller will connect to the last phone it was synced with.
- To turn off the controller, simply hold down the Home button for 6 seconds.
- Please note: the controller turns off after 15 minutes of inactivity to save battery power

Syncing your Android phone with the Nacon MG-X PRO controller

- Go to the Bluetooth menu on your phone and start a Bluetooth device search.
- Press the Nexus button on your controller, and the player indication LED should start flashing steadily.
- Press and hold the Bluetooth button on the lower right-hand side for 3 seconds to initiate pairing. The player indicator LED should start flashing rapidly.
- On your phone, you should see the controller appear under the name 'Nacon MG-X PRO', select it and wait until the controller is in the list of paired devices.

Low battery indicator

- When the battery is low, the battery LED flashes red slowly.
- When the battery is very low, the battery LED flashes red quickly.

Recharging the controller

The controller is equipped with an internal battery. To charge this battery, take the USB-C cable that comes with the controller and plug it into the charging socket/port (located below the D-pad). Then plug the other end into one of the free USB ports on your PC. The Red LED will stop flashing. Once recharged, the LED will turn green and turn off when the cable is unplugged.

Compatibility

- The Nacon MG-X PRO controller allows you to play on Microsoft's cloud gaming service.
- An Xbox Game Pass subscription is required to access the gaming service.
- The Nacon MG-X PRO controller is compatible with Android games that support controllers.
- **Warning:** This controller is not compatible with Apple products.

Positioning your phone

When using your phone with the NACON Nacon MG-X PRO controller, please place your phone in the dedicated slot to secure your device.

Please note: If your phone has a case, it may keep your phone from correctly fitting into the dedicated slot. In this case, to avoid dropping your phone, it is best that you remove your phone case.

Warning: Please be careful not to catch your fingers in the sliding system when removing your phone from the MG-X PRO

Recycling

Do not dispose of this product with household waste. Dispose of your old electrical appliance at a suitable collection center. Recycling is important and helps protect the environment by reducing waste. EU and Turkey only
Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed of with

normal household waste. Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environment and human health.

Important precautions

1. This product is designed for indoor use only. Do not expose it to direct sunlight or bad weather.
2. Do not expose the product to splashes, rain, drips or moisture. Do not immerse it in a liquid.
3. Do not expose to dust, high levels of humidity, extreme temperatures or mechanical shocks.
4. Do not use and do not open if the equipment is damaged. Do not attempt to repair it.
5. When cleaning the outside, only use a soft, clean and damp cloth. Detergents can damage the finish and get inside the product.
6. Do not carry the product while holding it by the cable
7. This product is not designed for people (including children) suffering from a physical, sensory or mental impairment, or for users without the necessary and relevant experience or knowledge (unless they have been given advice and instructions on how to use the device from a person responsible for the user).
Do not leave the product unattended, do not leave this product within the reach of children. Not suitable for children under 7 (the cable can get wrapped around the neck).
8. The maximum operating temperature must not exceed 35°C

Precautions for use regarding the battery

- If your product has a built-in, non-replaceable battery, do not attempt to open the product or remove the battery, as you may damage the product and/or injure yourself.
- If your product has a built-in replaceable battery, only use the type of battery supplied by Nacon/ RIG. Used batteries should be removed promptly and taken to appropriate collection centres. RECYCLING: The product battery should be recycled or disposed of in the proper manner. Contact your local recycling centre for instructions on battery removal and disposal.
- The battery has a limited lifespan. Battery charge duration gradually increases with repeated usage and age. Battery life also varies depending on the storage method, usage state, environment and other factors.
- Charging may not be as effective when performed in other environments.
- Battery duration may vary depending on the usage condition and environmental factors.

When not in use :

When the controller is not used for an extended period of time, it is recommended that you fully charge it at least once a year in order to maintain its functionality

WARNING: Risk of fire, explosion and burns

- Do not leave your charged battery for an extended period without the product being used
- Prevent metal objects such as keys or coins from coming into contact with a battery or its holder.
- Do not attempt to open or damage the battery. It may contain corrosive products which are dangerous if they come into contact with eyes or skin and are toxic if ingested.
- Never put a battery in your mouth. If ingested, contact a doctor or poison control centre.
- If the product contained in the battery comes into contact with your clothes, skin or eyes, please wash thoroughly with clear water and contact your doctor immediately.

- Always keep batteries out of the reach of children.
- Never throw a battery into a fire or oven; crushing or cutting a battery may cause an explosion;
- A battery should not be subjected to extremely high or low temperatures, low air pressure at high altitude during use, storage or transportation, as this may cause an explosion or leakage of flammable liquid or gas

Ergonomics

Keeping your hand in the same position for a prolonged period can result in pain. If this happens repeatedly, please consult your doctor.

As a precaution, take a 15-minute break every hour.

Technical specifications

- Dimensions: 236 x 105 x 49 mm
- Cable length: 80 cm
- Consumption: 5V 500mA
- : DC power supply
- Battery life: 20 hours
- Charging time: >2 hours
- Battery capacity 600mA
- The maximum operating temperature of the controller is 35°C
- Information on the emission power of the product:
 - Frequency band: (2.402 ~ 2.480) GHz
 - Maximum radio frequency transmission power: 1.70dBm lever

Legal Notices

Windows™ 10 is registered trademark of Microsoft Corporation.

MANUFACTURER / FABRICANT :

NACON – 396 – 466 Rue de la Voyette, CRT2 – 59273 Fretin, France

DISTRIBUTORS / DISTRIBUTEURS

- Bigben Interactive DEUTSCHLAND GmbH
Walter Gropius Str. 28, 50126 Bergheim, Deutschland
Bigben Interactive Belgium s.a./n.v.
- Waterloo Office Park / Bâtiment H
Drève Richelle 161 bte 15, 1410 Waterloo, Belgium
- Bigben Interactive NEDERLAND b.v.
's-Gravelandseweg 80, 1217 EW Hilversum, Nederland
- Nacon Gaming ESPAÑA S.L.
Calle Velázquez, 31 3º Dcha, 28001 Madrid, España
- Bigben Interactive ITALIA s.r.l
Corso Sempione 221, 20025 Legnano – MI, Italia
- Nacon Gaming Inc.
1124 8TH Street, Kirkland, WA 98033 USA Nacon Pty. Ltd.

SUPPORT

FRANCE, du lundi au vendredi :

10h00-18h00 ou support.fr@nacongaming.com

UK, support@nacongaming.com

Tel.: +44 08081010970

DEUTSCHLAND, Montag bis Freitag von 09:00 bis 18:00 Uhr

Tel.: 02271-9047997 Mail: support.de@nacongaming.com

BELGIQUE, support.be@nacongaming.com

NEDERLAND, support.nl@nacongaming.com

ESPAÑA, support.es@nacongaming.com

Tel.: +34 900993359

ITALIA, support.it@nacongaming.com

Tel.: +39 800172494



USA/CANADA, support.us@nacongaming.com

AUSTRALIA, support.us@nacongaming.com

MEXICO, soporte@nacongaming.com

WWW.NACONGAMING.COM

Documents / Resources

  MG-X PRO ERGONOMIC - WIRELESS - UNIVERSAL	nacon MG-X PRO Wireless Game Controller [pdf] Instruction Manual MG-X PRO, MG-X PRO Wireless Game Controller, Wireless Game Controller, Game Controller, Controller
--	--

References

- [🕹️ Manettes, Jeux vidéo, RIG, Equipements gaming - Nacon](#)
- [🕹️ Manettes, Jeux vidéo, RIG, Equipements gaming - Nacon](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.