



NAIFAY Wireless Carplay and Android Auto Instructions

[Home](#) » [NAIFAY](#) » NAIFAY Wireless Carplay and Android Auto Instructions 

Contents

- 1 NAIFAY Wireless Carplay and Android Auto
- 2 INSTALLATION
- 3 INTERFACE DESCRIPTION
- 4 REVERSING CAMERA INSTALLATION METHOD
- 5 MAIN INTERFACE
- 6 Phonelink (CarPlay & Android Auto & Mirrorlink)
- 7 Mirrorlink (Android)
- 8 Mirrorlink (iPhone)
- 9 SYSTEM SETTINGS
- 10 REMOTE CONTROL FUNCTION
- 11 TROUBLESHOOTING
- 12 Documents / Resources
 - 12.1 References

NAIFAY

NAIFAY Wireless Carplay and Android Auto



INSTALLATION

BEFORE INSTALLATION


Thank you very much for purchasing and using our products. when you receive the product. please do not take the product directly to the car for installation. because the product is in the after a long journey. it may affect the product. Please try the machine before installing.


Test method: Take the machine to the battery of the car and test it. This car stereo applies to a power supply voltage at 12V DC. Connect the red and yellow wires of the power cord of the machine together and connect it to the positive pole of the battery. The black wire of the power cord is connected to the negative pole of the battery. Wait for 10 seconds after connecting. press each button of the machine to see if the machine can boot normally. If it can be turned on. it means there is no problem. you can install it. If the test machine can not start normally. please again Confirm that you follow the steps of our test method in strict accordance with the operation. If the problem is still not solved. please contact our work in time.

Thank you for your cooperation.

INTERFACE DESCRIPTION


REAR INTERFACE DESCRIPTION





- When the yellow line B+ and the red line ACC have a 12V positive power at the same time, the unit can be turned on normally.
- The yellow line B+ keeps the power on and the machine has a memory function.
- 8 speaker cables, each cable can not be grounded, can not be shared, can not touch the line, otherwise there will be no sound output, output sound distortion, machine fever and so on.


REVERSING CAMERA INSTALLATION METHOD



If the reversing camera is not installed, please do not connect the REVERSE/BACK cable to any place. Please leave the cable unconnected, otherwise the machine will not display properly, or it will automatically enter the reverse mode, which will cause the machine to fail. In case of such a situation, please disconnect the

REVERSE/BACK line as soon as possible to avoid affecting the normal use of the user.

MACHINE FIXED REFERENCE METHOD



MAIN INTERFACE



1. HOME: Return to the main interface.
2. Return: Return to the previous interface.
3. RADIO: Enter the radio mode to listen to the radio station.
4. BT: Enter the BT mobile phone music and BT call interface.
5. Phonelink: CarPlay / Android Auto / Mirrorlink function. Connect the machine and the mobile phone through a USB cable. and the car screen can be used as the second screen of the mobile phone.
6. USB: Playing music/video/pictures in a USB flash drive (Front USB).
7. AV IN: Enter the AV IN external audio mode interface.
8. Setup: Enter the system setting interface.
9. BT music: Play mobile music by connecting Bluetooth.
10. Sound: Enter the EQ sound effect setting interface
11. Logo: You can select multiple car logos provided by the system to set the boot interface, or customize the boot logo by putting pictures into the USB flash disk.

AV In FUNCTION




You can connect an external audio player. such as a mobile phone or iPod. through the 3.5MM Front AUX hole.

STEERING WHEEL CONTROLS



By learning, turn the buttons on the steering wheel into the function buttons of the player.



Wiring Method:

1. Locate the positive pole of the original car steering wheel button control line and connect it to the KEY line on the machine's output line.
2. Locate the negative pole of the original steering wheel button control line and connect it to the ground (power negative) line on the machine's output line.

Learning Method:

1. First press and hold the function key on the steering wheel, and then click the desired function key on the car screen. At this time, the key on the screen will be always on, indicating that the learning is successful. Then learn the second button in the same way. Finally, press the confirm button to complete the study.
2. When the operation error needs to be re-learned, just press the reset button and then re-learn.

Sound Setup



Rdio Function



1. ◀ ◀ / ▶ ▶ : Short press to automatically search for the next station and play it: Long press to manually search for radio stations. step by 0.05MHz for each press. then long press P1. P2. P3. P4. P5. P6 to save the radio station.
2. Pre-stored stations. Can store 18 radio stations. When you need to listen to a certain fixed station. just click it.
3. FM: Band switching. switchable FM1-FM2-FM3.
4. AS, Automatically search and store full-band radio stations.
5. Introduce: Radio browsing
6. LOC/DX, Long-range/short-range broadcast.
7. Enter the EQ sound effect setting interface.

BT FUNCTION



1. Make a call interface.

2. Call history interface.
3. Contact interface.
4. BT pairing interface.
5. BT Music interface.
6. Answer call key.
7. Dial keypad interface.
8. Backspace key.
9. BT Music Prev / next track.
10. Pause music/ resume playback

- Device Name: "CarPlay BT"
- PIN Number: "0000" (If need) Connection Method:
 1. Power on the machine and turn it on.
 2. Turn on the BT function on the mobile phone. click Search Device. when the mobile device list searches for the BT device name of the current machine, click the device name to connect it.

Please note that:

The car Stereo is connected to the wireless carplay&Android Auto function by default, so when you connect to Bluetooth, the wireless carplay&Android Auto function will be directly connected by default. If you need to use the Bluetooth function alone/use the wired carplay&Android Auto/use the Mirror Links function, please follow the steps below:

Method 1 (Please note: This method will cause the wired carplay&android auto function to be unavailable.):

- **Iphone:** Please enter the CarPlay operation interface: Setting-General-CarPlay. Select your car in the CarPlay interface, and turn off the CarPlay function in the following interface.
- **Android phone:** Please enter the Android Auto operation interface: Setting-Connection&sharing-Android Auto, Close the Wireless Android Auto function in the Android Auto operation interface.

Method 2: Turn off your phone's Wi-Fi function.

Phonelink (CarPlay & Android Auto & Mirrorlink)


When connected to the USB data cable. you can project the phone screen to the



1. iPhone enter Apple carplay mode.
2. iPhone enter Mirrorlink mode.
3. iPhone Default state. "CarPlay or Mirrorlink" is selected.
4. Android phone enter Mirrorlink mode.
5. Android phone enter Android Auto mode.
6. Android Default state. "Android Auto or Mirrorlink" is selected.


Apple CarPlay (CarPlay)


1. Connect the iPhone and the machine with a USB data cable.
2. Then the machine will automatically enter the carp lay interface.
3. After exiting. you can press Phonelink on the HOME to enter the carplay function again.




Android Auto (Auto)

This feature is not supported in all countries. and "Google Play" services need to be available locally.

1. Need to download and install "Android Auto"  software in "Google Play".
2. A mobile phone with Android 6.0 or higher must be used. Must use a valid data cable connection.
3. Connect Mobile Phone and the machine with a USB data cable. (It is not necessary to turn on the USB debugging mode.)
4. Then the machine will automatically enter the Android Auto interface.



[You can also control your android phone here.](#)



Wireless Apple CarPlay & Android Auto save turned on i and Setola. After the diast come on, it can be automatically connected after each subsequent startup.

- Method 1 (not recommended): use the data line to connect the car stereo, use the wired carplay and Android auto function, wait for 1 minute, and pay android auto function. ais method ay be unstablecale to different mobile phone models and system versions.)
- Method 2 (recommended): Connect the Bluetooth function of the car stereo (see pages 7 and 8 for specific methods), and wait for a few seconds before automatically connecting.

Please note: when connecting for the first time, if the interface stays in the race, plas e check whether the Timbie phone has the car play dection droid auto function turned on (see the introduction of turning off the function on page 8 for the specific method), or the problem cannot be solved. Please restart the mobile phone and car stereo to try again.

Mirrorlink (Android)

The system supports most Android phones below Android 11.0. If you cannot connect , please contact us .

1. Open developer mode(Since different mobile phones have different ways to open the developer mode , please find the way to open the developer mode for the corresponding mobile phone model through the browser . You only need to set it once , and then the connection does not need to be set again .)
2. Open “USB debugging”(Since different mobile phones have different ways to open “USB debugging”,please find the way to open “USB debugging” for the corresponding mobile phone model through the browser. You only need to set it once , and then the connection does not need to be set again .)
3. Connect the mobile phone to the car car stereo through the USB cable, download the software according to the mobile phone prompt , and then the mobile phone screen content can be projected onto the car stereo.



[You can also control your android phone here.](#)


Mirrorlink (iPhone)

When the device is plugged into the iPhone. the content on the phone's screen is projected onto the car's screen. and the sound is transmitted in sync.



SYSTEM SETTINGS

Basic Setup:



1. Beep, Key tone switch.
2. Reverse Mute, Mute switch when reversing.
3. Watch the video warning while driving.
4. Front camera setting
5. Key light settings.
6. 7 Color light change interval time.
7. Touch calibration
8. Restore to factory settings.

Radio area:



Set the appropriate radio frequency according to the region.

Factory Set:




Enter the password “113266” to enter the factory setting interface.

Display Settings:



Brightness, contrast, hue, saturation can be set.

Background image settings:



Toggle background image.


Language settings:



Language settings for multiple countries.

REMOTE CONTROL FUNCTION

1. Power switch
2. ◀ Left
3. Mode switch
4. Last song
5. USB/SD
6. Volume-
7. Band/ Automatic/ Station Search
8. Digital key
9. ▲ Up
10. Menu
11. Confirm/P lay/Pause
12. ▶ Right
13. TUnder
14. Next song
15. Choice
16. Volume+
17. Answer the phone
18. Hang up



NOTE:

1. Before using the remote control, please remove the battery insulation paper at the bottom of the remote control.
2. If the remote control does not work, please take the battery off and wipe it, then put it back. Generally it can be used normally. Still not working, it may be that the remote control battery is low, please replace the remote control battery.

TROUBLESHOOTING

COMMON PROBLEMS AND SIMPLE TROUBLESHOOTING

Unable to boot normally

Reason for not booting

1. 'Yellow' 'Red' 'Black' these 3 lines only connected 2 lines of them, so it will not start, it should be that the yellow line is connected to the positive pole, red line to the key control line, black to the negative pole. Less connection or wrong connection does not boot.
2. The original car line and unit wiring can not be connected to the color, the color of the original car line is not standard. If you connect like that it can not only be turned on but also may burn.
3. The original car plug can't be plugged directly into the new unit, even if it just plugs in, it can't be used, otherwise it won't be turned on or burned.
4. The 3 wires are connected right, but it does not boot. Check if the fuse on the yellow line is broken. If there is no problem with the fuse, twist the yellow and red wires together. Turn on the key and press the unit's power button to see if it can be turned on.
5. Every time you change the fuse, it burns. Please don't change it again. The reason is that when you first connect the positive and negative poles, the protection circuit of the unit is short-circuited. The unit can be repaired under the guidance of our master. No basis can only be returned to the after-sales or new unit. If there are no problems, or also don't boot, please make the final step to confirm. Find a 12V battery or 12V power supply -yellow- and "red" twist together with the positive, black to the negative pole, press the button check if it

can boot or no, if you can boot. it showed that the original car line is not right connect, or there is a problem with the car line. If it can't be boot. the unit is broken. Does not boot unit. check the Line carefully. do not blindly suspect the unit problem.

Automatic shut-down

Automatic shutdown usually has these following conditions

1. The cable error connect, If the blue cable (automatic antenna power supply) is connected to the power cable of the unit. an automatic shutdown will occur. Please follow the correct wiring method to solve the problem.
2. The voltage is unstable, please find a 12V-5A which one is the power supply and retested to see if it will automatically shut down. If it does not automatically shut down after the test. please replace the power supply. If it will automatically shut down. it is problem with the unit.

3. Having noise

The general situation of noise is caused by two reasons

1. The original speaker power is too small When the volume of the unit is turned up. there will be noise.

Solution: When replacing the speaker or Listening to the song. the volume should not be too large.

2. The speaker cable is grounded. Solution, Take the iron speaker cable. Directly connected to the speaker cable of the unit

4. Remote control cannot be used

Check if the battery of the remote control has power

1. Test method, Tum on the camera of the mobile phone and aUgn the Light of the remote control then press the button of the remote control to see if the phone will light up. If? is not Lit there will be no power. Replace the battery, If is Lil there is electricity. which proves that there is no problem with the remote control.

5. Settings can not be saved (no memory l

There is no memory function. there is only 2 points in memory

1. The yellow line and the red line are connected together (separate yellow to positive. red to key contro O.
2. Yellow and red are reversed ijust change position).

6. Car audio with Bluetooth but it can't work

Check the phone to see if you can search for the unit code

Operation steps: turn on the unit. use the phone Bluetooth search. search for CAR-BT. then click the connection. after connecting. you can answer the phone or Bluetooth to play the song. PIN Code: 0000.

7. The product smoke has proved that the internal circuit has been burned. Change the insurance FUSE can not solve the problem

In this case. the unit needs to be repaired.

8. How to adjust the sound, where is the equalizer set, the sound can not be adjusted

1. Adjust the sound, please turn the volume to adjust.
2. Equalizer settings, In general. press the volume knob to display the equaUzer SEL. and rotate the volume button to adjust each sound effect.
3. The sound cannot be adjusted,
 - a. Please reset the unit or unplug the power cord and plug it in.
 - b. The Volume knob is broken. and the knob can be replaced.

9. No display of reversing video

1. Connect the wrong Line or less wiring. Camera connection method, a> The first step is to find

accessories (accessory, one camera + one power cord + one video cable). b> The second step is to find the port of the wiring.

First find the reverse control Line on the power Line of the unit. The control Line is a pink Line or brown line. connect this line to the positive pole of 12V and the screen will turn blue. And then find the back of the unit the CAME video input interface. find the positive and negative of the backup Light. The third step is connect, there are two sockets on the camera. the red socket is connected to the power cable. the yellow is inserted into the video cable. the red wire of the power cable and the wire of the video cable are screwed together on the positive pole of the reverse lamp. and the black wire of the power cable is not used. connected. the other end of the video cable is connected to the CAME video input interface on the back of the unit. The red Line coming out of the video Line is connected to the reversing control Line of the power line.

2. The camera is broken. If the lamp that is properly wired to the camera is not Lit. it will be broken and replaced with a new one.

10. USB flash disk can not be played, the card slot does not enter the card? USB flash disk can not play, Format the USB flash disk. and the file system is selected as: FAT32. re-download on or two songs and try again. If it still doesn't work. please replace the USB flash drive.

The card slot does not enter the card:

- Check whether the memory card is inserted. the plug is broken.

11. FM does not receive the radio station Can not receive the station check the 2 points

1. The antenna plug is not fully inserted, the antenna is disconnect or the line is disconnect.
2. Search channel hold AMS does not let go for 2 seconds The unit will automatically search or press the up and down button to perform a channel search. Can't solve the above 2 points. Please unplug the antenna plug and find a screwdriver or a metal strip to insert it instead of the antenna.

12. There is no sound right after installation Dear customers. the unit has been tested before shipment. If there is no sound. it is usually a wiring error or the original car speaker wire is short-circuited with iron. According to the steps to check it.

1. Check if the speaker cable is short-circuited and connected. Please reconnect if you have any short circuit.
2. Check how many speaker cables according to the original speaker cable if there are only 2 speaker cables to prove that the original car Line does not match our unit. you need to re-route the original car Line. One speaker must lead to 2 speaker wires. 2 speakers must be have 4 speaker cables to available.

13. There is no sound after a while Disconnect all the speaker cable from the unit (do not remove them). and then find an external speaker to receive the gray and purple of the tail Line of the unit Green any group. and then try to see if there is any sound. If there is a sound. it is proved that the car's speaker Line is short-circuited with iron or the speaker is damaged. If there is no sound. the unit is broken.

If none of the above methods can solve your problem, please contact us by email:

xiewufeng@Leadfan.onaliyun.com



[NAIFAY Wireless Carplay and Android Auto](#) [pdf] Instructions
Wireless Carplay and Android Auto, Wireless, Carplay and Android Auto, Android Auto

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)