

## natec FELIMARE Wireless Keyboard User Manual

[Home](#) » [natec](#) » natec FELIMARE Wireless Keyboard User Manual 

### Contents

- [1 natec FELIMARE Wireless Keyboard](#)
- [2 INSTALATION](#)
- [3 REQUIREMENTS](#)
- [4 SAFETY INFORMATION](#)
- [5 TROUBLESHOOTING](#)
- [6 WARRANTY](#)
- [7 GENERAL](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)
- [9 Related Posts](#)

# natec


**natec FELIMARE Wireless Keyboard**



## INSTALLATION

### PAIRING A NEW DEVICE WITH KEYBOARD IN BLUETOOTH MODE

- Turn on your computer or other compatible device.
- Turn on Bluetooth in the device you want to pair with the keyboard.
- Hold down FN + BT1 or BT2 buttons for 3 seconds to select Bluetooth mode.
- Flashing of the LED diode will notify of entering the pairing mode.
- Select Natec Felimare from the list on your device.
- After successful pairing the LED diode on the keyboard will stop flashing.
- The keyboard is ready for use.



### CONNECTING THE KEYBOARD WITH THE PREVIOUSLY PAIRED DEVICE

- Turn on Bluetooth on your device that you have previously paired with the keyboard.
- Turn on the keyboard from hibernation by pressing any key.
- The keyboard will automatically connect with the device.



### CONNECTION OF KEYBOARD VIA USB RECEIVER

- Turn on your computer or other compatible device.
- Connect included USB receiver to a free USB port on your device.
- The operating system will automatically install the required drivers.
- Press FN + 2.4G buttons to switch into connection mode 2.4 GHz, LED diode will flash once.
- The keyboard is ready for use.


## REQUIREMENTS

- PC or compatible device with a USB port
- Bluetooth 4.0 or above
- Windows® 7/8/10/11, Linux, Android, iOS, Mac

## SAFETY INFORMATION

- Recommended size of device for phone/tablet stand is up to 10". A larger device may tilt the keyboard. Manufacturer is not responsible for damage caused by misuse.
- Use as intended, improper usage may break the device.
- Non-authorized repairs or disassembly voids the warranty and may damage the product.
- Dropping or hitting the device may lead to device being damaged, scratched or flawed in other way.
- Do not use the product in low and high temperatures, strong magnetic fields and damp or dusty surroundings.

## INSERTING / REMOVING BATTERY



## SELECTING THE OPERATING SYSTEM MODE

The keyboard allows to adjust the functions of the keys for individual operating systems. Press FN + Win | iOS | Android | Mac to select the operating system mode.



## CONNECTION MODE CHANGE

To change appropriate connection mode press the keys FN + BT1 | BT2 | 2.4G.



## TROUBLESHOOTING

If you have trouble connecting the keyboard to the USB receiver, perform the pairing procedure.

- Disconnect the USB receiver.
- Reconnect the USB receiver.
- Hold down Fn + 2.4G buttons for about 3 seconds till flashing of LED light.
- The keyboard will pair automatically with the USB receiver.

### Note:

- The device is equipped with intelligent technology for energy management and will enter the hibernation mode after few minutes of not using it. Press any button to turn on the keyboard from the hibernation mode.
- Flashing of LED indicator will inform you about low battery level.
- Frequency band: 2402 Mhz – 2480 Mhz
- Maximum radio-frequency power: -4 dBm

## WARRANTY

2 years limited manufacturer warranty

## GENERAL

- The safe product, conforming to the EU requirements.
- The product is made in accordance with RoHS European standard.
- The WEEE symbol (the crossed-out wheeled bin) using indicates that this product is not home waste. Appropriate waste management aids in avoiding consequences which are harmful for people and environment and result from dangerous materials used in the device, as well as improper storage and processing. Segregated household waste collection aids recycle materials and components of which the device was made. In order to get detailed information about recycling this product please contact your retailer or a local authority.
- Hereby, IMPAKT S.A. declares that the radio equipment type NKL-1973 is in compliance with Directives 2014/53/EU, 2011/65/EU and 2015/863/EU. The full text of the EU declaration of conformity is available via the product tab at [www.impakt-com.pl](http://www.impakt-com.pl).



[WWW.NATEC-ZONE.COM](http://WWW.NATEC-ZONE.COM)

## Documents / Resources

The image shows the front cover of a user manual. At the top left is the 'natec' logo. Below it is a photograph of a black wireless keyboard. At the bottom, the word 'FELIMARE' is printed in large, bold letters, with 'User Manual' in smaller text underneath.	<p><a href="#">natec FELIMARE Wireless Keyboard</a> [pdf] User Manual FELIMARE Wireless Keyboard, FELIMARE, Wireless Keyboard, Keyboard</p>
--	---

## References

- [📄 Producent i dystrybutor sprzętu IT | IMPAKT S.A.](#)
- [🏢 NATEC | natural born technology](#)