



## NAVTOOL IR Remote HDMI Interface User Manual

[Home](#) » [navtool](#) » NAVTOOL IR Remote HDMI Interface User Manual 

### Contents

- [1 NAVTOOL IR Remote HDMI Interface](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)



### NAVTOOL IR Remote HDMI Interface



## Product Information

The IR Remote User Manual is designed and manufactured by NavTool.com. This product is compatible with an HDMI interface and allows users to control the interface from a distance using an IR remote. All product names, logos, brands, trademarks, and registered trademarks are the property of their respective owners.

## Product Usage Instructions


1. Set the vehicle's radio to AUX or an alternative AUX input device. Interface audio will not play through car speakers if AUX is not connected or the radio is not set to AUX input.
2. Aim the remote at the IR receiver and press the power button to turn on and off the interface. If the interface is not displaying on the screen please check that the led in the left arrow on the remote lights up when pressing any button. If it does not light up, check and replace the batteries as needed.
3. Use the following buttons on the IR remote for navigation:
  - Power: Turns the interface ON/OFF
  - Back: Not Applicable
  - Left / Right: Navigate the interface
  - Up / Down: Not Applicable
  - OK: Enter/Select button
  - Voice: Not Applicable
  - Menu: Returns to the bottom interface menu bar after selecting HDMI or Camera Inputs
4. To access HDMI input:
  - Press the Right button on the IR remote to navigate to HDMI.
  - Select HDMI by pressing the OK button. This will display the HDMI input of the HDMI device you connected to the interface.
  - Press the Menu button to return to the bottom menu bar.
  - If no HDMI device is connected, you will get a No Signal HDMI pop up message. Press the OK button to exit the pop-up.

## NOTICE


All product names, logos, brands, trademarks, and registered trademarks are the property of their respective owners.

## User Manual


- Set the vehicle's radio to AUX or an alternative AUX input device.
- Interface audio will not play through car speakers if AUX is not connected or the radio is not set to AUX input.
- Aim the remote at the IR receiver and press the power button to turn on and off the interface.
- If the interface is not displaying on the screen please check that the led in the left arrow on the remote lights up when pressing any button. If it does not light up, check and replace the batteries as needed.





- **Power:** Turns the interface ON/OFF
- **Left / Right:** Navigate the interface
- **OK:** Enter/Select button
- **Menu:** Returns to the bottom interface menu bar after selecting HDMI or Camera Inputs
- **Back:** Not Applicable
- **Up / Down:** Not Applicable
- **Voice:** Not Applicable




## HDMI

- Press the Right button on the IR remote to navigate to HDMI. Select HDMI by pressing the OK button.
- This will display the HDMI input of the HDMI device you connected to the interface.
- Press the Menu button  to return to the bottom menu bar.
- If no HDMI device is connected, you will get a No Signal HDMI pop-up message.
- Press the OK button to exit the pop-up.




## Cameras / Video Input

- Press the Right button on the IR remote to navigate to Camera / Video Inputs. Press the OK button to view the selected input.
- Selecting Camera / Video Inputs will let you see your aftermarket cameras/video inputs if installed.
- Press the Menu button  to return to the bottom menu bar.
- If your vehicle has factory cameras such as a factory rear view camera, you won't be able to manually view them from here.
- It will still automatically display when putting the vehicle in reverse.
- If the vehicle is equipped with CAN, the aftermarket front camera will automatically show when in the drive up to 5-10 mph, and aftermarket left and right cameras will automatically show when activating left and right turn signals.

[NavTool.com](http://NavTool.com) | Call: +1-877-628-8665 | Text: +1-646-933-2100.

## Documents / Resources

	<p><a href="#">NAVTOOL IR Remote HDMI Interface</a> [pdf] User Manual IR Remote HDMI Interface, IR Remote, HDMI Interface</p>
--	---

## References

-  [NAVTOOL INC](#)